

Chalk Board™ PowerPad™ User's Guide



Version 2.0/830730

Copyright © 1983. Chalk Board, Inc. All rights reserved. No portion of this work may be made the subject of a copy, reproduction, derivation, data transmission, adaptation or translation, in whole or in part, without the prior written consent of Chalk Board, Inc. Violation of the Copyright Law may result in substantial civil and criminal damages and penalties.

Chalk Board and PowerPad are trademarks of Chalk Board, Inc. Commodore 64 and VIC-20 are trademarks of Commodore Business Machines.

Atari is a registered trademark of Atari, Inc.

Apple II, Apple IIe and Apple II+ are registered trademarks of Apple Computers.

IBM is a registered trademark of International Business Machines Corporation.

Chalk Board™ PowerPad™ User's Guide



*Chalk Board, Inc.
3772 Pleasantdale Road
Atlanta, Georgia 30340
(404) 496-0101
(800) 241-3989 (outside Georgia)*

Table of Contents	Page
An Introduction	3
Chalk Board PowerPad and Your Computer	4
Making Connections	
Part I: The PowerPad Connector Cable	4
Part II: Commodore 64™ and VIC-20™	5
Part III: Atari® Computers	6
Part IV: Atari® Game Machine (VCS)	7
Part V: Apple II®, Apple IIe® and Apple II+®	8
Part VI: IBM® Personal Computer	9
Taking Care of Your PowerPad	
Temperature	10
Humidity	10
PowerPad's Surface	11
Chalk Board Software	
The Cartridge	12
The Diskette	12
The Software Overlay	12
The Manual	13
Technical Specifications	14

An Introduction

With your purchase of the Chalk Board PowerPad, you are ready to begin one of the most exciting experiences your home computer has to offer. Limitless applications with the Chalk Board libraries of software will lead you to a new level of understanding your computer and making use of its capabilities.

Your Chalk Board PowerPad is a unique technological development, allowing you full communication *with* your computer, but *without* your keyboard. This unconventional means of control over your computer allows you much greater freedom in using your imagination.

You are in charge. No longer are you at the mercy of traditional computer "buzz words" and entry techniques. The Chalk Board PowerPad lets you be the master with the touch of a finger.

To assure your own satisfaction and PowerPad's durability, we at Chalk Board have compiled this manual to help you install PowerPad and maintain it. You will be pleased with the simplicity of starting up your computer system with PowerPad, and with the ease of keeping this state-of-the-art device in good operating condition.

Chalk Board PowerPad and Your Computer

As our packaging tells you, Chalk Board PowerPad requires that you have a home computer, a television or display screen, and any one of the many software packages developed for the various Chalk Board libraries. Each software package comes complete with cartridge or diskette, user's manual and specific PowerPad overlay.

Making Connections

Part I: The PowerPad Connector Cable


You can use only the specially designed PowerPad connector cable to connect PowerPad and your computer.

Do not attempt to use a telephone cord in place of this cable. If you do, you may permanently damage PowerPad.

To connect the cable and PowerPad, follow these steps:


1. Read all of the following directions before attempting to connect PowerPad and its connector cable.
2. Examine the cable. One end of this cable has the shape of your computer's game port receptacle. The other end resembles that of a telephone cord. This end of the cable connects to the PowerPad.
3. Be sure the computer end of the cable is not connected, and that the cable is not carrying an electric current.
4. Find the cable's receptacle at the top of PowerPad.

5. Study the diagram below. Then carefully insert the PowerPad cable.




Part II: Commodore 64 and VIC-20

1. Read all of the following instructions before attempting to connect PowerPad to your computer.
2. Unplug your computer. Be sure that none of the equipment you are using is receiving an electrical current.
3. If you have not already done so, follow the directions for inserting PowerPad's cable into its receptacle on the pad. Then look carefully at the other end of the cable. It fits into your computer's control port.
4. Study the diagram below. Then carefully insert the cable into your computer. If you have a Commodore 64, use Control Port 1. If you have a VIC-20, use the first control port receptacle.




Part III: Atari Computers

1. Read all of the following instructions before attempting to connect PowerPad to your computer.
2. Unplug your computer. Be sure that none of the equipment you are using is receiving an electrical current.
3. If you have not already done so, follow the directions for inserting PowerPad's cable into its receptacle on the pad. Then look carefully at the other end of the cable. It fits into the first controller jack in the front of the computer.
4. Study the diagram below. Then carefully insert PowerPad's cable into your computer.




Part IV: Atari Game Machine (VCS)

1. Read all of the following instructions before attempting to connect PowerPad to your game machine.
2. Unplug your game machine. Be sure that none of the equipment you are using is receiving an electrical current.
3. If you have not already done so, follow the directions for inserting PowerPad's cable into its receptacle on the pad. Then look carefully at the other end of the cable. It fits into the **LEFT CONTROLLER** jack in the back of the game machine.
4. Study the diagram below. Then carefully insert PowerPad's cable into your game machine.




Part V: Apple II, Apple IIe, and Apple II+

1. Read all of the following instructions before attempting to connect PowerPad to your computer.
2. Unplug your computer. Be sure that none of the equipment you are using is receiving an electrical current.
3. If you have not already done so, follow the directions for inserting PowerPad's cable into its receptacle on the pad. Then look carefully at the other end of the cable. It fits into the i/o game receptacle inside your computer.
4. Follow the manufacturer's directions for removing the top of your computer.
5. Study the diagram below. Then carefully insert PowerPad's cable into your i/o game plug.



Part VI: IBM Personal Computer

1. Read all of the following instructions before attempting to connect PowerPad to your computer.
2. Unplug your computer. Be sure that none of the equipment you are using is receiving an electrical current.
3. If you have not already done so, follow the directions for inserting PowerPad's cable into its receptacle on the pad. Then look carefully at the other end of the cable. It fits into the Printer Connector in the back of the computer.
4. Study the diagram below. Then carefully insert PowerPad's cable into the Printer Connector.



Taking Care of your PowerPad

PowerPad is a durable computer device that requires only a few special maintenance procedures. *Temperature* and *humidity* are two areas of concern. Also, the PowerPad *surface* requires some simple care.

Temperature

First, like most computer parts, PowerPad is a little sensitive to extreme temperatures. You do not want to expose PowerPad to temperatures exceeding 50 degrees Celsius (125 degrees Fahrenheit). Radiators, direct sun light, some television sets, and parked cars can reach this limit. At the other extreme, temperatures falling below 0 degrees Celsius (32 degrees Fahrenheit) also can affect the components of PowerPad. If you live in a colder climate, for example, you probably should not leave PowerPad in a parked car.

Humidity

Computer parts ideally should not be exposed to high humidity, which may cause failure of complex electrical elements. Do not leave PowerPad in a humid setting. Like a radio or hairdryer, PowerPad can produce an electric shock if you emerge it in water while it is connected to current. Do not immerse PowerPad or use a liquid on its surface.

PowerPad's Surface

The surface of PowerPad is a tough plastic material, but like all plastics, it can be marred by sharp objects. Within this PowerPad package is a stylus you can use safely on PowerPad with any of the various Chalk Board software units. **Do not use sharp objects on PowerPad.** If you puncture PowerPad's surface, it may not continue to function as it should. You could damage it permanently. If you want to use an instrument other than your finger or the Chalk Board stylus on PowerPad's surface, we suggest you use blunt wooden or plastic objects.

Avoid using water on the PowerPad surface. Instead, a clean damp cloth can help maintain its new appearance. Do not eat or drink over the pad.

Finally, because PowerPad may be your children's first computer "toy," you may need to help them understand the respect that all electronic devices require.

Chalk Board Software

PowerPad is designed to operate with any of the many packages in the Chalk Board software library systems. Each software package comes with three items: a cartridge or diskette, an overlay, and a manual.

The Cartridge

Each Chalk Board software cartridge is designed for use with your specific computer. If you do not know how to insert the cartridge into your computer, consult the user guide which came with your computer. Most systems require you to turn the computer off before you change cartridges.

The Diskette

If your system uses diskettes, follow standard procedures for inserting the diskette into the drive. Consult your computer's user's manual if you have further questions.

The Software Overlay

Each Chalk Board software package includes a framed plastic overlay for the PowerPad surface. The frame has been designed to slip easily into the groove that surrounds the PowerPad working surface.

- Try not to bend the overlay unnecessarily.
- Slip the overlay's frame into the groove at the bottom of PowerPad. Gently drop it onto the surface. Then press lightly on the top of the frame to wedge it into place.
- When you want to change the overlay to play with a different package, you can remove it by using the liftout tabs at the top of the frame.

If the overlay is accidentally damaged or destroyed, you may purchase a replacement by sending a \$6.00 check or money order to:
Customer Support
Chalk Board, Inc.
Suite 140
3772 Pleasantdale Road
Atlanta, Georgia 30340

This \$6.00 charge includes \$3.00 for the cost of the replacement overlay itself, and \$3.00 for mailing and handling.

The Manual

Each Chalk Board software package includes a manual to help you become acquainted with the program's potential. These manuals are written in easy-to-understand language. In each case, they include suggested applications and activities you can use to become familiar with the product and new ways to take advantage of your computer's capabilities.

NOTE: Chalk Board does not control or guarantee the performance of any software package not specifically produced or sanctioned by us. If you purchase software from another vendor and experience incompatibility, inconsistencies, or faulty performance, you should address your problems to the vendor from whom you purchased the software.

Chalk Board PowerPad Technical Specifications

Outside dimensions: 20" x 17" x 1.5"

Active surface area: 12" x 12"

Weight: 4.5 pounds

Resolution: 1/10 x 1/10 (100 points per square inch for most computers.)
Multiple touch, discrete point, digital technique.

Power: 5-12 volts from host. Less than 2 ma.

Operating Temperature and RH:
0 to 50 degrees Celsius
32 to 125 degrees Fahrenheit
Non-condensing environment

Attention Users

In the event that your PowerPad should become defective after the ninety (90) day warranty period, please forward the following items and information to Chalk Board:

- your defective PowerPad.
- a brief explanation of the defect.
- a check or money order made out to Chalk Board, Inc. in the amount of fifty dollars (\$50.00). This amount already includes five dollars for postage and handling.
- your mailing address, including zip code.

Upon receipt of the above, Chalk Board will replace your defective unit with a new one.

Author: Kathy Williams
Engineer: Rod Price
Design: Taylor & Taylor/Atlanta, GA

The first part of the document discusses the importance of maintaining accurate records of all transactions. It emphasizes that every entry, no matter how small, should be recorded to ensure the integrity of the financial statements. This includes not only sales and purchases but also expenses and income. The document further explains that proper record-keeping is essential for identifying trends, managing cash flow, and complying with tax regulations.

In the second section, the author provides a detailed overview of the accounting cycle. This cycle consists of eight steps: identifying the accounting event, recording the event in the journal, posting the journal entry to the ledger, determining the debit and credit balances, preparing a trial balance, adjusting the accounts, preparing financial statements, and closing the books. Each step is explained in detail, with examples provided to illustrate the process.

The third section focuses on the classification of accounts. It distinguishes between assets, liabilities, and equity accounts, as well as revenue and expense accounts. The document explains how these accounts are used to track the financial performance of a business and how they relate to the accounting equation: Assets = Liabilities + Equity.

Finally, the document discusses the importance of internal controls. It outlines various measures that can be implemented to prevent errors and fraud, such as segregation of duties, authorization requirements, and regular reconciliations. The author stresses that strong internal controls are crucial for the reliability of financial information and the overall success of the organization.



A touch of genius.

FCC Statement

WARNING: This equipment has been certified to comply with the limits of a Class B computing device, pursuant to Subpart J of Part 15 of FCC rules. Operation with non-certified computers is likely to result in interference to radio and TV reception.

This equipment generates and uses radio frequency energy and if not installed and used properly, that is, in strict accordance with the manufacturer's instructions, may cause interference to radio and television reception. It has been type tested and found to comply with the limits for a Class B computing device in accordance with the specifications in Subpart J of Part 15 of FCC rules, which are designed to provide reasonable protection against such interference in a residential installation. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient the receiving antenna.
- Relocate the computer with respect to the receiver.
- Move the computer away from the receiver.
- Plug the computer into a different outlet so that the computer and receiver are on different branch circuits.

Some peripheral devices require shielded cabling to prevent radio frequency interference.

Chalk Board supplies a shielded cable for PowerPad. In order to avoid radio frequency interruption be sure to use the Chalk Board cable which accompanied your PowerPad.

If necessary, the user should consult the dealer or an experienced radio/television technician for additional suggestions. The user may find the following booklet prepared by the Federal Communications Commission helpful: "How to Identify and Resolve Radio-TV Interference Problems." This booklet is available from the U.S. Government Printing Office, Washington, D.C. 20402, Stock No. 004-00345-4.

The care and “feeting” of your PowerPad™

Pad Wrinkles

Due to temperature extremes during shipping, our PowerPad may arrive with a slightly wrinkled surface. Removing wrinkles is a simple process following this procedure:

1. Turn PowerPad onto its face, with its handle to your left. You should be able to see several screws.
2. By one turn, loosen the two screws at the top of PowerPad.
3. By one turn, loosen the screw at the right of PowerPad.
4. By one turn, loosen the five screws at the bottom of PowerPad.
5. By one turn, loosen the five screws at the left of PowerPad.

CAUTION: DO NOT REMOVE screws from PowerPad.

6. Turn PowerPad over onto its back, with its handle still to your left. Loosening the screws straightens the wrinkles on PowerPad's surface. However, if any wrinkles remain, smooth them with the flat of your hand, beginning at the left (the handle) side and moving to the right.
7. Turn PowerPad on its face again, so you can see the screws.
8. By one turn, tighten each of the screws.

Pad “Feet”

Your PowerPad comes with four rubber pads (“feet”) which are used to cushion the pad and keep it firmly in place. Follow this procedure to attach the “feet”:

1. Turn PowerPad onto its face.
2. Locate the four “pockets,” one in each corner. These pockets are designed for the feet.
3. Peel the backing paper away from each foot to expose the adhesive.
4. Position each foot with the adhesive side in its pocket.
5. Press each foot firmly into its pocket so that the adhesive grips the PowerPad.

Chalk Board™ Warranty and Registration Card

4. Where did you purchase your Chalk Board product?
- | | |
|--|---|
| <input type="checkbox"/> Department Store | <input type="checkbox"/> Catalogue Showroom |
| <input type="checkbox"/> Discount Store | <input type="checkbox"/> Video/Stereo Store |
| <input type="checkbox"/> Toy Store | <input type="checkbox"/> Computer Store |
| <input type="checkbox"/> Business Equipment Dealer | <input type="checkbox"/> Other _____ |
5. User's age(s) (Please check all that apply):
- | | | |
|-------------------------------------|-------------------------------------|-------------------------------------|
| <input type="checkbox"/> 0-6 yrs. | <input type="checkbox"/> 7-12 yrs. | <input type="checkbox"/> 13-18 yrs. |
| <input type="checkbox"/> 19-30 yrs. | <input type="checkbox"/> 30-50 yrs. | <input type="checkbox"/> Over 50 |
6. Product will be used by:
- | | | |
|----------------------------------|------------------------------------|-------------------------------|
| <input type="checkbox"/> Male(s) | <input type="checkbox"/> Female(s) | <input type="checkbox"/> Both |
|----------------------------------|------------------------------------|-------------------------------|
7. Annual Household Income:
- | | | |
|--|--|--|
| <input type="checkbox"/> \$15,000-30,000 | <input type="checkbox"/> \$30,000-50,000 | <input type="checkbox"/> Over \$50,000 |
|--|--|--|
8. Did you purchase any software when you purchased your PowerPad?
- | | |
|------------------------------|-----------------------------|
| <input type="checkbox"/> yes | <input type="checkbox"/> no |
|------------------------------|-----------------------------|
9. If yes, how many packages?
- | | | | | |
|----------------------------|----------------------------|----------------------------|----------------------------|-------------------------------------|
| <input type="checkbox"/> 1 | <input type="checkbox"/> 2 | <input type="checkbox"/> 3 | <input type="checkbox"/> 4 | <input type="checkbox"/> 5 or more. |
|----------------------------|----------------------------|----------------------------|----------------------------|-------------------------------------|
10. I would like to see more types of the following Chalk Board software:
- | | | |
|---|--|--------------------------------------|
| <input type="checkbox"/> Visual Arts | <input type="checkbox"/> Music | <input type="checkbox"/> Math |
| <input type="checkbox"/> Science | <input type="checkbox"/> Language Arts | <input type="checkbox"/> Games |
| <input type="checkbox"/> Social Studies | <input type="checkbox"/> Sports | <input type="checkbox"/> Other _____ |

11. General Comments: _____

Please detach and send this warranty card in the enclosed envelope.



A touch of genius.

LIMITED WARRANTY

Chalk Board, Inc., warrants this PowerPad™ touch-sensitive pad, connector cable, or software (including overlay, diskette or cassette and manual) against defects in material and workmanship for a period of 90 days from the date of purchase. This warranty is made only to the original consumer purchaser and only if such purchaser completes and returns the attached warranty registration card within 15 days after the date of purchase. Completion and return of the warranty registration card are conditions precedent to the effectiveness of this warranty.

If this product appears to be defective within 30 days after the date of purchase, return it to the retail store where it was purchased with your sales receipt and your retailer will replace your defective product with a new Chalk Board product.

If during the next 60 days the product appears to be defective, send the product, your name and address, a check or money order for \$5.00 to cover mailing and handling, and complete description of the problem to: Customer Support Department, Chalk Board, Inc., 3772 Pleasantdale Rd., Atlanta, Ga. 30340. If Chalk Board, Inc. determines that the product is defective in either materials or workmanship, it will (at its option) repair or replace the product. Under no circumstances will Chalk Board, Inc. be responsible for damage resulting from improper use or installation of this product.

CHALK BOARD, INC., MAKES NO OTHER EXPRESS WARRANTIES AND LIMITS THE DURATION OF ALL IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTY OF MERCHANTABILITY, TO DURATION OF THE ABOVE WARRANTY (90 DAYS AFTER THE PURCHASE DATE). Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. **CHALK BOARD, INC. WILL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT (EXCEPT FOR CONSEQUENTIAL DAMAGES FOR PERSONAL INJURY).**

Some states do not allow the exclusion or limitations of incidental or consequential damages, so the above limitation may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Copyright 1983 by Chalk Board, Inc.

PowerPad is a trademark of Chalk Board, Inc.

Thank you for purchasing a Chalk Board product. To help us serve you better in the future, please take a few moments to complete this warranty registration card.

You must complete and return this card within 15 days after date of purchase to qualify for warranty protection.

Name: _____ Age: _____

Address: _____ City: _____

State: _____ Zip: _____

Country: _____

Telephone: _____

Product(s) Purchased: Chalk Board PowerPad™
 PowerPad™ software

Serial Number: _____

Date of Purchase: _____

Place of Purchase: _____ City: _____

The following questions are for market research purposes ONLY. PLEASE PROVIDE US WITH AS MUCH INFORMATION AS YOU FEEL IS APPROPRIATE.

Questions:

1. Do you or your family currently own a video game or computer?

Video Game Computer Both

2. If yes, what type?

Computer:

Commodore VIC 20 64

Atari 400 600 800 1200

Apple II Ile

IBM PC

Texas Instruments 99/4A

Other _____

Game:

Atari 2600 5200

Intellivision

ColecoVision

Other _____

3. How did you hear about Chalk Board?

From a friend Used in school Newspaper article


Magazine article Newspaper ad (specify) _____

Magazine ad (specify) _____

From my children _____

Other (Please Specify) _____

(continued on other side)



NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES

BUSINESS REPLY MAIL

FIRST CLASS PERMIT NO. 13575 ATLANTA, GA.

POSTAGE WILL BE PAID BY ADDRESSEE

Chalk Board, Inc.
3772 Pleasantdale Road
Atlanta, Georgia 30340





PowerPad

Introducing the
most powerful
learning tool
available today.
A simple, powerful
learning tool.



Includes cable for Commodore 64, VIC-20 and Atari computers. Requires a home computer system and PowerPad software.

PowerPad

