

BackButton™

BackButton™ Lid Replacement Instructions



1. Lift off old lid from BackButton™. If the circuit board underneath lifts, push it back down.



2. Apply key cap on the blue switch. Wiggle and push until it sets.



3. Push the LEDs down or to the side slightly so that they aren't touching the key cap.




4. Pour a small amount of 100% acetone into an unpainted glass or ceramic dish.



5. Dip a wooden stick into the acetone, and apply a few drops to the top of the key cap until there is a thin layer on top (but don't let it overflow).



6. Center the lid on the button so that the antennae in the logo line up with the flat side of the button.



7. Turn the button upside-down and apply a paperweight on top for at least 30 minutes. *After it sets, lift the LEDs using tweezers to their previous position.*

