

(If you have a printer not listed on the Setup Menu)

This sheet is designed to help you make the optimal selections on the Fleet System 2 Printer Setup Menu for your printer. Please be sure to work through the Introduction section of the Fleet System 2 manual and then please refer to this sheet when you get to the section on printer set up.

Although we list about 25 printers on the Setup Menu, Fleet System 2 will actually work with almost any printer available, as many printers use the same "codes" as other printers. Below is a list of several printers which do not appear on the printer Setup Menu that will help you determine the best printer selection for your printer.

<u>If You Own</u>	<u>Please Select</u>	<u>Device #</u>	<u>Secondary Address</u>	<u>Line Feed</u>	<u>User Port</u>
Star SG/SD/SR	Gemini	4	5	n	n
Star Powertype	Gemini	4	5	n	n
Homewriter	CBM-1526	4	0	n	n
Epson LX-80	RX-80	4	5	n	n
MPS-802	CBM-1526	4	0	n	n
MPS-803	CBM-1525	4	0	n	n
DPS-1101	Diablo	4	0	n	n
Panasonic (all)	RX-80	4	5	n	n
Okidata 182-193	Okidata	4	5	n	n
Okimate 10	CBM-1525	4	5	n	n
Olympia Compact2	Diablo	4	5	n	n
Olympia RO	Diablo	4	5	n	n
Blue Chip Matrix	RX-80	4	5	n	n
Blue Chip IQ	Diablo	4	5	n	n
Axiom Elite 5	ASCII	4	5	n	n
Tally Spirit 80	RX-80	4	5	n	n
Brother HR-15/25	Diablo	4	5	n	n
Brothers HR-1	Brother	4	5	n	n
Comrex CR-1	Comriter	4	5	n	n
Comrex CR-2	Diablo	4	5	n	n
Citizen	RX-80	4	5	n	n
Daisy 2000	Diablo	4	5	n	n
Juki 6000/6100	Diablo	4	5	n	n
Silver Reed	Diablo	4	5	n	n
All Others	ASCII	4	5	n	n

\* On the DPS-1101 make sure switch 1 and 3 on bank one is ON.

If when printing, you find that you are getting double spacing or no spacing at all, go back to the Setup Menu and change the setting for Linefeed.

### INTERFACES

Any interface that you use with Fleet System 2 must be in the TRANSPARENT MODE. On the CARDCO interface, this can only be done by typing in the following before you load Fleet System 2:

**OPEN#4,25:PRINT#4** and then press <RETURN>

With any other interface, TRANSPARENT MODE is usually accessed by setting the switches on the interface box a certain way. Refer to your interface manual or contact the interface manufacturer.

For further information on printer setup, please contact your dealer or printer manufacturer.