



## Cartridge for Commodore

### Quick Reference Guide

Works on any Commodore 64/SX64/128  
(and VIC 20/VC20 with BackBit adapter)

Navigation:

**F1/ESC - UTILitiesS (global)**

**F3 - PROPRietieS**

**F5 - SAVES/versions**

**F7 - TOOLS (for selection)**

↑ ← **CRSR**  
**HOME DEL**

Type name to search, **RETURN** to run  
**CTRL-RETURN** to open without starting  
**RUN-STOP** goes to BASIC  
**DEL** goes to parent directory

**F1**→**Presentation Mode** disables menus

**F1**→**Rip From Disk** from real 1541

**F7**→**Burn to Disk** to real 1541

**F7**→**Autostart On Boot** a single title

File Formats Supported: PRG, P00, T64, BIN,  
CRT, D64, D71, D81, KLA, SID, BBT

**Get support @**

**<http://forum.backbit.io>**

## To Upgrade Firmware:

Plug in the USB cable to your PC.

Download loader & firmware.

<https://www.pjrc.com/teensy/loader.html>

<http://backbit.io/downloads/Firmware>

## About Saves/Versions:

Original is never altered. Modified files stored  
in hidden **.saves** folder and can be exported.

BBT files store versions internally.

## Troubleshooting:

If you see blue border, you are in presentation  
mode. Hold the cartridge button while booting  
the computer to go to the file browser.

## Optional Accessories:

BackButton™ wired remote

TwoBit™ joystick doubler

VIC20/VC20 adapter

GenAssister™ joystick adapter

**(available at store.backbit.io)**

3D printed case made with ABS.

Assembled by hand in USA.