

# GeoCable Interface

The geoCable interface works with Geos printer drivers configured for geoCable, The Write Stuff with a \* [patch](#), Craig Bruce's ACE 16 operating system, and some other programs. The advantage, beside a possible increase in sending data to the printer, is it's cost and ease of use. There are no chips to die and no DIP switches to fiddle with.

The interface is simply a cable between the printer and the User Port.

\* - The file twsgc.bin is a self-extracting SFX file.

Pin on 64	Pin on Centronics
a ground	33 ground
b flag 2	11 busy
c PB0	2 data 1
d PB1	3 data 2
e PB2	4 data 3
f PB3	5 data 4
h PB4	6 data 5
j PB5	7 data 6
k PB6	8 data 7
l PB7	9 data 8
m PA2	1 strobe
n ground	16 ground

Superscript uses the same cable, but has the following change:

b flag 2	10 Acknowledge
----------	----------------

Either wiring will work for either program, but the geoCable wiring is preferred.