

Link-232 High Speed RS-232 Serial Interface

The Link-232 Interface, designed by Jim Brain, provides a high-speed serial port for Commodore 8-bit computers. It can operate at speeds of up to 38400bps, and is compatible with all software that can utilize a Dr. Evil Labs or CMD Swiftlink cartridge.

This is my second batch of interfaces, and I've decided to have solder mask applied to the boards. This makes soldering them easier, and they look a bit more professional. Because I doubled the size of the run this time, I was able to keep the prices the same as the last batch.

I'll first explain the jumpers on this board for those of you who purchased one already assembled.

Jumper JP1 on the board is used to change the I/O address from \$DE00 to \$DF00. Short pins 1-2 for \$DF00, and pins 2-3 for \$DE00.



Jumper JP2 changes the ACIA interrupt between NMI and IRQ. Use NMI mode with all Commodore computers in native mode, and IRQ for the C128 in CP/M mode. Shorts pins 1-2 for IRQ, and pins 2-3 for NMI.

As with all electronics, handle these interfaces with care. The 6551 UART chip is probably the most sensitive to static discharge. They are best handled by the edges of the board to reduce the chance of zapping one of the chips with static electricity.

That's about it for using the device, now onto some tips on assembling it yourself!

I'm going to assume you have the proper equipment, and have already honed your soldering skills on other stuff before you've decided to build this. Normally, when I put these together, I start with the sockets. They're all the same height, and you can let the board sit on them while soldering. Next, I solder on the DB9 connector, as a couple of the 1uF capacitors obscure pins 1 and 5 on the DB9. Then, I tackle the discrete components. You'll notice the solder pads for the capacitors, resistors and crystal are quite small. The application of solder mask makes soldering these components much easier now, and you can heat the pad and the lead at the same time. The resistors should all be installed standing straight up. The larger pads for the sockets and jumpers are much easier, and you can heat the pad and the lead at the same time while applying the solder.

Before plugging the interface into the computer, you should do a quick check with a multimeter between pins 1 and 2/3 on the edge connector. Make sure there's not a dead short between those two pins. If there is, check for solder jumping over the void between the solder pad and the ground plane on the board. I have found this can happen quite easily, so it's best to check the board before you apply power to it with your Commodore.



High Speed RS232 Interface

Designer: Jim Brain

TITLE: Link232

Document Number:

REV:

Date: 1/31/2007 10:25:04p

Sheet: 1/1