
for the Serious Computerist





Basic DVORAK Keyboard Applesoft Compression Better BASIC Hex Loader HiRes Graphic Printouts 6809/68000 Comparison Flight Simulator II

It all adds up



HOME COMPUTERS

		•
in the same of the	E. sed	
2	7 C 2 C 2 C 2 C 2 C 2 C 2 C 2 C 2 C 2 C	
A STATE OF THE STA		
200333683		

900XT	***********	\$149
800XL	•••••	\$229
WHITE SIL	PPT.V T. A	QTQ

850 Interface	\$ 150.00	1
1010 Recorder		. 1
1020 Color Printer		CZ
1025 Dot Matrix Printer	\$299.00	62
1027 Letter Quality Printer	\$269.00	40
1030 Direct Connect Modem	.\$99.99	40
1050 Disk Drive	\$349.00	40
1064 Memory Module	\$125.00	80
Touch Tablet/Software	\$64.99	80
Light Pen/Software	\$72.99	80
CX22 Track Ball	\$39.99	80
7097 Atari Logo	\$74.98	80
4018 Pilot (Home)	\$57.99	80
405 Pilot (Educ.)		80
8036 Atari Pilot		80
5049 VisiCale	\$149.99	40
488 Communicator II	\$119.99	81

1200XL	ALL
1450XL	ALL
CX30 Paddles	.\$11.99
CX40 Joystick	\$7.99
4011 Star Raiders	\$31.99
4022 Pac Man	.\$31.99
4025 Defender	\$31.99
8026 Dig Dug	\$31.99
8031 Donkey Kong	\$35.99
8034 Pole Position	\$37.99
8040 Donkey Kong Jr	\$33.99
8043 Ms Pacman	\$37.99
9044 Toyet	\$37 OO
8045 Pango	\$33.99
8052 Moon Patrol	\$33.99
4003 Assembler	
8126 Microsoft Basic I or II	\$64.99

DISK DRIVES FOR ATARI

PERCOM			AAAA	
AT 88-S1	.\$279.00	1000		.\$299.00
AT 88-S1 PD	\$299.00	NORTH TO CAPITAL	TRAK	
Twous		ATD2		
GT Drive	\$379.00	AT-D4	************	\$589,00
		完全實際影響遊出時 。		
	STREET, NO. 4-CHRACKSCO.	20 10 10 1 2 2 2		

	M	SMORY	BO.	RDS	
	ATARI			APPLE/FRAN	KLIN
Axlon	32K	\$59.99	Axlon	128K	\$299.00
Axlon	48K	\$99.99	Axlon	320K	\$849.00
Axlon	128K	.\$299.00			

ALIEN VOICE BOX	\$1	49.00
DISKETTES		

MAXELI	•	ELEPH.	ANT
5 1/4" MD-1	\$24.99	5 1/4" SS/SD	\$18.49
5 1/4" MD-2	\$34.99	5 1/4" SS/DD	\$21.99
8" FD-1	\$39.99	5 1/4" DS/DD	\$26.99
8" FD-2	\$49.99	DISK HO	LDERS
VERBATI		INNOVATIVE	CONCEPTS
SVA BSCOT Varue	Life \$22.99	Fito-n-File 10	\$3 99
54 DSDD Value	Life \$29.99	Flip-n-File 50	\$17.99
		Flip-n-File 50 w/loci	
514" Disk Head Cleane			
methodecreened to betalish with a tilling of the betalished of the set only	SCHOOL IS ABSTOLD A LANGE OF STREET	$\kappa(anthin \Phi) = tanthin terms A_{B, i} (\Phi) argues in a surface in i.$	distantial ministration

CONTROLLERS & JOYSTICKS

	** 100		44.44	
Joystick		\$21.99	Joystick	\$41.99
3-way Joysto	and the second s	\$22.99	Atari Single Fire	\$12.99
Power Grip.		\$21.99	Atart Switch Hitter	\$15.99
			Apple Paddles	
			IBM Paddles	
Apple Trak I	lall	\$54.99	IBM Joystick	\$46.99
Apple Analog	Section 2004 Colors of Colors Section 1	\$37.99	関連を表現を表するとも表でいた。	Seasonal Mary 2 - 3 - 5
		• •		

Кo	ala						
79.99	IBM						

Atari (ROM)\$79.99	1BM\$99.99
C-64 (ROM)\$79.99	Apple/Franklin\$85.99

AXIOM	PRINTERS
-------	----------

AT-100 Atari Interface Printer\$239.00	MANNESMAN TALLY
GP-100 Parallel Interface\$199.00	160L\$589.00
GP-550 Atari Bidirectional\$319.00	180L\$799.00
GP-700 Atari Color Printer\$489.00	Spirit 80 \$309.00
GP-550 Parallel Printer\$269.00	NEC
BMC	8023 Dot Matrix\$389.00
401 Letter Quality\$589.00	8025 Dot Matrix \$669.00
BX-80 Dot Matrix \$269.00	2010/15/30\$749.00
C.ITOH	3510/15/30\$1369.00
	7710/15/30\$1799.00
Gorilla Banana\$209.00	OKIDATA
Prowriter 8510P\$379.00	82, 83, 84, 92, 93, 2350, 2410CALL
Prowriter 1550F\$599.00	OLYMPIA
A10 (18 cps)\$569.00	Compact 2\$479.00
Hot Dot MatrixCALL	Compact RO\$509.00
F10-40\$999.00	ESW 3000\$1449.00
F10-55\$1349.00	SMITH CORONA
COMREX	TP-1000\$449.00
ComWriter II Letter Quality\$499.00	Tractor Feed\$119.00
DIABLO	SILVER REED
620 Letter Quality\$949.00	500 Letter Quality\$449.00
630 Letter Quality\$1749.00	550 Letter Quality\$549.00
	550 Letter Quality\$549.00 770 Letter Quality\$899.00
630 Letter Quality\$1749.00	550 Letter Quality
630 Letter Quality\$1749.00 DAISYWRITER	550 Letter Quality
630 Letter Quality\$1749.00 DAISYWRITER 2000\$999.00	550 Letter Quality \$549.00 770 Letter Quality \$899.00 STAN Gemini 10X \$299.00 Gemini 15X \$399.00
630 Letter Quality	560 Letter Quality \$549.00 770 Letter Quality \$899.00 STAR Gemini 10X \$299.00 Gemini 15X \$399.00 Serial Board \$75.00
630 Letter Quality \$1749.00 DAISYWRITER 2000 \$999.00 Tractor Feed \$109.00 EPSON	560 Letter Quality \$549.00 770 Letter Quality \$899.00 STAR Gemini 10X \$299.00 Gemini 15X \$399.00 Serial Board \$75.00 Radix 10 \$599.00
630 Letter Quality \$1749.00 DAISYWRITER 2000 \$999.00 Tractor Feed \$109.00 EPSON RX-80, RX-80FT, RX-100	560 Letter Quality \$549.00 770 Letter Quality \$899.00 STAR Gemini 10X \$299.00 Gemini 15X \$399.00 Serial Board \$75.00 Radix 10 \$599.00 Radix 15 \$699.00
630 Letter Quality \$1749.00 DAISYWRITER 2000 \$999.00 Tractor Feed \$109.00 EFSON RX-80, RX-80FT, RX-100 CALL FX-80, FX-100 CALL	550 Letter Quality. \$549.00 770 Letter Quality. \$899.00 STAR Gemini 10X. \$299.00 Gemini 15X. \$399.00 Serial Board. \$75.00 Radix 10. \$599.00 Radix 15. \$699.00
630 Letter Quality \$1749.00 DAISYWRITER 2000 \$999.00 Tractor Feed \$109.00 EPSON RX-80. RX-80FT. RX-100. CALL FX-80. FX-100. CALL LQ 1500. CALL	560 Letter Quality \$849.00 770 Letter Quality \$899.00 STAR Gemini 10X \$299.00 Gemini 15X \$399.00 Serial Board \$75.00 Radix 10 \$599.00 Radix 15 \$699.00 TOSHIBA 1340 \$869.00
630 Letter Quality \$1749.00 DAISYWRITER 2000 \$999.00 Tractor Feed \$109.00 EPSON RX-80, RX-80FT, RX-100 CALL FX-80, FX-100 CALL LQ 1500 CALL IDS	560 Letter Quality \$49.00 770 Letter Quality \$899.00 STAR Gemini 10X \$299.00 Gemini 15X \$399.00 Serial Board \$75.00 Radix 10 \$599.00 Radix 15 \$699.00 TOSHIBA 1340 \$869.00 1351 \$1699.00
630 Letter Quality \$1749.00 DAISYWRITER 2000 \$999.00 Tractor Feed \$109.00 EPSON RX-80, RX-80FT, RX-100. CALL FX-80, FX-100. CALL LQ 1500. CALL LQ 1500. CALL Prism 80For Configuration. CALL Prism 32For Configuration. CALL JUEI	550 Letter Quality. \$549.00 770 Letter Quality. \$899.00 STAR Gemini 10X. \$299.00 Gemini 15X. \$399.00 Serial Board. \$75.00 Radix 10. \$599.00 Radix 15. \$699.00 TOSHIBA 1340. \$869.00 1351. \$1699.00
630 Letter Quality \$1749.00 DAISYWRITER 2000 \$999.00 Tractor Feed \$109.00 EPSON RX-80. RX-80FT. RX-100. CALL FX-80. FX-100. CALL LQ 1500. CALL LQ 1500. CALL LD 1500. CALL LD 1500. CALL LD 1500. CALL Prism 80. For Configuration. CALL Prism 32. For Configuration. CALL	560 Letter Quality \$849.00 770 Letter Quality \$899.00 STAR Gemini 10X \$299.00 Gemini 15X \$399.00 Serial Board \$75.00 Radix 10 \$599.00 Radix 15 \$699.00 TOSHIBA 1340 \$869.00 1351 \$1699.00 TRANSTAR 120P \$469.00
630 Letter Quality \$1749.00 DAISYWRITER 2000 \$999.00 Tractor Feed \$109.00 EPSON RX-80, RX-80FT, RX-100. CALL FX-80, FX-100. CALL LQ 1500. CALL LQ 1500. CALL Prism 80For Configuration. CALL Prism 32For Configuration. CALL JUEI	560 Letter Quality \$49.00 770 Letter Quality \$899.00 STAR Gemini 10X \$299.00 Gemini 15X \$399.00 Serial Board \$75.00 Radix 10 \$599.00 Radix 15 \$699.00 TOSHIBA 1340 \$869.00 1351 \$1699.00 TRANSTAR 120P \$469.00 130P \$449.00
630 Letter Quality \$1749.00 DAISYWRITER 2000 \$999.00 Tractor Feed \$109.00 EPSON RX-80, RX-80FT, RX-100. CALL FX-80, FX-100. CALL LQ 1500. CALL LQ 1500. CALL Prism 80For Configuration. CALL Prism 32For Configuration. CALL JUEI	560 Letter Quality \$849.00 770 Letter Quality \$899.00 STAR Gemini 10X \$299.00 Gemini 15X \$399.00 Serial Board \$75.00 Radix 10 \$599.00 Radix 15 \$699.00 TOSHIBA 1340 \$869.00 1351 \$1699.00 TRANSTAR 120P \$469.00

21022220				
ANCHOR	NOVATION			
Volksmodem\$59.99	J-Cat\$99.99			
Mark IL Serial	Cat\$139.00			
Mark VII (Auto Ans/Auto Dial)\$99.99	Smart Cat 103			
Mark XII (1200 Baud)\$299.99	Smart Cat 103/212\$399.00			
Mark TRS-80\$99.99	AutoCat\$219.00			
9 Volt Power Supply\$9.99	212 AutoCat\$549.00			
HAYES	Apple Cat II\$249 00			
Smartmodem 300\$209.00	212 Apple Cat\$449.00			
Smartmodem 1200\$499.00	Apple Cat 212 Upgrade\$259.00			
Smartmodem 1200B\$449.00	PC Cat Access 1 2 3 \$399.00			
Micromodem IIe\$269.00	ZENITH			
Micromodem 100\$299.00	ZT-1\$339.00			
Smart Com II\$89.99	ZT-10\$309.00			
Chronograph \$199.00	ZT-11\$369.00			

MONIT

300 Green	.\$149.00
300 Amber	
310 Amber	
Color 1	
Color 1 Plus	
Color 2 Plus	
Color 3	
Color 4T IBM	\$699.00
BMC	
1201 (12" Green)	\$88.99
1201 Plus (12" Green Hi-Res).	\$98.99
9191 Plus	
GORILLA	
	•00 00
12" Green	
12" Amber	\$95.99
NEC NEC	
JB 1260 Green	
JB 1201 Green	
JB 1205 Amber	.\$159.99
JB 1215 Color	\$259.00
JC 1216 RGB	\$429.00
JC 1460 Color	\$359.00
PRINCETON GRAPHIC	8
MAX-12 Amber	\$199.00
HX-12 RGB	\$539.00

ORS	
SAKATA	
SC-100 Color	\$269.00
SG-1000 Green	\$129.00
SA-1000 Amber	\$139.00
TAXAN	
210 Color RGB	\$299.00
400 Med-Res RGB	\$319.00
415 Hi-Res RGB	
420 Hi-Res RGB (IBM)	
100 12" Green	
105 12" Amber	
USI	•
Pi 1, 9" Green	\$99.99
Pi 2, 12" Green	
Pi 3, 12" Amber	
Pi 4, 9" Amber	\$119.99
1400 Color	
QUADRAM	14. pt
Quadchrome 8400 Color	\$519.00
ZENITH	
ZVM122 Amber	\$ 00 00
ZVM123 Green	
ZVM124 IBM-Amber	
71/1/171 Color	

800-648-3311

In NV call (702)588-5654, Dept. 125 Order Status Number: 588-5654 P.O.Box 6689 Stateline, NV 89449

canada Ontario/Quebec 800-268-3974 Other Provinces800-268-4559

SRT-2 RGB

In Toronto call (416)828-0866, Dept. 125 Order Status Number: 828-0866 2505 Dunwin Drive, Unit 3B Mississauga, Ontario, Canada L5L1T1

\$649.00

800-233-8950

ZVM131 Color.

ZVM135 RGB/Composite.

ZVM133 RGB

In PA call (717)327-9575, Dept. 125 Order Status Number: 327-9576 Customer Service Number: 327-1450 477 E. 3rd St., Williamsport, PA 17701



\$309.00 \$429.00

\$469.00

tod for certified checks or money orders. Add 3% (minimum \$5) shipping and handling on all orders. Larger shipments may require additional charges. NV and PA residents add sales tax. All items subject to availability and price change. Call today for our catalog.

the best prices

DISK DRIVES

MICKO-BCI			
00			
00			
QC			
99			
99			
00			
00			

..\$569.00 APPLE IIe STARTER PACK 64K Apple IIe, Disk Drive & Controller, 80 Column Card, Monitor II & DOS 3.3 A COMPLETE......CALL
Call on all other Apple Models



CE	1000	Color	Compu	ter	.CALL
ACE	PRO	PLUS	System		CALL
CE	1200	Office	Mgmt.	System	CALL
CE	POR!	TABLE	S		CATIL

MBC	855	CALL CALL
		\$1499.00 \$1899.00





hp)	HEWL	ETT	PACK	(ARD
	1000	MEN'S HOLD		
				, .
			dema	
				ŀ
HP	71B		\$41	9.99

HP 71B	\$419.99
41CV	\$189.99
41CX	\$249.99

.\$62.99
\$92.99
.\$92.99
.\$92.99
\$879.99
\$98.99
\$359.99
\$ 143.99
\$63.99
\$63.99



PC-180	O.A	5 165.	99
PC-125	0.A	\$88.	99
CE-125 I	Printer/Cassett	e \$ 128	.99
	Color PrinterC		
	K RAM		
CE-161 1	6K RAM	\$134	.99
	, ,	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	



(commodo	re
CBM 8032	\$599
CBM 8096	\$869.00
CBM 9000	
B128-80	\$769.00
8032 to 9000 Upgrade	
2031 LP Disk Drive	\$299.00
8050 Disk Drive	\$949.00
8250 Disk Drive 4023 Printer 8023 Printer	\$1199.00
4023 Printer	\$379.00
8023 Printer	\$569.00
6400 Printer	1399.00
Z-RAM	
Silicon Office	
The Manager	
SoftROM VisiCalc	\$125.00
VisiCalc	\$159.00
PROFESSIONAL SOFTW	ARE .
Word Pro 2 Plus. Word Pro 3 Plus	\$159.00
Word Pro 3 Plus	\$189.00
Word Pro 4 Plus/5 Pluseach.	
InfoPro	
Administrator	\$399.00





8X-64Portable	E SA
CBM 64	
C1541 Disk Drive	.\$249.00
C1530 Datasette	
C1520 Color Printer/Plotter	\$129.00
M-801 Dot Matrix Printer	\$219.00
C1526 Dot Matrix/Serial	\$299.00
C1702 Color Monitor	\$259.00
Cl311 Joystick	\$4.99
C1312 Paddles C1600 VIC Modem	\$11.99
C1600 VIC Modem	\$59.99
C1650 Auto Mdoem	
Logo 64	
Pilot 64.	
Word Pro 64 Plus	
Calc Result 64	
Calc Result Easy	
Codewriter 64	\$78.99
MCS 801 Color Printer	
DPS HOL Daisy Printer	
Magic Voice Speech Module	
Desk Organizer Lock	
Vidtex Telecommunications	
MSD	
SDl Disk Drive	

SD2 Disk Drive.

NEC	2050	\$899.00
NEC	3550	\$1669.00
	PERCOM	TANDON

		1	DISK	DRIV	ES.		
5 1/4	" 32	OK	Flopp	y		.\$219.	00
5 I	Meg I	Hard	w/Co	ntroll	er	\$ 10 4 9.	00
10	Meg	Har	d w/C	Contro	ller	1349.	00
20	Meg	Har	d w/C	Contro	ller	1899.	00

VISICORP VisiCalc IV.....\$159.00 VisiWord +\$249.00 Visi-on Application Manager...\$79.99 Visi-on Calc.....\$269.00 Visi-on Graph..... Visi-on Word..... Optical Mouse ... \$189.99

AST	RESEARCH
Six Pak Plus	from\$279.00
Combo Plus II.	from\$279.00
Mega Plus	from\$309.00
LO Plus	from\$139.00
T Q T	JADRAM
Quadlink	\$479.00
Oundhound	as low as \$280.00

MARUAUY .	
Quadlink	\$479.00
Quadboardas low as	
Quad 512 Plusas low as	\$249.00
Quadcoloras low as	\$219.00
Chronograph	.\$89.99
Parallel Interface Board	.\$89.99
64K RAM Chips Kit	\$59.99

WandSton Doofs-size at Deal-	* 7700 00
WordStar Professional Pack	
InfoStar	.\$299.00
SpellStar	. \$159.00
CalcStar	
MICROSTUF	
Crosstalk	\$105.00
MICROSOFT	
MultiPlan	\$159.00
ASRTOW-TATE	
dbase II	.\$339.00
dBASE III	\$449.00
Friday!	
IUS	
EasyWriter II	.\$249.00
EasySpeller	
Easy Filer	
CONTINUENTAL SOFTW	ARE
1st Class Mail/Form Letter	\$79.99
Home Accountant Plus	\$88.99
LOTUS	
Symphony	\$549.00
1-2-3	\$339.00
PROFESSIONAL SOFTW	ARE
PC Plus/The Boss	.\$329.00
SYNAPSE	



File Manager

PC COMPATIBLE 16 BIT

Z-150 PC

Z-160 PC

Call for price and configurations

SOFTWARE

. On an energy and data space		Atari	IBM .	Apple
Electronic Arts				5.25 (0.145)
One on tine	\$29.99	\$29.99	\$29.99	\$29,99
Music Construction	\$29.99	\$29.99	\$29,99	\$29.99
Pinball Construction	\$29.99	\$29.99	\$29.99	. \$29.99
Cut & Paste	\$39.99	\$39.99	\$39.99	\$39.99
Hard Hat Mack	\$27 99	\$27.99	\$27.99	\$27 99
InfoCom				
Witness	\$29.99	\$29.99	\$ 29 99	\$29 99
Infidel	\$29.99	\$29 99	\$29.99	\$29 99
Deadline	\$29.99	\$29 99	\$29.99	\$29.99
Planetfall	\$29.99	\$29.98	\$29.99	\$29,99
Enchanter Zorkl 2 3 es	\$29.99 \$27.99	\$29.99 \$27.99	\$29.99 \$27.99	\$29:09 \$27:99
Suspended	\$29.99	\$29.99	\$29.99	\$29.99
Borcer er	\$29.90	\$29.99	\$29.99	\$29.99
AtariSoft	100 100 100			
Joust	學的學術學的學術	N/A	\$ 28 99	
Moon Patroi	\$35.99 \$35.99	N/A N/A	\$28.99 \$28.99	\$28.99 \$28.99
Ms. PacMan	\$35.99	N/A	\$28.99	\$28 99
PacMan	\$35.99	N/A	\$28.99	\$28.99
Donkey Kong	\$35.99	N/A	\$28.99	\$28.99
Pole Position	\$35.99	N/A	\$28.99	\$28.99
Splunaker	ann de Manufelliota Italia de calenda	E TENNÉN I WELLEN DE THE STÉANNE SE	consciutivité désignations	turneriscus ad kilomi ranno
Aerobics	\$28.99	\$28.99	\$28.99	\$28.89
Trans	\$24.99	\$24.89	\$24.99	\$24.99
Adventure Creature	\$24.99	\$24.99	\$24.90	824.99
Angean Voyage	\$24.99	\$24.99	\$24.99	\$24,99
Snooper Proops 1,2 ea	\$28.99	\$28.99	\$28.99	\$28.99
Traction Fever	\$22.99	\$22.99	\$22 99	\$22.99
Alphabet Zoo	\$22 99	\$22.99	\$22.99	\$22.99
In Search of	\$24.99	\$24.99	\$24.99	\$24.99
Facemaker	\$22.99	\$22.99	\$22.99	\$22.99
Kinder Comp	\$17 99	\$17.99	\$ 17 99	\$17 99
Dynatech	contract and a discovery state of the contract	- Address of and a print Constraints	L-802senesci-648ensefelici	deplitt frankada erabilitation de armanere
Code Writer	\$78.99	\$79.99	\$175.99	\$155.99
VisiCorp	CHARLES AND	4078,400	0.00	
VisiCale	6159.99	\$149.99	\$159.99	\$159.99
VisiCale Advanced	N/A	M/A	NA	\$269.98
pfs:				
Write	N/A	N/A	\$89.99	\$89.99
Graph	N/A	N/A	\$89 99	\$79.99
Report	N/A	N/A	\$79.99	\$79.99
File	N/A	N/A	\$89.99	\$79.99
Solutions: * as low as	N/A	N/A	\$ 16 99	\$ 16 99

west VISA'

800-648-3311 In NV call (702)588-5654, Dept. 125 Order Status Number: 588-5654 P.O.Box 6689

Stateline, NV 89449

canada Ontario/Quebec 800-268-3974 Other Provinces800-268-4559

.\$599.00


In Toronto call (416)828-0866, Dept. 125

Order Status Number: 828-0866 2505 Dunwin Drive, Unit 3B

east

800-233-8950

In PA call (717)327-9575, Dept. 125 Order Status Number: 327-9576 Customer Service Number: 327-1450 477 E. 3rd St., Williamsport, PA 17701







This Month in Micro

This month we have 10 complete, useful, exciting programs for you on a diverse group of topics. The longer ones are available on MicroDisk as well to save you time and effort.

Featured This Month

DVORAK Keyboard — Try out a new keyboard arrangement that can increase your typing speed dramatically. The keyboard now commonly used on computers was deliberately designed to avoid jamming slow typewriter keyboards. Technology eliminated the problem, but the awkward solution is still with us. However, a different layout is becoming more widely accepted, which results in productivity and typing speed skyrocketing. This demo program will allow you to convert your keyboard temporarily and see if you like the arrangement.

6809 vs. 68000 — While the 68000 based computer is far more expensive than the 6809, it can be 100 times more powerful, but, what are the real differences. A checkbook offers a good way to compare their abilities. This program contains the main subroutines to create a machine language program which runs on either kind of machine to allow comparison.

Flight Simulator II — Studying an accepted masterpiece of program design is one way to learn really fine programming skills. Flight Simulator II is just such an exciting state-of-the-art package. Looking into its details and the way it was created will give even experienced programmers more than a few pointers.

C-64 Graphics Dump — This "perfect" dump for the impressive C64 graphics works in either HiRes or multi-color mode, allows large size printouts, works with many printers and graphics packages, can vary color and intensity, and is very fast. This program is available on a MicroDisk.

Communication Between Computers — What do you do when you have several different computers and only one printer? Interface and merge it all into one efficient system.

HILISTER — Highlighting lines of text and programs can be very useful for emphasis or clarity when discussing material on the screen in business meetings, classrooms, seminars. This program also allows easy movement within a program or text.

Simple Numeric Sorting — This simple method lets long lists be arranged in order, without user supplied programs. It takes advantage of a built-in BASIC feature.

Applesoft Compression Program — With other programs, extra long listings often do not work, overflowing the Called Line Number Table. This program has several unusual features which surpass other Compression routines.

Useful Math Functions — Save time and mathematical aggrevation with a compilation of defined functions.

Commodore to Apple — Sort of a poor man's modem. Commodore cassette files can be sent to Apple disks for storage or interfacing with peripherals which don't work with Commodore. This works with data files, BASIC programs and memory ranges.

Circles for the C64 — In a HiRes environment, creating circles can be a problem. The code for this mathematical way of defining and plotting circles in a game or business type analysis is most helpful. The theory will generally work on any 6502 based computer with HiRes capabilities.

BASIC Hex Loader — This handy BASIC Utility will load Machine Language code in Hex, and a special version for the C64 will even generate the DATA statements.



of the Transactor. Very impressive.

new

CHECK THESE • Up-to-date: new and services. JIM BUTTERFIELD talk • Insights and stra æ cource.

respected experi Jim Butterfield. jo shi

• Interesting bits o user

among Commod ou'l anag

Subscribe now a wonder how you SIMPLY THE BEST without it.

S DEPT 9T 3P7 THE TRANSACTOR SUBSC

Telephone: 876-4741

Year's subscription (6.)

Bedt issues available.

Publisher/Editor-In-Chief Robert M. Tripp

> Associate Publisher Cindy Kocher

> Production Manager Jennifer Collins

> > Technical Editor Mark S. Morano

> > Technical Editor Mike Rowe

Advertising Manager William G. York

Dealer Sales Manager Linda Hensdill

Circulation Manager Linda Hensdill

> Office Manager Pauline Glard

Shipping Director Marie Ann LeClair

Comptroller Donna M. Tripp

> Accounting Louise Ryan

Loren Wright

Contributing Editors
Cornelis Bongers
Phil Daley
David Malmberg
John Steiner
Jim Strasma
Paul Swanson
Richard C. Vile, Jr.

MICRO is published monthly by: MICRO, Chelmsford, MA 01824. Second Class postage paid at: Chelmsford, MA 01824 and additional

mailing offices. USPS Publication Number: 483470.

ISSN: 0271-9002.

Send subscriptions, change of address, USPS Form 3579, requests for back issues and all othe fulfillment questions to: MICRO

P.O. Box 6502
Chelmsford, MA 01824
or call 617/256-3649.
Subscription Rates: (per year):
U.S. \$24.00 or \$42.00 for two years
Foreign surface mail: \$27.00
Air mail: Europe \$42.00
Mexico, Central America, Middle East,
North Africa, Central Africa \$48.00
South America, South Africa, Far East,
Australia, New Zealand \$72.00

Copyright © 1984 by MICRO.
All Rights Reserved.

MCRO 1

for the Serious Computerist

JULY 1984

13 A Basic DVORAK Keyboard for the VIC-20 and C-64

Alfred J. Bruey

A "new" key arrangement is gaining acceptance, increasing typing speed and productivity enormously.

15 A Comparison of 6809 and 68000

Mike Rosing

The checkbook offers a simple, effective way to compare these two microprocessors.

19 Flight Simulator II:
Microcomputer
Simulation At Its Best

Chris Williams

By analyzing this design masterpiece, programmers may discover the elements needed to make their own software great.

22 Graphic Print for C-64

Michael J. Keryan

Create a full-page graphic printout from a Commodore 64 high resolution display.

30 Interface Clinic:
Communication
Between Different
Computers

Ralph Tenny

Merge several computers into one efficient system, sharing a single printer.

34 HILISTER — A Study and Teaching Aid

J. Morris Prosser

Move easily within your programs and highlight parts of text or listings for emphasis, drama, clarity.

38 Super Simple Numeric Sort

MICRO

Robert L. Martin

Arrange a list in numerical order without the need for a user supplied sorting program.

42 CMPRSS: Improved Applesoft Compression Program

lan R. Humphreys

Compress large programs and retain comments without overflowing Called Line Number Table.

52 Useful Functions — Part II

Paul Garrison

Save time and mathematical aggrevation with a compilation of defined functions.

55 Commodore-To-Apple Cassette File Loader

Art Matheny

Transfer cassette files written on VIC-20 or C64 to an Apple disk for interfacing, etc.

65

BASIC Hex Loader

Robert M. Tripp

Handy BASIC utility to load Machine Language code in Hex.

66 Circles for the Commodore 64

Lester Cain

An interesting mathematical way to plot circles on the C64.

Product Reviews

11 Paint Magic

Easy to use graphics with joystick and keyboard.

11 Promenade Model C1 EPROM Programmer Add-on programmer which handles 12 models of EPROM and at least 8 of EEPROM.

11 TimeTrax

Time management system for personal or business life, including printed schedules.

12 Spell Perfect

Machine language spelling checker for Letter Perfect or any standard text files.

12 The Complete Graphics System

2 and 3 dimensional graphics including 108 colors.

Departments

2 Highlights

6 Editorial

7 Feedback

8 Spotlight: Sage

10 Lyte Bytes

11 Reviews

72 CoCo Bits

73 Microbes

74 Catalog

78 Books

79 Listing Conventions

80 Advertiser Index

80 Next Month in Micro

editorial

Dear Readers,

As we approach the midpoint of 1984, I find myself looking towards the future. In the field of computers so much happens so quickly that it is hard to imagine what will transpire in the remainder of this year, let alone five years hence. One way to approach the future is by examining the present, noting the trends and then projecting. At this time the world of the microcomputer continues to dish up new surprises. It seems every time you turn around a new computer is being launched. Although the appearance may differ from machine to machine they are all based on a few standard chips. At its inception, MICRO chose to focus on the 6502 chip. This chip has proven itself to be a well designed and dependable innovation. Although the heyday of the 6502 has passed, it is not dead. This is clearly evidenced by Apple releasing yet another 6502-based computer - the Apple IIc. Apple seems to also be aware of the need to move onward and did so with the introduction of the Macintosh. The 68000 brings the general populace in touch with 16-bit machines. (I will not go into the advantages of a 16-bit over an 8-bit because, if there weren't any, the 68000 would never have surfaced.) Presently the big name in chips seems to be Intel, not Motorola. The 8088, 8086 and other chips developed by Intel have become the backbones of micros made by IBM, Hewlett-Packard, and Digital, to name a few. These are not names to scoff at. As popular as 6502 based machines (Apple, Atari, Commodore, etc.) are, the bulk of sales is starting to shift to machines based on other chips. Unfortunately or fortunately, depending on your viewpoint, there are rumors that Intel is only going to be able to fill 25 percent of its orders. If this proves to be true then someone will have to pick up the slack. The question is who. Perhaps Motorola will seize the opportunity and cover the deficit, using their chips.

But, even if Intel completely dominates the market, the 6502 will carry on. People don't throw away computers because they become outdated. The fact that there are still many IBM mainframes using cards is a testimony to this. Why do people continue to use outdated computers? Certainly the monetary aspect can't be overlooked. Even with drastic reductions in the price of memory (the new HP Nomad has as many words of memory as the old IBM 360 series), and the lowering of the price of computers in general, they are still not cheap. For many it is a matter of loyalty. Others are content with the familiar and prefer the comfort of an old friend to the fear of the unknown. And there are those people who prefer to live in the past, not be bothered and are perfectly content, thank you very much. For these and other reasons there will be a need for 6502 machines, journals, software and support for many years to come.

But what about the future? Certainly one cannot ignore the 68000 or Intel's 80186. To pretend they aren't improvements on previous chips is folly. Rather than seek to delude ourselves I suggest we embrace new technology with open arms and open eyes. To blindly accept something simply because it has been billed as new and improved is foolish. I think the best approach is one of open skepticism. A willingness to explore new territory and seek new frontiers. After all, isn't that what the world of computers has always been about? Let's examine the innovations and carefully separate the wheat from the chaff. Bearing in mind past mistakes, we will always find room to improve and go forward. We have built better mousetraps; we have even built better "mouses"; why not now create men? Because, of mice and men, there is no end

Mark S. Morano

Mark S. Morano Technical Editor

On The Cover

Robert Cook, farmer - Cynthia Cabott 1741-1817 1753-1819 Came to Boston from London, 1753 Fought at Concord Bridge and throughout Rev. War

George Cook, merchant - Grace Adams 1778-1849 1793-1845 Moved to Virginia and fought in War of 1812 with Andy Jackson

Robert Cook, mountain man - Little Moon 1818-1876 ?? -1873 Prospected for gold in CA; Union Army Scout; Died at Little Big Horn.

William Cook, lawyer - Bonnie Lee 1923-1863 1831-1884 Confederate Major; Died at Gettysberg

On the bridge at Concord, Massachusetts, a colonial minuteman dreams of past and future glories of family and country. Data Bases, long thought of as tools for business and government, have many useful applications in personal life as well. Keeping family trees, health information, employment records are just a few uses which can make you paper-independent. Happy Independence Day!

Dear Ian,

(RE: Micro 67, Dec. 1983)

I have a question about your program 'C-64 Alarm Clock'. For some unknown reason, when I use 'GOSUB 9140' to reset the alarm, the computer displays 'SYNTAX ERROR IN 48'. It does not affect the operation of the clock, but I would like to know why this statement appears, since there is no statement 48 in this program. I have tried to list statement 48, however, nothing lists. Please reply as soon as possible. Thank you.

Kenneth K. Choy San Francisco, CA

Dear Kenneth,

The situation you describe, getting a 'syntax error' after 'gosub 9140', seems to occur only occasionally. The simplest explanation is that the GOSUB command is intended to be used from within a program. If you type

it into the keyboard directly, then BASIC will execute the subroutine ok. When it is finished, however, it will try to resume executing the program at the next statement after the GOSUB. Since there is no program running, it gets confused and gives an error message.

The error seems to be quite harmless, and does not affect anything. If you use the 'gosub 9140' statement within a program, you should not incur an error.

There is no line 48, of course, and that number is meaningless.

I hope you enjoy the alarm clock program, Kenneth, and that this odd error doesn't cause any problems.

Ian Adam Vancouver, BC, Canada

To the editor,

Ref. Micro No.51 August 1982, page 97.

First things first. I truly enjoy your magazine. Similarly for Mr. Bongers articles.

In Mr. C. Bongers program on an improved method of garbage collection, MICRO No. 51 page 90, the program works as advertised. However, I found a slight problem when I attempted to use it with string arrays. The second paragraph on page 97 appears to be too brief. I tried using the string version of:

&CLEAR A:DIM A(20,20)

to initialize a string array to zero. This version:

&CLEAR A\$:DIM A\$(20,20)

didn't do anything until it was modified to force a cleanup as follows:

&CLEAR A\$:FRE (1,K) : DIM A\$(20,20)

From then on I was smiling.

James Fulton Corona Del Mar, CA

AICRO

One Month Added to All Subscriptions

Because of our combined April/May issue, we've gotten some questions from readers wanting to know if we were going to be bimonthly, if they were going to loose an issue, if we were taking a vacation early, etc.

The answer is much simpler. When we redesigned MICRO to make it more readable, we needed some extra time between issues to gear up our production department (artistic temperament and all that). So we gained the needed time by combining two issues.

It was a one-time thing. We are not going to be bimonthly. More importantly, you will not lose an issue. If you subscribed for 12 issues, you will receive just that — and the combined issue counts as only one. All subscriptions will be extended one month.

While we're on the subject of subscriptions, please check your mailing labels to be sure all information is correct; tell us about problems right away.



At last! . . . A dual 6522 versatile interface adapter (VIA) board for the Commodore-64.

The 6522 VIA, long the preferred input/output chip for 6502 microcomputers, is now available for the C-64. 6522 programming techniques, covered in many available books, can now be applied to the C-64 for even the most sophisticated real-time control applications. Board allows full use of the IRQ interrupt. When combined with the C-64's memory capacity, it provides an extremely powerful yet cost-effective development system and controller in one package. Includes extensive application notes and programming examples.

Up to four boards can be connected together, providing sixteen 8-bit ports. Order Model 64IF22, \$169 for one, postpaid USA. Each additional \$149.

Complete reconstructed Assembly Language source code for the C-64's BASIC and KERNAL ROMs, all 16 K!

Extensively commented and crossreferenced. Far more than a mere "memory map" of useful locations, this book really does tell all. An incredible time-saver in effective C-64 programming and understanding. Order C-64 Source \$29.95, postpaid USA.

SCHNEDLER SYSTEMS

1501 N. Ivanhoe, Dept. M7 Arlington, VA 22205 Telephone orders/information: (703) 237-4796 VISA MASTERCARD





Sage Microcomputer System

Distributor

Sage Computer 4905 Energy Way Reno, NV 89502

Introduction

The SAGE II is a fast 32-bit computer using the p-System Operating System with a 68000 Interpreter to emulate the 'p-machine.' SAGE chose this operating system for a number of reasons. To develop their own Operating System would have been time consuming and costly, and once it was finished they would be incompatible with everyone else. Instead they opted for a highly portable system which would allow programs to be transferred from one machine to another with very little difficulty. Portability being the key, many programmers purchased SAGEs to use as developmental tools. The SAGE also had the added attraction of being very fast. With these points in mind, the majority of the SAGEs sold during the first year were bought by programmers and developers. Since that time the market and support of the SAGE has greatly expanded.

The Processor

The SAGE II uses an 8mhz, interrupt driven 68000 microprocessor. It has a 16-bit data bus and a 24-bit address bus, directly addressing 16 million bytes. There are more than 1000 executable instructions, the set containing 56 instruction types with 14 different addressing modes. With 17 general purpose registers, each 32 bits long, a 24-bit program counter and a 16-bit status register, the SAGE is a powerful machine. Using an 8 Mhz clock the MC68000 (without wait states) runs at 2 million instructions per second. There is a light on the processor which indicates when the bus is active, inactive or the processor is in process.

Memory

RAM memory for the SAGE II is configurable from 128K to 1024K bytes in 128K increments. On the Main processor board (CPU board) up to 512K bytes may be stored, with an additional 512K on the Winchester board. A self-test, DEBUGGER, and bootstraps are in the EPROM firmware.

Keyboard and Physical Description

Basically a standard Qwerty keyboard, the entire unit is connected with a telephone-like cord allowing the user to move the keyboard to his lap or any convenient position. The basic alphanumeric keys are laid out in the usual manner with a numeric pad to the right. Above this pad are four programmable function keys (their function changing from program to program). The SAGE II is contained in an aluminum case measuring 3.5" x 12.5" x 17". Weighing in at 15lb. 8 oz., it is easily moved.

Interfaces

SAGE decided to simplify I/O implementation by using I/O memory-mapped assignment. The connections provided are: Terminal - RS232-C, Modem - RS232-C, Printer - parallel, Group-A and B - dipswitch, and IEEE-488 -GPIB bus. A second RS232-C port is available. With the Winchester board 4 serial ports can be supported.

Documentation

The documentation we received included a Getting Started/Word Processing volume, a Technical Manual, and a p-System Operating System Manual. Each manual



was contained in a 3-ring hard-cover binder which fit into another hard-covered box. The documentation was clearly written, with indexes and table of contents that were very helpful. Most of the information was easily accessed and references were provided where appropriate.

Software

There are some fine software packages available for the SAGE II. These include some excellent business, spreadsheet and database products. As the SAGE II uses the p-System Operating System, it lends itself to easy transferral of software developed on other p-System machines. Given this portability of programs, I would expect a steady influx of software for this microcomputer.

Peripherals

The SAGE II supports single and dual disk drives, Winchester disk, dot matrix and daisy-wheel printers, monochrome and color monitors. The system came with a QUME monitor which is ergonomically designed (i.e., takes people into consideration). This was a very nice addition, being able to rotate and swivel the screen to avoid glare, and position the monitor to suit the user's preferences and body (tall, short, etc.).

Price

The SAGE II with one 640K floppy drive is listed at \$3,200, with two 640K floppy drives it is listed at \$3,900. If you choose to expand to 512K bytes of parity RAM [which is necessary for either the Sage Multi-User system or the Idris Operating System], it is an additional \$500. The Qume CRT comes in a variety of flavors, prices ranging from \$690 for the green QVT-102 to \$1,310 for the amber QVT-211GX which has full graphics capabilities.

Conclusion

The SAGE II is a well designed and competent computer. SAGE is the only low-cost multi-user (2 users) and multi-tasking micro on the market. Allowing foreground and background activites to run concurrently, you can compile while using the word processor. Although this not the micro for everyone it is definitely one of the best 68000 micros currently available. For those who are interested in a more serious micro, particularly for developmental or business purposes this is definitely a machine worth considering.

MICRO

OS9 APPLICATION SOFTWARE

ACCOUNTS PAYABLE

\$299

ACCOUNTS RECEIVABLE

\$299

GENERAL LEDGER

with CASH

JOURNAL

\$399

PAYROLL

\$499

SMALL BUSINESS INVENTORY

\$299

COMPLETE DOCUMENTATION \$19.95

OS9 & BASIC 09 ARE TRADEMARK OF MICROWARE, INC. & MOTOROLA CORP.




(405) 233-5564 2110 W. WILLOW — ENID, OK 73701



More features to prevent errors, false printout, disc skips! Only ISOBAR has 3-way spike protection, noise suppression for RFI PLUS isolated filter banks! Individual filter banks isolate each load from other loads minimizing data errors of any kind. MOV surge suppressors arrest both common mode and differential mode surges. L/C filter network rejects radio frequency noise at any amplitude. Torroidal coils for greatest efficiency! All-metal housing.

Order toll free 1-800-662-5021 IN ILLINOIS, CALL 1-312-642-6871


Glaci toll lice i o	00 002 002	1-312-042-0071
Indus-Tool, 325 W. Huran, Chicago, IL 60610 Send model #_	Dept. M MasterCard V/SA	Model IBAR 4-6 (4 outlets, 6 ft. cord) Only \$79.95
Enclosed is \$ MasterCard or Visa Card no. Name		Model IBAR 2-6 (2 outlets, 6 ft. cord) Only \$54.95
Signature	State Zip	Model IBAR 8-15 (8 outlets, 15 ft. cord) Only \$97.95



Last month we printed a puzzle, find the answer - first decipher each (see copy). The secret is now revealed -read the slashes and circles as ones and in reverse order; you get the following cartoon. We will of course provide the message -"welcome to lyte bytes."

This month to text your computer literacy we have a word scramble. To

word and write it in the adjacent box; extract the letters that fall within the zeros, divide them into groups of circles; take these letters and seven, translate each group into its unscramble them to arrive at the final ASCII equivalent, then read the letters answer using the blank lines under the answer in next month's Lyte Bytes.





Product Name: Paint Magic

Equip. Req'd: Commodore 64 with disk drive,

joystick and color monitor

Price: \$50

Manufacturer: Datamost, Inc.

8943 Fullbright Avenue Chatsworth, CA 91311

Description: A graphics program that creates pictures with the help of a joystick and the keyboard. You advance from circles and boxes with one color fills, to sketches with self-designed color patterns which can be transposed, exchanged and saved for later recall. Portions of the screen can be magnified for detailed work. Sample pictures are provided to show you what Paint Magic is capable of.

Pluses: Any screens you design can be saved and included in your own BASIC programs. Because of the numerous color and pattern choices you have amazing flexibility to experiment with.

Minuses: Only five colors can be used at a time. A joystick with eight positions is essential and being able to select diagonal lockout is a very useful feature.

Documentation: An attractive and simple tutorial provides the needed information

Skill level: Beginner and up

Reviewer: Mike Cherry

Product Name: Time-Trax

Equip. Req'd: Apple II, II or IIe, monitor (preferably

Black and White), disk drive, blank diskette, 2 AA alakaline batteries

Price: \$99.95

Manufacturer: Creative Peripherals Unlimited, Inc.

1606 S. Clementine Anaheim, CA 92802

Description: An easy to use time management system, designed to help you keep track of events, scheduled meetings, etc., in your personal or business environment. One package can manage an infinite number of users. The program keeps a calendar of scheduled events for one year, and enables the user to print out a daily, weekly, or monthly schedule. It has a search of entries option, using keyword(s) and wildcards.

Pluses: Very simple to use, clean, clear and helpful menus. Hitting an escape (at most three times) will return you from anywhere in program to the main menu. Will not allow you to make an entry into the past. Has two kinds of cursors: blinking — displayed when you are to type information in; and non-blinking — displayed when you are to select an option. Retains data for the present month, and eleven months past and in the future, deleting any

month that becomes 12 months old. Maximum of 311 entries per month or 9079 characters of text. Maximum of 99 entries per day. Good error messages. A clock is included [hardware and assembly instructions]. This maintains the correct time and date, using two AA batteries as a backup. The clock itself makes this package worth the price. The clock can also be used in Applesoft BASIC or 6502 assembly language programs, a machine language program is included on the disk. Clear readable graphic display of calendar (month at a time).

Minuses: Time-Trax has a feature which reminds you of upcoming appointments and tells you when you have missed a scheduled event. A great idea, but one that is limited by the necessities of 1) your computer must be on, 2) it must be running Time-Trax, and 3] a menu or calendar must be displayed. If you haven't met these requirements your reminder becomes a missed event. Not very practical in practice, since most people will not choose to keep their computer always running and tie up their system with one program, i.e., Time-Trax. Rather, I suggest they should have made this a background instead of a foreground task.

Documentation: Thorough, easy to understand. Unlike much documentation, an index has been provided.

Skill level: Beginner and up.

Reviewer: Mark S. Morano

Product Name: Promenade model C1 EPROM

Programmer

Equip. Req'd: Commodore 64 or VIC-20 Computer,

Disk or Tape

Price: \$99.50 plus \$3 postage/handling

Manufacturer: JASON-RANHEIM

580 Parrott Street San Jose, CA 95112

Description: The Promenade is a highly capable EPROM programmer which operates from the User Port of the VIC or C-64 computers. It can program at least 12 models of 5-volt only EPROM (Erasable Programmable Read Only Memory) ranging in size from 1K x 8 to 32K x 8 and 8 models of EEPROM (Electrically Erasable PROM). In addition to programming EPROMs and EEPROMs (and erasing EEPROMs) the unit will save assembly language object code (as will any programmer) and also will put BASIC object code into ROM. An auto-start loader is furnished which can make any ROM auto-start when plugged into the computer's expansion port. Promenade's own software will put several BASIC programs on an EPROM, along with a directory of those programs. Thus, working programs can be "cast in silicon" on EPROM and simply plugged in to change job assignments for a computer. This feature is being widely used in industry where the low cost of a VIC-20 makes it attractive to dedicate a computer. The ease of BASIC programming and subsequent installation of the program in EPROM, allows major cost savings for computerized projects. Rapid turnaround of modified programs is possible with EEPROMs: the time for erasure and reprogramming an EEPROM can be as short as 2 minutes or less!

Pluses: This package outperforms most other add-on programmers, yet the cost is lower than any I've heard of. If you have the computer, all you need is mass storage, a Promenade and EPROMs to start generating programs which don't go away if the power fails. It is rugged, attractive, highly engineered and well made. Their immediate concern is to get the customer's problems solved as promptly as possible, even if this requires express mail delivery of a replacement unit.

Minuses: The major lack of this equipment is in documentation for programming EPROMs with assembly object code, and on how to manipulate assembly files with a debug monitor co-resident with the Promenade software. Everything works well together - it is just hard to learn how from the documentation. It is my personal prejudice that electrical schematics should be furnished with all electronic products, but the low cost of Promenade overcomes this feeling somewhat.

Documentation: A 16 page manual (but no schematic) is furnished. It covers saving BASIC programs to EPROM in meticulous detail. The manual is not well organized, but it is small enough that everything can be found rather easily. Documentation regarding use of Promenade for "normal" assembly-language programming is very sparse.

Skill level: In general, using EPROM programmers requires considerable knowledge about preparing assembly code for use in a read-only environment. However, this combination of equipment and documentation should allow inexperienced persons to save BASIC programs readily.

Reviewer: Ralph Tenny

Product Name: Spell Perfect

Equip. Req'd: Apple II w/48K and drive

Price: \$89.95

Manufacturer: LJK Enterprises, Inc.

7852 Big Bend Blvd. St. Louis, MO 63119

Description: A machine-language spelling checker program operating on Letter Perfect or any standard text files. It is compatible with most 80 column cards and has a file buffer of over 40,000 characters. Words are easily added to the dictionary from corrected documents and up to 255 dictionary disks are allowed - the program prompts for disk insertions.

Pluses: The well written manual is not needed for the most part being menu driven and having easily understood prompts. The program is fast (a 100 sector file took less than 2 minutes) and offers words to be corrected in context with the surrounding text. A "help" command is available

to prompt you with similar sounding words from the dictionary or you can edit the word in place.

Minuses: The program doesn't recognize "'" or "-" leading to problems with hyphenated or contracted words. A prompt to add word to dictionary instead of rerunning the program on the corrected file would be nice.

Documentation: The 72 page manual nicely complements the on-line prompting and answers all questions with specific examples.

Skill level: No particular computer knowledge necessary.

Reviewer: Phil Daley

Product Name: The Complete Graphics System
Equip. Req'd: Apple II, II, IIe, Color Monitor, disk

drive, extra diskettes for backup copies

and work disks

Price: *

Manufacturer: Penguin Software

830 4th Avenue P.O. Box 311 Geneva, IL 60134

Description: As the title says, this is a complete graphics system. Easy enough for those who aren't programmers and sophisticated enough for those who are. You can create two and three dimensional graphics, use 108 blended colors, outline areas, fill them in, draw with lines. brushes (96 choices), use freehand drawing, employ preprogrammed boxes, arcs, circles, triangles, and ellipses. There is a program in which you can create your own shapes, store them in a table, and then draw on them whenever you choose. A variety of input devices are compatible: ordinary keyboard, joystick, trackball, touch tablet, paddles, Apple graphics tablet, a mouse, and Houston Instruments HiPad. (What's left?) An object can be magnified 2, 4, or 8 times its original size, rotated, shrunk, varied in intensity, and easily transferred to any drawing. Text can be added to graphics using another special program. As originally stated — this is a complete graphics system.

Pluses: The pluses are many. The fact that it can do all of the above is a plus; that it does them well merits special applause.

Minuses: Overall, there is no such thing as a perfect graphics package. There will always be flaws. As far as minuses go with this product they are truly insignificant, bordering on non-existent.

Documentation: The documentation is generally clearly written. There are some sections that could be more lucid, but with some rereading most everything can be figured out.


Skill level: Intermediate to advanced.

Reviewer: Mark S. Morano

NICRO

feature:

A Basic DVORAK Keyboard for the VIC-20 and Commodore 64



by Alfred J. Bruey

The current keyboard was designed to slow typists down. A new arrangement can increase productivity enormously

At the 1876 Centennial Exposition one exhibitor presented a strange gadget which is now known as the "typewriter." It did not receive as much attention as it should have because this new, practical discovery was overshadowed by the "telephone," another strange new invention.

One of the first typewriter designers, Christopher Sholes, found that if the keys were arranged in a reasonable order, they would jam because of their slow action. So he rearranged them so the keys that were often hit together would not get tangled with each other. His arrangement, which assigns the letters QWERTYUIOP to the top row of alphabetic keys, is still used today. I will refer to this arrangement as the QWERTY keyboard, for obvious reasons. If there is a QWERTY keyboard, there must, of course, be a non-QWERTY keyboard. Otherwise, what would I be writing about?

Actually, there are, or have been, many non-QWERTY keyboards. The

one that I'll be discussing here, the Dvorak keyboard, was designed by August Dvorak in the 1930's. Dvorak wasn't the first to develop a non-QWERTY keyboard; in the last quarter of the nineteenth and first quarter of the twentieth century, there were a great variety of typewriter keyboard arrangements from which to choose. When I was collecting old typewriters a few years ago, before a lack of storage space put an end to that hobby, I found that probably the easiest-to-find non-QWERTY keyboard was found on the old Oliver typewriter whose model numbers went all the way to Number 9 before they were discontinued.

The DVORAK Keyboard

Figure 1 shows a drawing of the VIC-20 and C-64 keyboard with the commonly used keys changed to represent a simplified version of the Dvorak keyboard. Notice that no attempt was made to incorporate all the special characters. The arrangement in this

figure follows that shown in an article [Dvorak Keyboard for Your Computer] by John Raines in the August, 1983 issue of MICRO Magazine. This article presented a 6502 machine language program for the Apple Computer, which allows the Dvorak arrangement to be used to input data to Apple programs.

The VIC DVORAK Program

The Dvorak keyboard program shown in Listing 1 is a demonstration program that you can run to see whether or not you like this "new" arrangement. All it does is put whatever you type on the screen.

The program logic is straightforward. A GET instruction is used to get characters, one at a time, from the keyboard buffer. Then the ASCII value of the character is obtained. A conversion table, entered with a DATA and READ statement, is used to convert the QWERTY characters to the equivalent Dvorak keyboard positions. Then the character is printed on the screen (in

Listing 1

```
10 DIM MT(47)
      50 DATA 87,00,86,90,56,55,53,51,49,57,48,50,52,54,83,00
      55 DATA ØØ,ØØ,ØØ,ØØ,ØØ,65,88,74,69,46,85,73,68,67,72,84
      60 DATA 78,77,66,82,76,63,80,79,89,71,75,44,81,70,59
      65 FOR I=1 TO 47:READ MT(I):NEXT I
      100 GET K$:IF K$=""THEN 100
      1Ø1 K=ASC(K$)
      1Ø2 IF K=6Ø THEN K=44:UC=1:GOTO 115
0
      1Ø3 IF K=62 THEN K=46:UC=1:GOTO 115
      1Ø4 IF K=63 THEN K=47:UC=1:GOTO 115
      1Ø5 IF K=91 THEN K=58:UC=1:GOTO 115
      1Ø9 UC=Ø:IF K<>1ØØ THEN UC=1:K=K-128
      11Ø IF K$=CHR$(13) THEN PRINT CHR$(13);:GOTO 1ØØ
      111 IF K$=CHR$(32) THEN PRINT CHR$(32);:GOTO 100
      115 PRINT CHR$(MT(K-43)+128*UC);
      12Ø GOTO 1ØØ
0
```

lines 110, 111, or 115). Then execution 3. Another temporary solution is to is returned to line 100 to GET the next put the Dvorak character on tape on the character.

3. Another temporary solution is to put the Dvorak character on tape on the front of the keycap, the way APL.

Using the Program

First press the SHIFT and COMMODORE keys to put the VIC into text mode. Next load the program (QWERTY LOAD translates to Dvorak NRAE) and the RUN it (RUN becomes PGB). Then you begin typing as though you had a Dvorak keyboard. When you are done using the program, press the RUN/STOP key to get out of the program and revert to the QWERTY keyboard.

Notice that only the characters outlined in the heavy black lines in Figure 1 are defined. You can use other characters, but you will probably get the message

?ILLEGAL QUANTITY ERROR IN 115 if you do.

Changing Your Keyboard

There are various ways to change your keyboard:

- 1. The easiest way is to put squares of masking tape on the keytops and write on the proper leters with a felt-tip pen. You might write the QWERTY symbols in one corner of the tape and the DVORAK in another.
- 2. You can change keycaps. This is not a trivial task and you should consider it only if you are making a permanent change.

3. Another temporary solution is to put the Dvorak character on tape on the front of the keycap, the way APL characters are often imprinted on keys. These characters can also be painted on the keyfronts for a permanent change.

Getting New Keyboard Arrangements Adopted

The major problem in trying to get a new keyboard arrangement adopted is that there are millions of people trained on the QWERTY keyboard. Another problem is that there are millions of QWERTY Keyboards in use. Tests performed since the 1940's have shown convincingly that it does not take long for the increased productivity possible with the Dvorak keyboard to recover the investment in re-training QWERTY typists on Dvorak keyboards. But many companies don't have the money to hire replacement help to keep up with the day-to-day work as their typists are being retrained. They also do not have the money to replace all their QWERTY hardware.

A simple solution to the hardware problem is in sight. The availability of computers with programmable keyboards makes it possible for users trained on two different keyboards to use the same computer (at different times, of course) by plugging in differently defined keyboards. By using this method, companies can gradually switch their employees to the Dvorak layout. A Dvorak keyboard is already available as an option for the IBM PC.

Program Extensions

As this program now stands, it is only useful as a demonstration of the Dvorak keyboard. You can't use this program to input data into a different program without some programming effort.

- 1. You can change this program to an input subroutine which you can attach to a more useful program. Then you can use the subroutine to enter data for the main program.
- 2. If you are going to use the Dvorak keyboard for your permanent keyboard arrangement, you will probably want to re-write this technique in machine language and use this program as a replacement for your computer's input routine. You can get help doing this from the MICRO article referenced earlier.
- 3. You might want to extend this system to handle the characters that I didn't include in my program.
- 4. You can add coding to print the characters on the printer as well as the screen, so you can have a record of your typing progress if you are using this program to learn the new keyboard.

MICRO




SAFEWARE™ Insurance provides full replacement of hardware, media and purchased software. As little as \$35/yr covers:

• Fire • Theft • Power Surges

• Earthquake • Water Damage • Auto Accident


For information or immediate coverage call:

1-800-848-3469



SAFEWARE, THE INSURANCE AGENCY INC.

A Comparison:



The checkbook offers a simple but effective way to compare these two microprocessors

The 6809 microprocessor is found in several computers, including the Radio Shack color computer which is available just about anywhere. The 68000 microprocessor is also found in several computers. Some of these are APPLE's LISA and MACINTOSH computers and the SAGE II. While the 68000 based machines can cost 10 times the price of the 6809 based machines, they are easily 100 times more powerful.

To compare these two machines at the machine level requires a specific project; the check book is simple, but illustrative. This requires addition, subtraction, movement of values, the conversion of ASCII to binary. What tollows is not a complete program. It does contain the main subroutines required to create a simple check book program in machine language on either the 6809 or 68000.

To avoid rounding problems the choice of integer arithmetic is preferred. The smallest unit of money is the penny, so all calculations are done in pennies.

Next we have to decide the maximum value with which we are going to deal. This value should be a power of two and so large that we will never reach it. Since 16 bits leaves us with \$327.67 as a maximum value we take 32 bits as the size. This gives us \$21,474,863.54 as a maximum value. Very few check books exceed this value [positive or negative].

Good machine code writing involves subroutines. Because the

comparisons here are so simple, the subroutines may look silly. Remember that the purpose is comparison and not necessarily good code.

An implicit assumption in these subroutines is that some operating system is involved. Thus the user stack on the 6809 is presumed to be initialized. The 68000 is presumed to be in user mode and the stack pointer is initialized.

Movement

The first subroutine (MOVEATOB) is to move a quantity from point A to point B in memory. The 6809 code requires two load and two store instructions. These destroy the A and B registers so they are pushed on the stack before and recovered at the end of

the subroutine. The 68000 code can move 32 bits from memory to memory in one instruction without disturbing any other registers.

Addition

Next we need a subroutine to add numbers into an accumulator (see SUM). For the 6809 adding the least significant 16 bits is no problem. Since the carry can not be added to the D register, we have to go to byte addressing to sum the most significant bytes. Another way to do this is to create a loop count with the B register and use it as an offset. This runs slower than straight inline code.

The 68000 code can add 32 bit quantities in a single crack, so there is no need to worry about the carry bit. The ADD instruction is not as powerful as the MOVE instruction. It can only add with a data register. So we bring the 32 bit value into a data register and then sum this into the accumulator. Note that the MOVEM (move multiple registers) can be used with a single register as well as many registers.

ASCII to Binary

The simple example so far has assumed that the numbers are already in memory. Since most computers have keyboards which work in ASCII, we need a routine [GETNUM] to convert an ASCII string to a binary number which our subroutines can then add. Every operating system has its own method of getting characters from the keyboard. Here we assume that a subroutine can be written called GETBYTE which will return a byte from the keyboard into a register.

Once the string is pulled into memory and all the digits are in the range ASCII '0' to ASCII '9', the process of conversion can begin. Multiplying the result by 10 and adding in each byte of the string converts from human base 10 to computer base 2. A simple way to multiply 32 bits by 10 is to first multiply by 2 and save this in a temporary location. Then multiply by 4 [giving a final multiplication by 8] and add in the temporary value. Multiplication by 2 consists of a shift left.

For the 6809, the subroutine ROTL rotates the result area left one bit. Calling this 3 times with a MOVEATOB and the SUM subroutines completes the multiplication. Finally, a digit from the input string is masked off and added to the result. The addition requires propagating the carry

```
0
* MOVING 32 BIT VALUES CODE COMPARISON
                                                              0
    68Ø9 CODE
   SUBROUTINE MOVEATOB MOVES A 32 BIT VALUE POINTED
   TO BY X TO THE PLACE POINTED TO BY Y.
                                                              0
MOVEATOB: PSHU
                  D
                        SAVE D REGISTER
          LDD
                  ,X
                        GET 16 BITS
                                                              0
          STD
                  Υ
                        SAVE 16 BITS
          LDD
                  2,X
                        NEXT 16 BITS
          STD
                  2,Y
                        SAVED
          PULU
                        RECOVER D REGISTER
                                                              0
          RTS
                        AND LEAVE
   68ØØØ CODE
   SUBROUTINE MOVEATOB MOVES A 32 BIT VALUE POINTED
                                                              0
   TO BY AØ TO THE PLACE POINTED TO BY A1.
MOVEATOB: MOVE.L (AØ),(A1) MOVE 32 BITS
                                                              0
          RTS
                             AND LEAVE
                                                              0
  SUMMING 32 BIT VALUES CODE COMPARISON
   68Ø9 CODE
   SUM ADDS A 32 BIT NUMBER POINTED TO BY X TO AN
                                                              0
   ACCUMULATOR POINTED TO BY Y.
SUM:
          PSHU
                  D
                        SAVE REGISTER
                                                              0
          LDD
                  2,X
                        GET LEAST SIGN. BITS
          ADDD
                  2,Y
                        ADD TO ACCUMULATOR
          STD
                  2,Y
                        SAVE RESULT
          LDA
                        ONE BYTE UP
                  1,X
                                                              0
          ADCA
                        ADD IN CARRY TO NEXT BYTE
          STA
                        SAVE BYTE
                  1,Y
          LDA
                  ,X
                        MOST SIGN. BYTE
                  ,Y
          ADCA
                        ADD TO ACCUMULATOR AND CARRY
                                                              0
          STA
                        SAVE RESULT
          PULU
                  D
                        RESTORE REGISTER
          RTS
                        AND LEAVE
                                                              0
   68ØØØ CODE
   SUM ADDS A 32 BIT NUMBER POINTED TO BY AØ TO AN
   ACCUMULATOR POINTED TO BY A2
                                                              0
SUM:
          MOVEM.L DØ,-(SP)
                            SAVE A REGISTER
          MOVE.L (AØ),DØ
                            GET NUMBER
                                                              0
                            SUM INTO ACCUMULATOR
          ADD.L
                  D\emptyset, (A2)
          MOVEM.L (SP)+,DØ
                            RECOVER REGISTER
                            AND LEAVE
                                                              0
   CONVERTING ASCII TO BINARY CODE
                                                              0
   GETNUM BRINGS AN ASCII STRING INTO MEMORY AND CONVERTS
   IT TO A BINARY NUMBER. ALL ENTRIES ARE IN PENNIES.
                                                              0
  ENTER WITH X POINTING TO PLACE FOR NUMBER TO GO.
                                                              0
```

	* GETNUM:	PSHU	DXX	SAVE REGISTERS
0	GETNOM.	CLR	3,X	ZERO RESULT AREA
		CLR	2,X	
		CLR	1,X	
0		CLR LEAY	,X	POINT TO INPUT AREA
	GNLOOP:	BSR		GET BYTE FROM KEYBOARD
		CMPA	#13	WAS IT A CARRIAGE RETURN ?
0		BEQ		THEN PROCESS STRING
		CMPA	#'Ø'	WAS IT TOO SMALL ?
		BLT CMPA	GNLOOP #'9'	THE IGNORE IT WAS IT TOO BIG ?
0		BGT		THEN IGNORE IT
		STA	, Y+	SAVE BYTE INTO STRING AND GET NEXT CHARACTER
	¥	BRA	GNLOOP	AND GET NEXT CHARACTER
0	* HAVE S'	TRING IN	MEMORY.	NOW PROCESS IT.
	*			
0	KRUNCH:	CLR		MARK END OF STRING
١	*	CLR	COUNT	BYTE COUNT INTO STRING
		LY RESULT	BY TEN.	
0	*			
] `	CNVRT:	LEAY		POINT TO TEMP AREA
		BSR BSR	ROTL	RESULT TIMES 2 PUT INTO TEMP
0		BSR		RESULT TIMES 4
			ROTL	RESULT TIMES 8
		EXG		ADD RESULT
0		BSR EXG	SUM	TO TEMP AND SAVE INTO RESULT
		BCS	TOOBIG	ERROR: NUMBER TOO BIG
	*			
0	* ADD IN	BYTE FRO	OM STRING	
	*	LEAY	INSTRING	GET NEXT
		LDA	COUNT	BYTE
●		LDB	A,Y	FROM STRING
		BEQ CLRA	DONE	NO MORE TO DO HIGH BYTE OF D CLEARED
		ANDB	#15	KEEP LOW NIBBLE ONLY
0		ADDD	2,X	ADD IN RESULT
		STD	2,X	SAVE RESULT
_		BCC LDA	BMPCNT 1,X	NO CARRY TO PROPOGATE ADD IN
0		ADCA	#Ø	CARRY BIT
		STA	1,X	TO EACH
		BCC	BMPCNT	BYTE IF
0		LDA ADCA	,X #Ø	NECESSARY
		STA	πν , Χ	
0	* BUMP TO	O NEXT B		RING AND CHECK FOR DONE
٦	*	o nem p		iting line officer for some
	BMPCNT:	INC	COUNT	BUMP STRING COUNTER
0		LDA TST	COUNT	DONE WITH STRING ?
~		BNE	A,Y CNVRT	NOT YET
	DONE:	PULU	D,X,Y	RECOVER REGISTERS
0		RTS		AND LEAVE
	* ERROR I	ו מילו דרווא וו	ITIT DE M	ACHINE DEPENDENT
ł	* ERROR I	UVNDTEK /	AILL DE M	ACHINE DEPENDENT
0	TOOBIG:	(SEND E	RROR MESS	AGE TO SCREEN)
	* DAMA 41	DT.4		
	* DATA AI	HEA		
0	INSTRING:	2Ø BYTES	3	
	TEMP:	4 BYTES		
	COUNT:	1 BYTE		

through all 32 bits of the result. The loop is repeated until all string digits have been converted or an error occurs.

Comparing the 68000 version of GETNUM to the 6809 version, we see that one instruction of the 68000 does the same as two calls to a 10 line subroutine of 6809 code. To shift 32 bits left once, takes ROTL for the 6809. To shift 32 bits left twice, takes only one line of code for the 68000. The number of registers on the 68000, reduces a lot of memory requirements. While the 6809 must continually swap pointers from register to memory, the 68000 keeps all values in registers, for this simple example at any rate.

Conclusion

These simple comparisons are intended to be educational. Experience with the 68000 sometimes makes writing code on the 6809 frustrating. The ability to address 16 megabytes of RAM on the 68000 versus 64 kilobytes on the 6809 makes one wonder if the term "micro" really applies anymore.


The reduced coding required for the 68000, increases programmer productivity and decreases the time for producing a final result. Obviously, there are many ways to solve each problem. The flexibility of the 68000 and the number of registers, makes this microprocessor the most powerful chip to date. While the 6809 makes a great home based computer, the power of the 68000 makes it far more useful in the business or scientific environment.

Bibliography

- "MC6809 Preliminary Programming Manual", Motorola Inc., 1979
- "Color Computer Assembly Language Programming", William Barden, Radio Shack
- "16-Bit Microprocessor Users Manual", Motorola, Prentice-Hall, 1982
- "Motorola Microprocessors Data Manual", Motorola, 1981, pgs. 4-298 to 4-329 and pgs. 4-661 to 4-710

Mr. Rosing received a B.S. Engineering Physics from Univ. of Colorado in 1976, and a Ph.D. in Nuclear Engineering from Univ. of Wisconsin in 1982. He is presently Chief Engineer for Network Telecommunications in Denver.

ATARI 48K * TRS C/C 32K COMMODORE 64 747 FLIGHT SIMULATOR



ACTUAL SCREEN PHOTOGRAPH

Superbly realistic instrumentation and pilot's view in lifelike simulation which includes emergencies such as engine fires and systems failures. This program uses high resolution graphics to the full to produce the most realistic flight-deck display yet seen on a home computer. There are 21 real dials and 25 other indicators. Your controls operate throttle, ailerons, elevators, flaps, slats, spoilers, landing gear, reverse thrust, brakes, etc. You see the runway in true perspective. Uses joysticks and includes options to start with take-off or random landing approach. A real simulation, not just another game! Cassette only, \$27.95 (add 6% in Calif.). Sole U.S. distributor for D.A.C.C. Ltd., England.

F. Ashton P.O. Box 7037 Chula Vista, CA 92012

Come See Us at Commodore Convention

Sat. & Sun, July 28-29 Hershey, Pennsylvania

The show is being run by the Mid-Atlantic Regional Commodore Association (MARCA) and there will be speakers, workshops, and exhibitors. For info. call Mindy at 717/486-3274.

It's an easy trip from all areas of the east, from CT to VA, and a lovely place with lots of family fun.

Come visit us at

Booth Number 101 try some of our latest software packages, and say "Hi" to the MICRO Staff.

	TINE TO ROTATE 4 WITH X POINTING 1	BYTES LEFT ONCE TO BYTES TO ROTATE	0
ROTL:		SAVE REGISTER CLEAR CARRY BIT SET COUNTER	0
ROTLOOP:	LDA B,X ROLA STA B,X DECB	GET BYTE TIMES 2 SAVE BYTE DO 4 TIMES	0
*	BPL ROTLOOP PULU D RTS	RECOVER REGISTER AND LEAVE	0
68ØØØ GETNUM CONVER	BRINGS AND ASCII TS IT TO A BINARY	I STRING INTO MEMORY AND Y NUMBER. ENTRIES ARE	C
POINTI	NG TO THE PLACE I		C
GETNUM: GNLOOP:	MOVEM.L DØ-D2/AØ LEA INSTRING BSR GETBYTE CMP.B #13,DØ	### ACCORD NAME OF THE PROCESS STRING WAS IT A CARRIAGE RETURN ? THEN PROCESS STRING WAS IT TOO SMALL ?	C
	BEQ KRUNCH CMP.B #'Ø',DØ BLT GNLOOP CMP.B #'9',DØ	THEN PROCESS STRING WAS IT TOO SMALL ? THEN IGNORE IT WAS IT TOO BIG ? THEN IGNORE IT	C
(MOVE.B $D\emptyset$, $(A\emptyset)$ +	THEN IGNORE IT - SAVE BYTE INTO STRING - AND GET NEXT BYTE	•
HAVE S		NOW PROCESS INTO BINARY	0
CRUNCH:	CLR.L D1	MARK END OF STRING CLEAR RESULT G,AØ POINT TO TOP OF STRING	•
NVRT:	LSL.L #1,D1	RESULT TIMES 2	C
(ADD.L D2,D1	SAVE THIS RESULT RESULT TIMES 4 MORE FOR 8 ADD IN 2 FOR 10 TIMES NUMBER TOO BIG	•
		Ø GET BYTE FROM STRING	¢
	ADD.L DØ,D1 BVS TOOBIG TST.B (AØ)	MASK OFF ALL BUT LOW NIBBLE ADD TO RESULT TOO MANY DIGITS DONE YET ? NOPE, KEEP ADDING BYTES	¢
4	MOVE.L D1(A3)	### ADDING BITES AND LEAVE ##################################	C
* * SUBROU *	TINE TO SEND ERRO	OR MESSAGE TO SCREEN	(
TOOBIG: ♥ DATA A		AGE TO SCREEN	(
*			

Flight Simulator II Microcomputer Simulation At Its Best

by Chris Williams

By analyzing this design masterpiece, programmers may discover the elements needed to make their own software great



Until now, simulations designed for microcomputers have been unexciting, crude approximations of whatever reallife phenomenon they were trying to model. They were slow. They lacked detail. And all too often, the modeling equations employed were out-and-out wrong. But no longer. A company called SubLogic Corporation has seen fit to single-handedly advance the state-of-the-art in microcomputer simulation technology beyond its childhood stage into exciting, energetic adolescence.

SubLogic was the manufacturer of Flight Simulator, the first popular microcomputer flight simulation. It was designed to run on a 16K Apple II, and it did so -- more or less. Amid relatively little fanfare, they've now released a sequel designed for the newer crop of Apples that sport 64K. There are also versions out for other machines. They call it Flight Simulator II, but there all similarity between sequel and

original ends.

Flight Simulator was revolutionary in its day. No one had done a flight simulation on a microcomputer before Bruce Artwick, co-founder of SubLogic, worked his magic. The final product ran reasonably well, but it was slow and the graphics lacked pizazz.

Not so with Flight Simulator II. The screen updates are faster and detailed scenery for four different parts of the U.S. are included with the package. Additionally, the company advertises the availability of scenery disks for other areas of the U.S. It all makes for a degree of realism never before approached on a microcomputer.

Flight

The airplane modeled in Flight Simulator II is a Piper PA-28-181 Archer II; a single engine, 148 mph., non-retractable gear general aviation aircraft. In real-life, the Archer II performs very well while remaining easy to fly. It is, consequently, an excellent choice for the product.

The simulation flight controls are on the keyboard. SubLogic includes helpful cue-cards with the package that specify which keys do what. As a pilot, I found flying with keys instead of a control yoke and rudder pedals disconcerting at first, but I soon adjusted. At my request, other pilots tried it and agreed the adjustment came easy. A non-pilot would probably never notice.

The layout of the keyboard is fascinating and all computerists writing user-interactive routines could learn from it. The T,F,H,B diamond is used as the control yoke of the aircraft. It's perfect for one hand operation and easily learned.

But it's in the use of the G key that something innovative has been added. Whatever the value of the aileron control variables (set by F and H), they are nulled to neutral with a single press of G. Without this, several key presses of either F or H would be necessary to return a given setting to zero. They gave this problem a lot of thought and came up with an excellent answer.

Some of the most interesting features of the product are in the navigation and communications radios. Here the simulation uses cntl-C and cntl-N followed by greater-than or less-than signs to simulate changing a frequency. This is a good choice as cntl keys are generally a bit awkward. Why is that good? Because nothing in flying is as awkward as changing radio frequencies in turbulence. Making it difficult on the simulation is entirely appropriate.

The Editor

The product includes a particularly valuable feature called "The Editor". At any time during flight, a touch of the ESC key sends you to The Editor, and from there you can change the current flight situation to be anything you wish.

The procedure is interesting and, again, programmers should take note. When you press the ESC key, a menu entitled "Simulation Control" is displayed. The menu is two pages long. Moving off the bottom of one page automatically sends you to the other. These two pages contain a list of simulation variables and their current values. By positioning the cursor at the proper variable line and entering a new value, the user can quickly change his situation without having to fly into it.

There are two valuable applications for this feature. First is the ability to set North and East coordinates which allows the user to instantly change from, say, the Chicago scenery area to the Boston-N.Y. scenery area without a time consuming crossing of the intervening distance between.

The second valuable application has to do with Critical Attitude Recovery. CAR is required by the FAA (Federal Aviation Administration) as an integral part of the instrument flight training curriculum for pilots attempting to add an instrument rating to their license. CAR is taught in an actual airplane, generally as follows. The student, wearing a hood to restrict his vision to the instrument panel, is told to close his eyes or cover them while the instructor takes control of the aircraft.

The instructor then places the aircraft in an "unusual" or "critical" attitude. This is typically an extreme nose high or low configuration with a very steep bank included.

After a few seconds delay [to let the gee-forces confuse the student's equilibrium], the instructor tells the student to open his eyes and, using no outside visual references [i.e., instruments only], recover the aircraft to normal, straight-and-level flight.

The Editor allows a user to practice this procedure. Extreme values for the pitch, roll, and yaw variables can be entered at the Simulation Control menu and then, when the user exits Edit mode, he is faced with a critical attitude. Recovery technique is the same on the simulator as in real life so the exercise is excellent practice.

The Weather

Any pilot will tell you that the single most important factor in flying is the weather. Winds aloft, turbulence, and clouds often determine more about a flight than the pilot's wishes. Therefore, a simulation predicated on its accuracy in modeling real-life operation must have user variable weather. Naturally, Flight Simulator II does.

This is another area where the computerist can learn from what SubLogic has done. They've devoted attention to detail and implemented features to promote realism even where it makes the programming complex. Having this sort of professional attitude is probably more important than sheer technical skill in producing excellence in a program.

SubLogic handled the weather by allowing the user to define two layers of clouds and four of wind. Wind adjusts the airplane's ground speed for given airspeeds and clouds simply clear the screen to white when the airplane is at a blanketed altitude. With cloud bases set at about 500 feet, the airplane "breaks out" on an ILS (Instrument Landing System) instrument approach lined up nicely with the runway, making final descent and landing both easy and immensely satisfying.

Incidently, when the #1 Nav. radio is tuned to the ILS frequency, the glideslope needle on the indicator becomes active. The Localizer needle acts as it does for all the VOR navigational beacons. The pilots reading this will appreciate the level of

detail SubLogic is covering there.

Turbulence is also permitted as a user-defined feature. Its effect is random motion of the instruments which makes the airplane harder to fly.

Lastly, the user can specify a given season. The effect of this is to change the time of day when night falls. Oh yes, there's a night mode, and it is hairy. Would you have expected anything less?

Seeing the World

The reason most pilots love to fly is nowhere near as esoteric and romantic as they'd have you believe. It's really very simple. The higher you are, the more pleasant things you can see. Flight Simulator II was clearly designed with that in mind. The original Flight Simulator was a forward-looking simulation that had nothing of consequence to see in its database. This product allows the user to look in all directions by using a special key sequence. Such is the attention to detail that when you look out the rear window of the cabin, the rudder is superimposed on the screen as a thick vertical line. And, of course, when you look out the side, the wingtip is prominent at the bottom of the screen.

There's another viewing mode included that is not realistic. It's called Radar Mode. In this mode, the user can get a top view of the world and an impression of where the airplane is with respect to landmarks. This is unavailable on a real airplane and therefore somewhat bizzare, but for users to whom flying is unfamiliar it probably is a valuable, perhaps even vital, feature.

Emergency Procedures

What do you do if the engine quits? That is the first question people new to single-engine flying ask. The answer (which I've found is always responded to with a chuckle] is to execute the emergency procedures all pilots are trained to perform. But there are also other emergencies in flying that a pilot can encounter. Flight Simulator II has a feature that will throw them all at a pilot randomly to see how he reacts. It's called the Reliability Factor. This is a number the user selects from the Editor's Simulation Control menu. Anything less than 100 percent here and things start to go wrong. The lower the number, the more they go wrong.



This is an excellent feature. The malfunctions modeled are often subtle and a pilot's inattention to his instruments can result in a simple problem becoming fatal. It's a good training aid in that it really brings home to the user the importance of staying sharp and alert.

The Dogfight Game

They call it World War I Ace, and since today's general aviation airplanes are similar in performance to World War I fighters, I suppose it was inevitable. As an option of the Simulation Control menu, the user may select the dogfight game and fly against enemy fighter aircraft.

Actually, it's not bad. It's not simply a shoot 'em up. The user still has to fly his airplane properly and manuever into position in order to bomb ground targets or shoot down enemy fighters. If he fails to fly properly, the airplane will stall and crash, just as it would in the pure simulation mode.

Rules of the game are standard; you get points for shooting fighters down or bombing fuel depots, and you lose points for getting shot. Additionally, your plane degrades in performance each time it gets hit.

One rather interesting feature of the game is worth special mention because of its educational value to computerists. Unlike any actual World War I fighter, the one in this game has air-to-air radar. What this does is provide the user with information concerning targets where no information would otherwise have been available.

That is important because it demonstrates a flexibility on the part of SubLogic. They concentrated hard on realism throughout the product, but they didn't lose their ability to perceive the need for a feature that wasn't real. That's rare. I often see programmers who, once they learn to juggle assembly language routines, refuse to take advantage of those features of BASIC that simply cannot run any faster. That sort of locked-in attitude costs hours of programming time. One should guard against it.

Conclusions

This product is one of those that can be perceived as something special even before the marketplace has passed its judgement. As such, one feels compelled to examine it and determine what core characteristic makes it what it is and, further, what does it have in common with other software programs already acknowleged as masterpieces of design.


Through this sort of analysis, programmers can remove a bit of the uncertainty in software design. They can find certain prerequisite things their programs must have to excel. They can make the process more of a science and less of an art. So what is it about Flight Simulator II? What is it that makes it superb? Is it something that can be emulated?

My opinion is that the program was planned intricately, written intricately, and, most important, debugged intricately. That all comes down to one phrase - attention to detail. They covered everything. Frankly, most programs don't cover half of what they could — and therefore should. Programmers need to make a rule for themselves. This rule would say that on the day the "Finished!!" tag is hung on a program, an X is placed on the calendar for two weeks in the future. The programmer must continue testing and working on the program until that day. Just think of how many bugs would never find their way to market.

ALCRO"








Graphic Print for Commodore 64

(*Part 1*)

by Michael J. Keryan



Editor's Note: This is part 1 of a three part series. Parts 2 and 3 will appear in subsequent issues.

The Commodore 64 is capable of displaying some pretty impressive graphics. Take a look at a few of the games recently introduced, like Neutral Zone, Blue Max, or Pogo Joe. Most sophisticated games use a high-resolution bit-mapped display rather than the alphanumeric/graphic-symbol display that most of you use for your programs.

High-resolution bit-mapped graphics (and the multi-color variation) are described in the Commodore 64 Programmer's Reference Guide. The manual even shows you how to create a display using PEEKs and POKEs. However, since several thousand memory locations are involved, BASIC is extremely slow. Any practical use of high resolution graphics must use machine language routines. Since most

Create a full-page printout from a Commdore 64 high resolution display

people are not familiar with assembly or machine language programming, quite a few graphic aid and drawing programs for the Commodore 64 have been developed.

I was quite disappointed when I learned that pictures that were created on my Koala Pad could not be dumped to my printer. I also found that even though other graphic packages contained graphic dump routines, the resulting printouts were much less than perfect. Many routines give rather small drawings, one dot on the screen to one printed dot--this results in a picture a little smaller than 3 inches by 4 inches. Many graphic dump routines use the Commodore 1525 graphic mode which can be emulated by a number of interfaces with non-Commodore printers, but this

technique is very slow. The most serious fault of all of the routines I've seen is their inability to recognize a color on the screen and translate it to a pattern that is approximately the same darkness of the color. Most graphic dumps print, at most, 3 or 4 varying shades of black dots, even though one of the colors represented is white.

Since a perfect graphic dump program wasn't available, I decided to write one. These were the objectives that I set for this program:

- 1. It will work in either standard HiRes or multi-color mode.
- 2. Printouts should be large, about the same size as the display on my Commodore 1701 color monitor (approx. 7" x 9"). This will fit nicely on a normal sheet of paper with one inch borders on all sides.

Figure 1. Graphics Bit-map Mode

8193 to	8200 8201 to 8207	40 Columns of 8 bits each for 320 dots	8504 8505 to 8511
8512 8513 to 8519		horizontally 25 Rows of 8 bits each for 200 dots vertically	
		Total of 8000 Bytes	to 16191

- 3. The dump routine should work on my printer as well as those of my friends. These include NEC 8023, Prowriter (C. Itoh), Epson MX-80 and FX-80, and Gemini (Star) printers. Sorry 1525 owners, you're on your own.
- 4. Fast--to get the needed speed to print a full page of graphics, the print commands should directly access the printhead (transparent interface operation).
- 5. A unique dot pattern should be used for each of the 16 colors, so that any two adjacent colors can be distinguished. Each pattern should vary in intensity roughly in proportion to the darkness of the color on the CRT. Needless to say, the program should be able to determine the color of each dot on the screen.
- 6. Printouts of any part of the screen or the whole screen should be possible.
- 7. Most important, the program should be able to access graphic displays made from a number of graphic aid and drawing programs.

All of these objectives have been met and the resulting Assembly language program, GDUMP, is shown in Listing 1. The program is not especially compact; in fact, it uses quite a bit of memory for lookup tables. However, it works as per the above objectives and is the best graphic screen dump program that I have seen for the Commodore 64.


High Resolution Bit Map

Before describing how the program works, a short review of Commodore 64 bit map graphics is helpful. The standard high resolution bit map screen of the 64 is divided into 320 dots horizontally and 200 dots vertically. Each dot corresponds to a bit in memory. Therefore, 320 x 200 = 64000 bits, or exactly 8000 bytes of memory is required to hold this bit map pattern of ones (bit is on) and zeros [bit is off]. Let's assume our bit map memory starts at \$2000 hexadecimal (or 8192)


decimal). The order of the bytes in memory do not correspond to the manner in which the lines are scanned on the CRT--they are arranged in 8 byte blocks as shown in Figure 1.

Despite the fact that the bytes are arranged in memory a little strangely, you can see that the screen is made up of 320 bits across and 200 bits down. You can think of this as: when a bit is off (0) the corresponding dot will be off (black), and when a bit is on (1) the dot will be on (white). Many two-color screens are set up like this, but the HiRes screen (HIRES) is a little more complicated than this, as shown in Figure 2. For every 8 byte block of bit map memory (or every 8x8 dot square) there exists a corresponding one byte of screen memory.

Let's assume this 1K block of memory starts at \$0400 (1024 decimal]. The colors of the foreground and background are picked up in the screen byte. The way one byte can hold two colors is by breaking the 8 bit byte into two 4 bit nibbles. With 4 bits, each nibble can hold a number from 0 to 15. for one of the 16 colors. Therefore, for every 8x8 square of dots, the color displayed for any of these 64 dots can be found in the high nibble of the corresponding screen memory if the bit is on (1) and in the low nibble if the bit is off (0). Note that only two unique colors can be displayed in any 8x8 block of dots, but an adjacent block can have any two other [or the same] colors.



24



Multi-Color Bit Map Mode

If you thought the last section was difficult, you may as well skip this section right now. With the HIRES mode, there are two separate blocks of memory to worry about. In multi-color mode [MULTI] there are three blocks of memory, as shown in Figure 3. An additional 1K block of memory (usually starting at \$D800 or 55296 decimal] is also used to store color information. In MULTI-color mode. the horizontal resolution is reduced to 160 dots, half of that as HIRES mode. Actually, there are still 320 dots on the screen, but the color can only change for every two dots. In every two-dot sequence of the bit-map memory, we can get four possible patterns of bits: 00, 01, 10, or 11. The pattern determines where the color for these two dots can be found. So in any 8x8 square of dots, a total of 4 colors are possible. Three of these colors can be different for every 8x8 square, but one color is common to all squares--the sequence of two zeros calls for the color in the background color register \$D021.

To get an accurate graphic screen dump, we must first determine the location of each bit in an BK bit-map block, and determine the corresponding colors from either the upper or lower nibble of screen memory, the lower nibble of color memory, or from the background color register. Each color must be translated to a unique pattern for a dot-matrix printer, and these patterns must be sent to the printer. A method is also required to duplicate dot patterns for grids larger than the original 320x200 dot grid.

GDUMP

The assembler (Listing 1) is commented, so you should be able to follow along, if you are familiar with machine language. The program is assembled to begin at \$5000. There were very few memory areas left to put this code, when you want it to be compatible with the files containing graphic data from various third party routines. I decided to stick it right in the middle of your BASIC workspace. All the important constants were brought near the beginning to allow easy changes. The minimum and maximum horizontal and vertical byte numbers are located at \$5003-\$5006. The upper left of the screen is 0,0; the lower right is 39,199. You can change these if you want only part of the screen printed (but you will also have to change N1-N4 and EN1-EN2 in GSETUP and ESETUP).

There are four modes of operation:

- 0. Mode 0 is for two-color HIRES printouts. Every bit equal to 1 prints a 2x2 black square.
- 1. Mode 1 inverts the dots of mode 0. Bits that are equal to 1 print a 2x2 white area; bits equal to 0 print black dots.

- 2. This is MULTIcolor mode in which colors are determined from one of four possibilities as in Figure 3.
- 3. This is HIRES color mode in which colors are determined from either high or low nibbles of the screen memory as in Figure 2.

The starting page number for the bit-map memory, screen memory, and color memory are stored in \$5008-\$500A. These can be changed from the defaults (\$2000, \$0400 and \$D800) for non-standard screen configurations.

The program begins by jumping to a printer setup routine. For TYMAC CONNECTION interfaces, an extra sequence is required before any other sequences. This is equivalent to CHR\$(27) "W"CHR\$(00). It disables the width command in the interface and is necessary to disable printing a carriage return after 80 graphic bytes. The printer channel is opened with a secondary address which puts the interface into transparent mode (5 for CARDCO, 6 for CONNECTION). Next the correct codes are sent to change the printer spacing to 1/9 inch vertically, to eliminate blank spaces between lines. These sequences are different for NEC/C.ITOH and EPSON/GEMINI printers. Then a carriage return is sent to start the printer at a known state.

Three loops can be found in the code: LOOPH, LOOPV and LOOPN. LOOPH cycles through the 40 horizontal screen bytes. LOOPV cycles through the 200 vertical bytes. LOOPN cycles through the repeat counter REPT several times for each of the 200 lines. REPT is set up to 3 for NEC/C.ITOH and 2 for EPSON/GEMINI. This gives a total of 600 or 400 dots, respectively for the top to bottom CRT scan (left to right on the printer]. For both types of printers, this gives a line length of about 7 inches. Actually LOOPH is cycled through twice, since two dots are printed for every horizontal dot on the screen. If you follow through the logic in the area of LOOPN, you will see that every byte sent to the printer (for the 8 dots on the printhead) is made up of two 4 bit nibbles, each derived from a two-bit horizontal dot sequence on the screen.

Subroutine CHKREV simply reverses the 8-bit pattern for EPSON type printers since the printhead is set up the opposite of NEC type printheads. This routine also replaces every \$0D bit pattern with \$0B. For an

	Listing 1							
_	Liothing i							
0		; GRAPHIC S	SCREEN DUMP	V1.2	,			
		; M. J. H	KERYAN 3-	-27-84	5Ø28 1B	ESPC	BYT \$1B	;LINE SPACING
		;			5029 41	EA	BYT \$41	OF 8/72 INCH
0		; TO BE USI	ED WITH TYP	MAC CONNECTION	502A 08	ENN1	BYT \$Ø8	FOR EPSON TYPE
		; OR SIMIL	AR TYPE OF I	INTERFACE	5Ø2B ØD	ERET2	BYT \$ØD	•
		; AND PRINT	rers—		,			
_		; NEC 802	23, PROWRITE	ER, C.ITOH 851Ø	ØØFD	PL	EQU \$FD	; MEMORY USED FOR
0		; OR EPSC	ON WITH GRAF	TRAX OR	ØØFE	PH	EQU \$FE	; INDIRECT
		; EPSON (COMPATIBLE F	RINTER.	,			POINTERS
		;			5Ø2C ØØ	DATA	BYT Ø	; MEMORY REGISTERS
9					5Ø2D ØØ	VBYT	BYT Ø	USED IN THIS
•	5ØØØ		ORG \$5000	5	5Ø2E ØØ	HBYT	BYT Ø	; PROGRAM
		;			5Ø2F ØØ	NBYT	BYT Ø	
_	5000 4C 39 5	5Ø GDUMP	JMP GSTAR	T	5Ø3Ø ØØ	TBYT	BYT Ø	
0		;			5Ø31 ØØ	NIBL	BYT Ø	
	5003 FF	MINH	BYT \$FF	; HORIZ. MIN1	5Ø32 ØØ	DATAXX	BYT Ø	
	5004 27	MAXH	BYT 39	; HORIZ. MAX.	5Ø33 ØØ	DATAYY	BYT Ø	
3	5ØØ5 ØØ	MINV	BYT Ø	; VERT. MIN.	5ø34 øø	DATATM	BYT Ø	
	5ØØ6 C8	VXAM	BYT 200	; VERT. MAX.+1	5Ø35 ØØ	COLORB	BYT Ø	
	5ØØ7 Ø3	REPT	BYT 3	; REPEAT BYTES	5ø36 øø	SCREEN	BYT Ø	
	5ØØ8 2Ø	BMPG	BYT \$2Ø	; BIT MAP PAGE #	5Ø37 ØØ	ETEMP1	BYT Ø	
9	5ØØ9 Ø4	SCPG	BYT \$Ø4	; SCREEN PAGE #	5Ø38 ØØ	ETEMP2	BYT Ø	
	500A D8	CLPG	BYT \$D8	; COLOR PAGE #	;			
	5ØØB ØØ	PTYPE	BYT \$ØØ	; PRINTER	ØØ71	GFILE	EQU \$71	;PRINTER FILE #
		; $\emptyset = NEC/C$; TYPE	;			
	500C 06	; 1 = EPSON SECADR	BYT \$Ø6	. CECOMDARY	FFCC	CLRCHN		;KERNAL ROUTINES
	סש טששל	; (TRANSPAR	• •	; SECONDARY ; ADDR	FFC3	CLOSE	EQU \$FFC3	
	500D 00	INTERF	BYT \$ØØ	; INTERFACE	FFBA	SETLFS	EQU \$FFBA	
9	שש טששל	; Ø = CONNE		; TYPE —	FFBD	SETNAM	EQU \$FFBD	
		; $1 = OTHER$, IIIE —	FFCØ FFC9	OP EN CHKOUT	EQU \$FFCØ EQU \$FFC9	
	5ØØE Ø2	MODE	BYT \$Ø2	; MODE TYPE	1 1109	CHROOT	EQU PIFC9	
•)	:	D11 402	,	5039 20 21 52	GSTART	JSR SETUP	;OPEN PORT, ETC.
9		: MODE Ø =	NORMAL HIRE	S B/W	503C AD 04 50	GD 21412	LDA MAXH	, 0.2 1 0, 2201
			INVERTED HI		5Ø3F 8D 2E 5Ø		STA HBYT	; INIT. WIDTH
		•	MULTI-COLOR	,	5042 A9 00		LDA #\$ØØ	,
)		; 3 =	HIRES COLOR		5Ø44 8D 31 5Ø		STA NIBL	;FIRST NIBBLE
		;			5Ø47 AD Ø5 5Ø	LOOPH	LDA MINV	
	5ØØF ØD	GSETUP	BYT \$ØD	;SET UP CARR RET	5Ø4A 8D 2D 5Ø		STA VBYT	; INIT. HEIGHT
3	5010 20	SP1	BYT \$2Ø	; AND 4 SPACES	504D AØ ØØ		LDY #\$ØØ	
	5Ø11 2Ø	SP2	BYT \$2Ø	;FOLLOWED BY	504F AD 0B 50	OUTNUM	LDA PTYPE	;PRINTER TYPE
	5Ø12 2Ø	SP3	BYT \$2Ø	;THE NEC/C.ITOH	5Ø52 DØ ØD		BNE OUTN2	
	5013 20	SP4	BYT \$2Ø	;REQUIRED	5Ø54 B9 ØF 5Ø	OUTN1	LDA GSETUF	
•	5Ø14 1B	ESC	BYT \$1B	GRAPHIC CONTROL	5057 20 CA F1		JSR \$F1CA	;GRAPHIC
	5015 53	ES	BYT \$53	;SEQUENCE-	5Ø5A C8		INY	; CONTROL CODE
	5016 30	N1	BYT \$3Ø	; ESC, S, N1, N2,	5Ø5B CØ ØB		CPY #\$ØB	; FOR 1 LINE
)	5017 36	N2	BYT \$36	; N3, N4 WHERE	5Ø5D DØ F5		BNE OUTN1	;11 BITS
	5Ø18 3Ø	N3	BYT \$3Ø	; N'S ARE 4 DIG.	5Ø5F FØ ØB	Ottmato	BEQ LOOPV	v .Oumnum
	5 Ø 19 3 Ø	N4	BYT \$ 3Ø	; BYTE COUNT	5061 B9 1A 50	OUTN2	LDA ESETUF	
	Edit AD	;	DVm #4D	ייים ממאט מון קיקט.	5064 20 CA F1		JSR \$F1CA	GRAPHIC
)	501A 0D	ESETUP	BYT \$ØD	;SET UP CARR RET	5067 C8		INY CPY #\$Ø9	; CONTROL CODE ; FOR 1 LINE
	5Ø1B 2Ø	ESP1	BYT \$20	;AND 4 SPACES	5068 CØ 09			•
	5Ø1C 2Ø	ESP2	BYT \$20	; FOLLOWED BY	506A DØ F5 506C AD 07 50	LOOPV	BNE OUTN2 LDA REPT	;9 BYTES
•	501D 20 501E 20	ESP3 ESP4	BYT \$2Ø BYT \$2Ø	;THE EPSON ;REQUIRED	506F 8D 2F 50	TOOLA	STA NBYT	; INIT. COUNTER
-	5Ø1F 1B	EESC	BYT \$1B	GRAPHIC CONTROL	5072 A9 00		LDA #\$ØØ	, IIIII OOUII EIL
		EESC	BYT \$4B	; SEQUENCE—	5074 8D 30 50		STA TBYT	;RIGHT BYTE
	501201 AB	EN1	BYT \$9Ø	; ESC, K, N1, N2	5077 20 B4 51		JSR DATACI	•
	5Ø2Ø 4B 5Ø21 9Ø		BYT \$Ø1	;	507A 8D 2C 50		STA DATA	
3	5Ø21 9Ø	CMA	TATE 4161 T	,	507D AD 2C 50	LOOPN	LDA DATA	
•		EN2	77-		על טש שה שופל		- a Dain	
•	5Ø21 9Ø 5Ø22 Ø1	;		:LINE SPACING	5080 29 03		AND #ROR	: ØØØØØØ11
	5Ø21 9Ø 5Ø22 Ø1 5Ø23 1B	; SPC	BYT \$1B	;LINE SPACING :OF 16/144 INCH	5080 29 03 5082 20 0B 51		AND #\$Ø3 JSR DATACO	;00000011 CONVERT TO
	5021 90 5022 01 5023 1B 5024 54	; SPC TEE	BYT \$1B BYT \$54	;OF 16/144 INCH	5Ø82 2Ø ØB 51		JSR DATACO	; CONVERT TO
	5021 90 5022 01 5023 1B 5024 54 5025 31	SPC TEE NN1	BYT \$1B BYT \$54 BYT \$31		5Ø82 2Ø ØB 51 5Ø85 29 ØF		JSR DATACO AND #\$ØF	;CONVERT TO ;4 BITS
	5021 90 5022 01 5023 1B 5024 54	; SPC TEE	BYT \$1B BYT \$54	;OF 16/144 INCH	5Ø82 2Ø ØB 51		JSR DATACO	;CONVERT TO ;4 BITS

		Г	
5Ø8D 29 ØC	AND #\$ØC ;ØØØØ11ØØ	5129 18	CLC
5Ø8F 4A	LSR A	512A 9Ø ØF	BCC ONETWO
5Ø9Ø 4A	LSR A	512C EØ Ø3 ONE	
5091 20 0B 51 5094 0A	JSR DATACO ;4 MORE BITS	512E FØ 1F	BEQ THREE
	ASL A	513Ø AD 36 5Ø	LDA SCREEN ; TWO BITS = 10
5Ø95 ØA	ASL A	5133 EØ Ø2	CPX #\$Ø2
5096 ØA	ASL A	5135 FØ Ø4	BEQ ONETWO
5097 0A 5098 0D 34 50	ASL A	5137 4A HINIB	LSR A
5098 0D 34 50	ORA DATATM ; COMBINE 8 BITS	5138 4A	LSR A
509B 20 DB 50 509E 20 CA F1	JSR CHKREV ; CHECK IF REVERSE	5139 4A	LSR A ; HIGH NIBBLE 🔘
509E 20 CA F1	JSR \$F1CA ;OUTPUT BYTE	5139 4A 513A 4A 513B 29 ØF ONETWO 513D AA	LSR A ; CONTAINS COLOR
5ØA1 CE 2F 5Ø		513B 29 ØF ONETWO	AND #\$ØF
5ØA4 FØ ØB	BEQ NEND	513D AA	TAX
5ØA6 AD 3Ø 5Ø 5ØA9 49 Ø1	LDA TBYT	513E BD BE 52 5141 AA GETCOD	LDA TABCOL, X ; GET SHADE #
	EOR #\$Ø1 ;TOGGLE BYTE #		TAX .
5ØAB 8D 3Ø 5Ø		5142 BD CE 52	LDA TABCOD,X ;GET CODE
5ØAE 18 5ØAF 9Ø CC	CLC	5145 AE 3Ø 5Ø	LDX TBYT
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	, , , , , , , , , , , , , , , , , , , ,	5148 FØ Ø4	BEQ DATAE ; ALTERNATE LOW
5ØB1 EE 2D 5Ø NEND		514A 4A	LSR A ; AND HIGH
5ØB4 AD 2D 5Ø 5ØB7 CD Ø6 5Ø	LDA VBYT	514B 4A	LSR A ; NIBBLES OF
		514C 4A	LOR A ; CODE
5ØBA DØ BØ	BNE LOOPV ; CONTINUE VERT.	514D 4A	LSR A
5ØBC AD 31 5Ø 5ØBF 49 Ø1	LDA NIBL	514E 6Ø DATAE	RTS
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	EOR #\$Ø1 ;TOGGLE NIBBLE	514F AD 35 50 THREE	LDA COLORB ; COLOR IN COLOR
5ØC1 8D 31 5Ø		5152 18	CLC ; MEMORY
50C4 AD 31 50	LDA NIBL	5153 9Ø E6	BCC ONETWO
5ØC7 DØ ØF	BNE TOLPH	5155 EØ ØØ HIRØ	CPX #\$ØØ ;BITS ØØ
50C9 CE 2E 50	DEC HBYT	5157 DØ Ø6	DAD HILLY
50CC AD 2E 50	LDA HBYT	5159 AD 36 50	LDA SCREEN ; USE LOWER
5ØCF CD Ø3 5Ø	CMP MINH	515C 4C 3B 51	JMP ONETWO ;NIBBLE
5ØD2 DØ Ø4 5ØD4 2Ø 98 52	BNE TOLPH	515F EØ Ø3 HIR3	CPX #\$Ø3 ;BITS 11
50D7 60	JSR SETDWN ;UNDO SETUP RTS	5161 DØ Ø6	BNE HIR2
5ØD8 4C 47 5Ø TOLE		5163 AD 36 5Ø	LDA SCREEN ; USE UPPER
	The Looph ; Branch 100 Long	5166 4C 37 51	JMP HINIB ;NIBBLE
; 50DB 8D 37 50 CHKF	REV STA ETEMP1	5169 EØ Ø2 HIR2	CPX #\$Ø2 ;BITS 1Ø ◎
5ØDE 8D 38 5Ø	STA ETEMP2	516B DØ 1B	BNE HIR1
5ØE1 AD ØB 5Ø		516D AD 36 50 5170 20 37 51	LDA SCREEN ;GET UPPER
5ØE4 FØ 1B	BEQ PCR ; EPSON, THEN	5170 20 37 51 5173 20 A3 51	JSR HINIB JSR HIRC
50F6 49 00	LDA #\$ØØ ;REVERSE DOT		ODK HILLO
5ØE6 A9 ØØ 5ØE8 8D 38 5Ø	STA ETEMP2 ;ORDER	5176 ØA	ASL A ;DATA IN BITS ASL A ;——**—
5ØEB AØ Ø8	LDY #\$Ø8	5177 ØA	CONT. DAMASEL
5ØED B9 F2 52 EP1		5178 8D 32 5Ø	STA DATAXX
5ØFØ 2D 37 5Ø	AND ETEMP1	517B AD 36 5Ø	LDA SCREEN
5ØF3 FØ Ø9	BEQ EP2	517E 2Ø 3B 51	JSR ONETWO ;GET LOWER
5ØF5 B9 FA 52		5181 2Ø A3 51	JSR HIRC ;——**
5ØF8 ØD 38 5Ø	LDA TABTIB-1,Y ORA ETEMP2	5184 ØD 32 5Ø	ORA DATAXX ; COMBINE
5ØFB 8D 38 5Ø	STA ETEMP2	5187 6Ø	RTS
5ØFE 88 EP2	DEY	5188 AD 36 50 HIR1	LDA SCREEN ;BITS Ø1
5ØFF DØ EC	BNE EP1	518B 2Ø 3B 51	JSR ONETWO ;GET UPPER
51Ø1 AD 38 5Ø PCR	LDA ETEMP2 ; IF BIT CODE	518E 2Ø A3 51 5191 ØA	JSR HIRC ASL A ; DATA BITS
51Ø4 C9 ØD	CMP #\$ØD ; IS SAME AS	5192 ØA	ASL A ;——**—
51Ø6 DØ Ø2	BNE PRET ; CARR RETURN,	5193 8D 32 5Ø	
51Ø8 A9 ØB	LDA #\$ØB ; CHANGE IT	5196 AD 36 5Ø	STA DATAXX LDA SCREEN
51ØA 6Ø PRET		5199 2Ø 37 51	JSR HINIB ;GET LOWER
;		519C 2Ø A3 51	JSR HIRC ;——**
51ØB AA DATA	ACO TAX ;X = 2 BITS	519F ØD 32 5Ø	ORA DATAXX ; COMBINE
51ØC AD ØE 5Ø	LDA MODE	51A2 6Ø	RTS
51ØF C9 Ø2	CMP #\$Ø2 ;<2?	;	
5111 BØ ØB	BCS DØ ;NO, GO ON	51A3 48	PHA ; THIS ROUTINE
5113 BD DE 52 ZERO		51A4 29 Ø3	AND #\$Ø3 ; AVERAGES THE
5116 AE ØE 5Ø	LDX MODE	51A6 8D 33 5Ø	STA DATAYY ; THE BITS
5119 FØ Ø2	BEQ D1	;	,
511B 49 ØF	EOR #\$ØF ; INVERT GRAPHICS	51A3 48 HIRC	PHA ; THIS ROUTINE O
511D 6Ø D1	RTS	51A4 29 Ø3	AND #\$Ø3 ; AVERAGES THE
511E C9 Ø3 DØ	CMP #\$Ø3 ;MODE 3?	51A6 8D 33 5Ø	STA DATAYY ; THE BITS
512Ø FØ 33	BEQ HIRØ ;YES, HIRES COLOR	51A9 68	PLA ;——**
5122 EØ ØØ MULT		51AA 4A	LSR A ; AND
5124 DØ Ø6	BNE ONE	51AB 4A	LSR A ;——**—
5126 AD 21 DØ	LDA \$DØ21 ;COLOR IN \$DØ21	51AC 29 Ø3	AND #\$Ø3

		51AE 18		CLC	5231 20 BA FF JSR SETLFS ; TO AVOID EXTRA
W	•	51AF 6D 33 5Ø		ADC DATAYY	5234 A9 ØØ LDA #\$ØØ ;CARR RETURNS
	•				
***		51B2 4A		LSR A ; DIVIDE BY 2	5236 20 BD FF JSR SETNAM
		51B3 6Ø		RTS	5239 20 C0 FF JSR OPEN
***		;			523C BØ 56 BCS GCLOSE
***	⊗	51B4 AD 2D 5Ø	DATACT.	LDA VBYT ; GET MEMORY	523E A2 71 LDX #GFILE
	•		DHIMOL		
***		51B7 4A		LSR A	5240 20 C9 FF JSR CHKOUT
***		51B8 4A		LSR A	5243 A9 1B LDA #\$1B
888					
***		51B9 4A		LSR A	5245 2Ø CA F1 JSR \$F1CA
	;	51BA AA		TAX	5248 A9 57 LDA #\$57
		51BB BD FC 54		LDA HCTAB,X	524A 2Ø CA F1 JSR \$F1CA
				COTA DU	
		51BE 85 FE		STA PH LDA LCTAB,X CLC	524D A9 ØØ LDA #\$ØØ
	6	51CØ BD E3 54		LDA LCTAB.X	524F 2Ø CA F1 JSR \$F1CA
#	•			010	
***		5103 18		CLC	5252 A9 ØD LDA #\$ØD
		51C4 6D 2E 5Ø		ADC HBYT	5254 2Ø CA F1 JSR \$F1CA
***					l .
***	-	51C7 85 FD		STA PL	5257 A9 71 LDA #GFILE
***	®	5109 9Ø Ø2		BCC CL3	5259 20 C3 FF JSR CLOSE
#	•				and the state of t
***		51CB E6 FE		INC PH	525C A9 71 SET2 LDA #GFILE
		51CD A5 FE	CL3	LDA PH	525E AC ØC 5Ø LDY SECADR
		JIOD R) FE	ريان		L
**		51CF 48		PHA .	5261 A2 Ø4 LDX #\$Ø4
#	w	51DØ 18		CLC	
		51D1 6D Ø9 5Ø		ADC SCPG	5266 A9 ØØ LDA #\$ØØ
		51D4 85 FE		STA PH	5268 20 BD FF JSR SETNAM
	(51D6 AØ ØØ		LDY #\$ØØ	526B 2Ø CØ FF JSR OPEN
	•				
		51D8 B1 FD		LDA (PL),Y	526E BØ 24 BCS GCLOSE
		51DA 8D 36 5Ø		STA SCREEN ;SCREEN MEMORY	5270 A2 71 LDX #GFILE
				DIA DOIMEN JOSEMEN IMPROIT	l ' '
	-	;			5272 2Ø C9 FF JSR CHKOUT
	#	51DD 68		PLA	5275 AØ ØØ LDY #\$ØØ

		51DE 18		CLC	5277 AD ØB 5Ø LDA PTYPE
		51DF 6D ØA 5Ø		ADC CLPG	527A DØ ØC BNE OUTSP2
		51E2 85 FE		STA PH	527C B9 23 5Ø OUTSP LDA SPC,Y
	•	51E4 B1 FD		LDA (PL),Y	527F 2Ø CA F1 JSR \$F1CA
		51E6 8D 35 5Ø		STA COLORB ; COLOR MEMORY	5282 C8 INY
				,	
	_	;			
***	❷	51E9 AC 2E 5Ø		LDY HBYT	5285 DØ F5 BNE OUTSP
***	_				, , , , , , , , , , , , , , , , , , ,
***		51EC AE 2D 5Ø		LDX VBYT	5287 6Ø RTS
		51EF BD Ø3 53		LDA LTAB,X	5288 B9 28 5Ø OUTSP2 LDA ESPC,Y

	®	51F2 85 FD		STA PL	528B 2Ø CA F1
	•	51F4 BD CB 53		LDA HTAB,X	528E C8 INY
				*	
		51F7 85 FE		STA PH	528F CØ Ø4 CPY #\$Ø4
		51F9 B9 93 54		LDA LTABA,Y	5291 DØ F5 BNE OUTSP2
	_	5470 40			
	▩	51FC 18		CLC	5293 6Ø RTS
	•	51FD 65 FD		ADC PL	5294 2Ø 98 52 GCLOSE JSR SETDWN

***		51FF 85 FD		STA PL	5297 6Ø RTS
		52Ø1 9Ø Ø2		BCC CL1	;
**					
***	₩	52Ø3 E6 FE		INC PH	5298 A9 ØD SETDWN LDA #\$ØD ; CARR RETURN
***		52Ø5 B9 BB 54	CL1	LDA HTABA,Y	529A 2Ø CA F1 JSR \$F1CA
***			OLL	*	
		52Ø8 18		CLC	529D A9 ØC LDA #\$ØC ; FORM FEED
	_	52Ø9 65 FE		ADC PH	529F 2Ø CA F1 JSR \$F1CA
	(3)				
	_	52ØB 85 FE		STA PH	52A2 A9 1B LDA #\$1B ;LINE SPACING
		52ØD 18		CLC	52A4 2Ø CA F1 JSR \$F1CA ; BACK TO 1/6 IN.
		52ØE 6D Ø8 5Ø		ADC BMPG	52A7 AD ØB 5Ø LDA PTYPE
	0	5211 85 FE		STA PH	52AA DØ Ø4 BNE EPCL
	•				,
		5213 AØ ØØ		LDY #\$ØØ	52AC A9 41 LDA #\$41 ; ESC A FOR NEC/
		5215 B1 FD		LDA (PL),Y	52AE DØ Ø2 BNE LSPC ; OR C. ITOH
	_	5217 AE 31 5Ø		LDX NIBL	52BØ A9 32 EPCL LDA #\$32 ;ESC 2 FOR
	❷	521A FØ Ø4		BEQ CL2	52B2 20 CA F1 LSPC JSR \$F1CA ; EPSON
	_				
		521C 4A		LSR A	52B5 2Ø CC FF JSR CLRCHN
		521D 4A		LSR A	
		521E 4A		LSR A	52BA 2Ø C3 FF JSR CLOSE
		521F 4A		LSR A ; ACCUM = BIT MAP	52BD 6Ø RTS
		522Ø 6Ø	CL2	RTS ;BYTE	;
			- Lac	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	5000 MD MADOOT DVM 45 M 41 2 4M M 40 4
		;			52BE ØF TABCOL BYT 15,0,11,3,10,7,12,1
	0	5221 A9 71	SETUP	LDA #GFILE	52C6 Ø8 BYT 8,14,5,13,9,2,6,4
1	_		52101		
		5223 2Ø C3 FF		JSR CLOSE	52CE ØØ TABCOD BYT \$ØØ,\$2Ø,\$Ø4,\$28
- 1		5226 AD ØD 5Ø		LDA INTERF	52D2 ØA BYT \$ØA,\$25,\$4A,\$A5
	_	5229 DØ 31		BNE SET2	52D6 69 BYT \$69,\$87,\$2D,\$A7
1	®				52DA 6D BYT \$6D,\$DB,\$9F,\$FF
ı		522B A9 71		LDA #GFILE ; FOR CONNECTION,	
1		522D AØ ØØ		LDY #\$ØØ ;WIDTH MUST BE	52DE ØØ HICOD BYT \$ØØ,\$Ø3,\$ØC,\$ØF
ı					52E2 28 AUTHOR BYT '(C) M.KERYAN 1984'
- 1		522F A2 Ø4		LDX #\$Ø4 ;SET TO ZERO TO	JEEG ZO MUTHOR DIT (U) M. KERTAN 1704
- 1					

unexplainable reason, my printerinterface would print two \$0D patterns for every one sent, messing up the 600 byte counter. Instead of tracking down the reason for this, I eliminated any chance for this glitch to occur.

At the beginning of every line a carriage return is sent, followed by 4 spaces (to center the drawing), then a code is sent to set up the printer to accept the correct number of graphic characters (600 or 400 as explained above). These are the labeled GSETUP and ESETUP.

Subroutine DATACL returns the contents of three memory cells, based on the current horizontal and vertical coordinates: the SCREEN memory, the COLOR memory and the bit-map memory in the accumulator. To avoid confusing calculations and to speed things up a bit, lookup tables are used extensively in this routine.

Subroutine DATACO is entered with the lower two bits of the accumulator equal to two bits from the bit-map memory. When finished, this routine returns with a four bit matrix pattern that eventually gets sent as half of a byte to the printhead. This routine works differently for the four modes of operation. In modes 0 and 1, simple 4 bit patterns duplicate (or invert) the original 2 bit sequence. In modes 2 and 3, the correct colors are determined. Then unique patterns are found through lookup tables TABCOL and TABCOD. Note that each of the 16 colors are associated with two different 4 bit patterns--the high and low nibbles of TABCOD. These two different codes are alternately used when the same byte is repeated to avoid vertical lines on the printed.

After the picture is printed, SETDWN sends a carriage return and a form feed to the printer and then changes the line spacing back to 1/6 inch for normal printer operation.

GDUMP can be run by your BASIC programs by POKEing the required setup parameters into the area in the beginning of the program, then SYS 20480. Next month we'll continue this series by adding another small machine language program and a BASIC program that will allow GDUMP to print pictures made from SIMONS' BASIC, ULTRABASIC-64, DOODLE, KOALA-PAINTER and TPUG's SLIDESHOW. For those of you who don't have an Assembler to enter GDUMP, MICRO will provide these programs on 1541 disks for \$15 (US). Order MicroDisk No. MD-4. ALCRO"

52F3 8Ø 4Ø 2Ø	TABBIT	BYT \$80,\$40,\$20,\$10,\$08,\$04,\$02,\$01	
52FB Ø1 Ø2 Ø4	TABTIB	BYT \$01,\$02,\$04,\$08,\$10,\$20,\$40,\$80	
5303 00 01 02	LTAB	BYT \$00,\$01,\$02,\$03,\$04,\$05,\$06,\$07	0
53ØB 4Ø 41 42		BYT \$40,\$41,\$42,\$43,\$44,\$45,\$46,\$47	
5313 80 81 82		BYT \$80,\$81,\$82,\$83,\$84,\$85,\$86,\$87	
531B CØ C1 C2		BYT \$CØ,\$C1,\$C2,\$C3,\$C4,\$C5,\$C6,\$C7 BYT \$ØØ,\$Ø1,\$Ø2,\$Ø3,\$Ø4,\$Ø5,\$Ø6,\$Ø7	0
5323 ØØ Ø1 Ø2 532B 4Ø 41 42		BYT \$40,\$41,\$42,\$43,\$44,\$45,\$46,\$47	
5333 80 81 82		BYT \$80,\$81,\$82,\$83,\$84,\$85,\$86,\$87	
533B CØ C1 C2		BYT \$CØ,\$C1,\$C2,\$C3,\$C4,\$C5,\$C6,\$C7	0
5343 ØØ Ø1 Ø2		BYT \$00,\$01,\$02,\$03,\$04,\$05,\$06,\$07	
534B 4Ø 41 42		BYT \$40,\$41,\$42,\$43,\$44,\$45,\$46,\$47	
5353 80 81 82		BYT \$80,\$81,\$82,\$83,\$84,\$85,\$86,\$87	_
535B CØ C1 C2		BYT \$CØ,\$C1,\$C2,\$C3,\$C4,\$C5,\$C6,\$C7	0
5363 ØØ Ø1 Ø2 536B 4Ø 41 42		BYT \$00,\$01,\$02,\$03,\$04,\$05,\$06,\$07 BYT \$40,\$41,\$42,\$43,\$44,\$45,\$46,\$47	
5373 80 81 82		BYT \$80,\$81,\$82,\$83,\$84,\$85,\$86,\$87	_
537B CØ C1 C2		BYT \$CØ,\$C1,\$C2,\$C3,\$C4,\$C5,\$C6,\$C7	0
5383 ØØ Ø1 Ø2		BYT \$00,\$01,\$02,\$03,\$04,\$05,\$06,\$07	
538B 4Ø 41 42		BYT \$40,\$41,\$42,\$43,\$44,\$45,\$46,\$47	
5393 8Ø 81 82		BYT \$8Ø,\$81,\$82,\$83,\$84,\$85,\$86,\$87	0
539B CØ C1 C2		BYT \$CØ,\$C1,\$C2,\$C3,\$C4,\$C5,\$C6,\$C7	
53A3 ØØ Ø1 Ø2 53AB 4Ø 41 42		BYT \$00,\$01,\$02,\$03,\$04,\$05,\$06,\$07 BYT \$40,\$41,\$42,\$43,\$44,\$45,\$46,\$47	
53B3 8Ø 81 82		BYT \$80,\$81,\$82,\$83,\$84,\$85,\$86,\$87	0
53BB CØ C1 C2		BYT \$CØ,\$C1,\$C2,\$C3,\$C4,\$C5,\$C6,\$C7	
53C3 ØØ Ø1 Ø2		BYT \$00,\$01,\$02,\$03,\$04,\$05,\$06,\$07	
53CB ØØ ØØ ØØ	HTAB	BYT \$00,\$00,\$00,\$00,\$00,\$00,\$00	0
53D3 Ø1 Ø1 Ø1		BYT \$01,\$01,\$01,\$01,\$01,\$01,\$01,\$01	•
53DB Ø2 Ø2 Ø2		BYT \$02,\$02,\$02,\$02,\$02,\$02,\$02,\$02	
53E3 Ø3 Ø3 Ø3		BYT \$03,\$03,\$03,\$03,\$03,\$03,\$03,\$03 BYT \$05,\$05,\$05,\$05,\$05,\$05,\$05,\$05	0
53EB Ø5 Ø5 Ø5 53F3 Ø6 Ø6 Ø6		BYT \$06,\$06,\$06,\$06,\$06,\$06,\$06	•
53FB Ø7 Ø7 Ø7		BYT \$07,\$07,\$07,\$07,\$07,\$07,\$07	
54Ø3 Ø8 Ø8 Ø8		BYT \$08,\$08,\$08,\$08,\$08,\$08,\$08,\$08	_
54ØB ØA ØA ØA		BYT \$ØA,\$ØA,\$ØA,\$ØA,\$ØA,\$ØA,\$ØA	0
5413 ØB ØB ØB		BYT \$ØB,\$ØB,\$ØB,\$ØB,\$ØB,\$ØB,\$ØB	
541B ØC ØC ØC		BYT \$ØC,\$ØC,\$ØC,\$ØC,\$ØC,\$ØC,\$ØC	
5423 ØD ØD ØD		BYT \$ØD,\$ØD,\$ØD,\$ØD,\$ØD,\$ØD,\$ØD BYT \$ØF,\$ØF,\$ØF,\$ØF,\$ØF,\$ØF,\$ØF	
542B ØF ØF ØF 5433 1Ø 1Ø 1Ø		BYT \$10,\$10,\$10,\$10,\$10,\$10,\$10,\$10	
543B 11 11 11		BYT \$11,\$11,\$11,\$11,\$11,\$11,\$11,\$11	
5443 12 12 12		BYT \$12,\$12,\$12,\$12,\$12,\$12,\$12,\$12	0
544B 14 14 14		BYT \$14,\$14,\$14,\$14,\$14,\$14,\$14,\$14	
5453 15 15 15		BYT \$15,\$15,\$15,\$15,\$15,\$15,\$15	
545B 16 16 16		BYT \$16,\$16,\$16,\$16,\$16,\$16,\$16	
5463 17 17 17 546B 19 19 19		BYT \$17,\$17,\$17,\$17,\$17,\$17,\$17 BYT \$19,\$19,\$19,\$19,\$19,\$19,\$19,\$19	-
5473 1A 1A 1A		BYT \$1A,\$1A,\$1A,\$1A,\$1A,\$1A,\$1A,\$1A	
547B 1B 1B 1B		BYT \$1B,\$1B,\$1B,\$1B,\$1B,\$1B,\$1B	0
5483 1C 1C 1C		BYT \$1C,\$1C,\$1C,\$1C,\$1C,\$1C,\$1C,\$1C	•
548B 1E 1E 1E		BYT \$1E,\$1E,\$1E,\$1E,\$1E,\$1E,\$1E,\$1E	
5493 ØØ Ø8 1Ø	LTABA	BYT \$00,\$08,\$10,\$18,\$20,\$28,\$30,\$38	0
549B 4Ø 48 5Ø		BYT \$40,\$48,\$50,\$58,\$60,\$68,\$70,\$78	0
54A3 8Ø 88 9Ø 54AB CØ C8 DØ		BYT \$80,\$88,\$90,\$98,\$A0,\$A8,\$B0,\$B8 BYT \$C0,\$C8,\$D0,\$D8,\$E0,\$E8,\$F0,\$F8	
54B3 ØØ Ø8 1Ø		BYT \$00,\$08,\$10,\$18,\$20,\$28,\$30,\$38	_
54BB ØØ ØØ ØØ	HTABA	BYT \$00,\$00,\$00,\$00,\$00,\$00,\$00,\$00	0
54C3 ØØ ØØ ØØ		BYT \$00,\$00,\$00,\$00,\$00,\$00,\$00	
54CB ØØ ØØ ØØ		BYT \$ØØ,\$ØØ,\$ØØ,\$ØØ,\$ØØ,\$ØØ,\$ØØ,\$ØØ	
54D3 ØØ ØØ ØØ		BYT \$00,\$00,\$00,\$00,\$00,\$00,\$00,\$00	0
54DB Ø1 Ø1 Ø1	T C/T/A/D	BYT \$01,\$01,\$01,\$01,\$01,\$01,\$01	
54E3 ØØ 28 5Ø 54EB 4Ø 68 9Ø	LCTAB	BYT \$00,\$28,\$50,\$78,\$A0,\$C8,\$F0,\$18 BYT \$40,\$68,\$90,\$B8,\$E0,\$08,\$30,\$58	
54F3 8Ø A8 DØ		BYT \$80,\$A8,\$D0,\$F8,\$20,\$48,\$70,\$98	0
54FB CØ		BYT \$CØ	
54FC ØØ ØØ ØØ	HCTAB	BYT \$00,\$00,\$00,\$00,\$00,\$00,\$00,\$01	
5504 Ø1 Ø1 Ø1		BYT \$01,\$01,\$01,\$01,\$01,\$02,\$02,\$02	0
55ØC Ø2 Ø2 Ø2		BYT \$02,\$02,\$02,\$02,\$03,\$03,\$03,\$03	-
5514 Ø3		BYT \$Ø3	
5515		END	

INTERFACE CLINIC:

Communication Between Different Computers

How to merge several computers into one efficient system

A few columns ago I answered a letter query about communication between different computers. Here's another example: I have two Radio Shack Color Computers and one Commodore 64, but only one printer (EPSON MX-80). The 64K Color Computer is in use constantly, mostly as a word processor; the 32K (home brew) Color Computer is usually idle. Both computer systems (computer, disk, cassette and display) are plugged into separate power strips. Thus, each system is individually controllable. In order to drive the printer from the Color Computer using standard software, the EPSON switch SW2 needs to be set to 0000. For the Commodore, using a "The Connection" serial interface, the settings must be 0010. Thus, whenever I print from the other computer, I must move the printer power cord to the other power strip, open the printer case and move one switch, and connect the other drive cable. The C-64 printer interface has a 2K buffer, but the Color Computer interface has no buffer. All writing is done using ELITE*WORD, and I often must wait

for one file to print out before working on another.

Obviously, things would go better if I had a large printer buffer to capture several pages of data and print it while I work on another file. Figure 1 shows how to merge my existing computers into a single, more efficient system. The printer and the 32K CoCo will be powered from a third power strip which turns on when either or both the other systems are active. A special interface board for the CoCo will have a serial input from the 64K CoCo printer port and a parallel input from the C-64 system. A separate parallel output will drive the printer. Either computer will be able to direct output to the printer. If the printer is busy, the requesting computer will have to wait as usual. I expect that 28K of memory would be available in the 32K CoCo after allowing for display memory, stack and controller program workspace. 28K of buffer is enough for more than 15 pages of double-spaced text, which exceeds any need I have had so far.

CORMODURE SY PARALLEL INPUT SERIAL INPUT PARALLEL OUTPUT SYK COCO EPSON FX-30

Figure 1. A special network connection will allow two computers to feed a third computer which will serve as a printer buffer.

by Ralph Tenny

Let me share some of my philosophy used in designing this system. Three primary considerations were involved: first, the new system should be compatible with commercial software running on both the 64K CoCo and the C-64. Primarily, that means no special printer drivers will be written for any commercial software. Second, the expansion will be modular. As I complete some part of the task, an improvement in system efficiency will result. Finally, no internal modifications will be made to either the 64K CoCo or the C-64. All these considerations are met by the (apparently) clumsy plan to configure the 32K CoCo interface to respond to either of the other computers as if it were a printer. That is, the input interfaces will handshake with the driver computers exactly as does the existing printer interface. Software options for straight-through printing or formatting by the 32K CoCo will be written.

At some future time, I may consider eliminating the "Connection" interface; most commercial software uses the Commodore serial port. To eliminate this interface would require hours of experimentation and study, designing an interface to convert from Commodore serial to RS-232 format, and there isn't time or need for that. The C-64 claims to have an RS-232 serial port available, but this requires a special output interface. Also, much commercial software for the C-64 does not support this port which is implemented by simulating a 6850 ACIA in software. Finally, the data transfer rate of the serial port is faster than the RS-232 transfer rate.

I am beginning to implement this printer buffer system as outlined above.

Due to various time pressures, the conversion will need to be made in several phases. Each phase will be reported in the column as the work is performed. A separate problem had to be solved first. The 32K CoCo must be capable of booting (starting up) unaided, so it must have an autostart ROM in the expansion (cartridge) port. I have an EPROM programmer for the C-64, along with 6502 development software which will handle the Commodore programming required. My 6809 development software has no way to send 6809 code to the C-64 programmer. The temporary link between the CoCo and the C-64 is presented this month; probably, the CoCo expansion interface will follow next month.

The simplest way to transfer data between dissimilar computers is to use a standard data rate and interface at the transmitting computer. If the software and hardware at the receiving computer is fast enough to capture the data as it comes, no handshake is needed. For this one-way data flow, the CoCo/C-64 interface can be a one-transistor level translator and inverter (Figure 2). R1 and D1 limit base drive to Q1, while Q1 and R2 drive PB7 of the

Commodore User Port. The CoCo printer port incorporates a BUSY* signal, so a third wire is needed to feed back a high level ("not busy") to the serial in-line.

The program listing is a rudimentary data input program which services the interface of Figure 2. Figure 3 shows the flowchart for the program, which assembles incoming serial data into bytes and saves the data in sequential locations beginning at \$2000. Since the C-64 has a timer available, complicated bit timing is not needed. Using a timer means that less

experimentation is needed to get the timing correct. Instead of counting down a software loop, the CPU polls the CIA Interrupt Status bit to learn when the timer has finished.

For those who need the review, Figure 4 shows how the 8-bit serial asychronous data is formatted. A Start bit (TTL low level) is sent first, followed by eight data bits which may be either low or high. At least one Stop Bit (high level) is sent to complete the transmission of a single byte. Note that Radio Shack 1.0 BASIC sends only seven bits with one Stop bit; later





Figure 2. Two resistors, a diode and one transistor make up a data transmitter to send data from the Color Computer to the Commodore 64 (see text).



FOR THE COMMODORE 64™ The home accounting package that will make your budget, not break it! ONLY \$39.95

TOT! TEVT - - 1/10 - 0/0

Money-Saving Bonus Paks of 64 Software

(BP-1)---(disk) toti.text/ totl.speller/totl.label reg. price \$103 NOW \$79 (BP-2)-(disk) totl.business/ totl time manager/ toti.infomaster/toti.text reg. price \$228 NOW \$159 (BP-3)—(disk) totl.infomaster/ totl.text/totl.speller reg. price \$129 NOW \$99 (BP-4)--(disk) totl.text/ totl.speller/ research assistant

reg. price \$118 NOW \$89 (BP-5)—(tape) totl.text/totl.label reg. price \$60 NOW \$49

Commodore 64 and VIC 20 are trademarks of Commodore Business Machines Inc.

INFORMATION AND ORDER COUPON

TAPE DISK

TOTL.TEXT 2.0 (VIC + 8K) TOTL.TEXT 2.5 (VIC + 16K) TOTL.LABEL 2.1 (VIC + 16K) TOTL.TIME MGR. 2.1 (VIC + 8K) RESEARCH ASST. 2.0 (VIC + 8K) TOTL.BUSINESS 3.0 (VIC + 24K)	□ 24.95 □ 28.95 □ 34.95 □ 38.95 □ 19.95 □ 23.95 □ 29.95 □ 33.95 □ 29.95 □ 33.95 □ 84.95
TOTL.TEXT 2.6 (C-64) TOTL.SPELLER 3.6 (-C64) TOTL.LABEL 2.6 (C-64) TOTL TIME MGR. 2.6 (C-64)	□ 39.95 □ 43.95 □ 34.95 □ 19.95 □ 23.95 □ 34.95 □ 38.95
RESEARCH ASST. 2.0 (C-64) TOTL.INFOMASTER 3.6 (C-64) TOTL.BUSINESS 3.6 (C-64) TOTL.MONEYMINDER 3.6 (C-64) BONUS PAK #	□ 34.95 □ 38.95 □ 49.95 □ 94.95 □ 39.95
C.O.D. orders \$2'00 additional (CA residents additional (CA residents add 6'12'8' sales tax) FOR ORDERING ONLY—CAL OUR TO Continental U.S. 1-800-351-1555, Califori Hawaii and Alaska 415-943-7877 SEND MORE INFORMATION (no chic	nia 1-800-351-1551
Name	
City State	
Phone ()	Exn.
Card #	Date



quality you can afford 1555 Third Avenue Walnut Creek, CA 94596 415/943-7877




Figure 3. This flow chart describes the program listing for the Commodore to receive data from the Color Computer.

STAR*	T		EIGH"	TA <u>O</u> 1	A BIT	S			STOP
BIT	1	2	3	4	5	6	٦	8	EIT

Figure 4. This diagram illustrates a typical binary data byte as transferred by the circuit of Figure 2.

versions send eight data bits and one Stop bit.

Refer to Figure 3 and Listing 2 for the following discussion. NEW initializes various locations and the program waits for Bit 7 to go low. GET performs a 6502 BIT test which sets the N Flag equal to Bit 7. Until the Start bit takes PB7 low, the BMI test forces the testing to continue. When the Start bit arrives, the half-bit delay is called to be sure the input is still low. This test provides noise rejection only. If the line is still low (valid start bit), INBIT calls a one-bit delay. This allows time for the first data bit to arrive and settle. Next, the incoming data is captured and a test for eight bits received is made. The loop is executed eight times, until SAVX becomes zero.

Incoming data appears on PB7. The LDA BPORT reads all eight bits, but Bit 7 is stripped off by shifting the bit into the Carry Bit. Then the Carry Bit is shifted into the location named WORD. After eight bits have been received, DUMP saves the assembled data byte into the next sequential buffer location and increments the pointer. When the Y Index "rolls over" from \$FF to \$00, the location PAGE, which is the high order byte of the buffer address, is incremented. This way, the transferred data can be as large as necessary up to \$8000 (32768) bytes. Special Note: The listing was assembled at \$3000 to avoid destroying the Editor package at \$C000. In normal use, this program is intended to reside at \$C000, thus providing \$8000 bytes of data buffer. Otherwise, only \$1000 (4096) bytes of buffer is available with Listing 2.

SKIP makes sure the CIA Interrupt Status bit is clear before a full-bit delay is called. After the delay, control returns to FIX to test for the next Start bit. The delay routine is called once (enter at HLFBIT) for a one-half bit delay, or twice (enter at FULBIT) for a one bit delay. The timer is started and the Timer A Interrupt Status Bit (Bit 0 in the CIA Interrupt Register) is repeatedly polled. When this bit goes high, the timer has timed out, so the RTS causes normal program operation to resume. There is a special caution regarding use of the CIA timers. Timer A can be operated in the free-running mode to allow generation of arbitrary waveforms for special purposes. The one-shot mode, as demonstrated here, should always be used for normal timing. This mode selection is shown controlled by the assignments for TMRNIT and TMROFF.

This program is intended to be loaded and operated under control of HESMON 64 or another debug monitor; the RESTORE key forces a stop. CoCo can send data using a simple BASIC program. Data integrity can be verified by using another BASIC program to checksum the data in CoCo

```
Listing 1
                   5 REM DATA TRANSFER IN BINARY
                  1Ø FOR X=49152 TO 49168
0
                  2Ø HØ=PEEK(X)
                  3Ø PRINT#-2,CHR$(HØ);
                  4Ø NEXT
0
                  42 REM CHECKSUM COMPUTATION
                  45 AT=1:LM=65536
                  5Ø FOR X=49152 TO 49168
                  6Ø A=PEEK(X)
0
                  7Ø AT=AT+A
                  8Ø IF AT> LM THEN AT=AT-LM
                  90 NEXT X
                  100 PRINT''CHECKSUM = ''.AT
0
     Listing 2
                    ; THIS PROGRAM IMPLEMENTS A TTL
0
                    ; LEVEL SERIAL INPUT PORT ON THE
                      COMMODORE 64 COMPUTER WHICH WILL
                    ; INPUT AND STORE BINARY DATA
0
                     ; EQUATES
     DDØØ
                     APORT
                               EQU $DDØØ
                                             ; CIA REGISTERS
     DDØ1
                     BPORT
                               EQU APORT+1
     DDØ2
                               EQU APORT+2
                     ADDR
     DDØ3
                     BDDR
                               EQU APORT+3
     DDØ4
                     TMRALO
                               EQU APORT+4
     DDØ5
                     TMRAHI
                               EQU APORT+5
     DDØ6
                     TMRBLO
                               EQU APORT+6
```

and the same program to checksum the data in C-64 memory. A more "automatic" data transfer would require far more programming, so this simpler approach is a good compromise.

The BASIC program, Listing 1, will transfer binary data between a CoCo and a C-64 and checksum the data at both ends. Lines 10-40 send the data across to the C-64 which receives the data with the program in Listing 2. Compute the CoCo memory checksum before or after sending data by typing "GOTO 45". Lines 45 100 of the same program, entered into the C-64, will compute the checksum after the transmission. Note that line 10 specifies addresses 49152-49168 [\$C000-\$C010], which happens to be the first 16 bytes of the expansion area Disk BASIC for CoCo if you have a disk). Obviously, this could have been any set of locations, as long as the C-64 buffer area is long enough. Note also that line 50 must specify the same addresses as line 10. The C-64 version must use the target addresses set up by the C-64 receive program.

- I recommend the following sequence for data transfers using these programs:
 - 1. Connect and test the interface.
- 2. If data is to be transferred for programming in an EPROM, use HESMON 64 to prepare the buffer area:

F2000 2FFF FF

This command fills 4096 locations (a full 2732 EPROM) with \$FF. Thus, if the code transferred is smaller than 4096 bytes, unused EPROM locations will remain undisturbed.

- 3. Set up the CoCo by entering the BASIC program. Compute the checksum now or later.
- 4. Start the receiving program in the C-64 (it will wait on data if the interface is connected) using:

G3000

- 5. Type RUN on CoCo.
- 6. When CoCo prints "BREAK IN 40", hit RESTORE on the C-64.
- 7. Save the data using this HESMON command: (disk assumed)

S''filename'' 08 2000 2FFF

8. Return to BASIC (C-64) with the HESMON command XC; enter the checksum program and compute the checksum. In case other than HESMON is used, it may be necessary to load the data from disk with an offset to avoid conflicts with BASIC. If the checksum is OK, you are free to program the EPROM.

MICRO"

						ľ
DDØ7	TMRBHI	EQU	APORT+7			
DDØD	CIA2IR	EQU	APORT+\$D			
DDØE	TMRACR		APORT+\$E			0
DDØF	TMRBCR		APORT+\$F			
DDpr		T. O	AI OI(I+pI			
	;	ma.				
444-	; CONSTAN					0
ØØØ9	TMRNIT		\$ Ø9		TIMER ON/ONE SHOT	-
øøø8	TMROFF	EQU	\$Ø8	;	TIMER OFF	
ØØ2C	BAUDLO		\$2 C		TIMER VALUE FOR	
ØØØ3	BAUDHI		\$Ø3		600 BAUD	0
777		T. C	ΨĐ	,	OPP DROD	9
	;					
d days	; BUFFERS					
ØØ7C	SAVA	EQU	\$ 7C			0
ØØ7E	SAVX	EQU	\$7E			9
ØØ7F	SAVY	EQU	\$7F			
ØØ8Ø	POINTR		\$8Ø	:	DATA BUFFER POINTER	
ØØ81	PAGE		POINTR+1		BUFFER HI BYTE	_
ØØ82	WORD					0
ששט∠		ΕŲU	POINTR+2	;	INPUT SCRATCH BYTE	
- 4 4 4	;					l
3000			\$3ØØØ			ا ہ
	; MAIN PRO	OGRA	M			0
3000 A9 08	NEW	T.DA	#TMROFF	:	INSURE TIMER OFF	
3002 8D ØE DD			TMRACR	,	11.001.011	
3005 A9 00					INIT DATA POINTER	
			#\$ØØ	,	INTI DATA PULNIEK	0
3007 85 80			POINTR	;	LOW BYTE	
3009 A8		TAY		;	AND INDEX POINTER	
300A A9 2C		LDA	#BAUDLO	;	SET TIMER FOR	
300C 8D 04 DD		STA	TMRALO		HALF-BIT TIME	0
300F A9 03			#BAUDHI	•		-
3Ø11 8D Ø5 DD			TMRAHI			
					THE DAME DOTHERD	
3Ø14 A9 2Ø					INIT DATA POINTER	0
3016 85 81					HI BYTE	۱
3Ø18 A9 Ø8	FIX		#Ø8	;	INIT BIT COUNTER	
3Ø1A 85 7E		STA	SAVX			
3Ø1C 78		SEI		:	KILL C64 INTERRUPTS	ا م
3Ø1D A9 ØØ					INIT INPUT	0
3Ø1F 85 82			WORD		SCRATCH PAD	
JULY 07 02	_	DIA	WOILD	,	SCRATCH FAD	
	;					_
	; INPUT LO					0
3Ø21 2C Ø1 DD	GET	BIT	BPORT		TEST FOR START BIT	
3Ø24 3Ø FB		BMI	GET	;	WAIT FOR IT	
3026 20 53 30		JSR	HLFBIT	:	FOUND IT	_
3029 2C 01 DD			BPORT		WAIT ONE-HALF BIT	0
302C DØ F3					FALSE START BIT?	
	TIMETO		CEI	,	CAMPLE MEYER DIE	
3Ø2E 2Ø 5Ø 3Ø	INBIT		FULBIT	;	SAMPLE NEXT BIT	
3Ø31 AD Ø1 DD			BPORT	;	READ PORT	0
3Ø34 ØA		ASL	A	;	GET INPUT DATA BIT	
3035 66 82		ROR	WORD	;	ROTATE INTO BUFFER	
3Ø37 C6 7E			SAVX	:	COUNT BIT AND	
3Ø39 FØ Ø3			DUMP	:	TEST FOR LAS	0
3Ø3B 4C 2E 3Ø		•	INBIT		GET MORE	
	עוואט		TUDE	,	CAUTE ACCEMENTED	
3Ø3E A5 82	DUMP				SAVE ASSEMBLED	
3040 91 80			(POINTR),Y		; DATA	0
3Ø42 C8		INY		;	BUMP POINTER	•
3043 DØ Ø2		BNE	SKIP	;	PAGE BOUNDARY?	
3045 E6 81			PAGE	:	INCREMENT PAGE BIT	
3Ø47 AD ØD DD	SKIP	T DA	CTACTE	:	CLEAR STATUS BIT	0
304A 20 50 30	~	מפד			WAIT FOR STOP BIT	~
		JUCIO	LOTOTI			
304D 4C 18 30		JMP	FIX	;	AND CONTINUE	
	;					0
	; POLLED ?					U
	FULBIT	JSR			TWICE FOR FULL BIT	
3050 20 53 30					START TIMER	
	HLFBIT			•		
3053 A9 Ø9	HLFBIT		TMRACR			0
3Ø53 A9 Ø9 3Ø55 8D ØE DD		STA	TMRACR		WATT FOR	0
3053 A9 09 3055 8D 0E DD 3058 AD 0D DD	HLFBIT TEST	STA LDA	CIA2IR		WAIT FOR	0
3053 A9 Ø9 3055 8D ØE DD 3058 AD ØD DD 305B 29 Ø1		STA LDA AND	CIA2IR #\$Ø1		WAIT FOR STATUS BIT	0
3053 A9 09 3055 8D 0E DD 3058 AD 0D DD 305B 29 01 305D F0 F9		STA LDA AND BEQ	CIA2IR #\$Ø1 TEST	;	STATUS BIT	
3053 A9 Ø9 3055 8D ØE DD 3058 AD ØD DD 305B 29 Ø1 305D FØ F9 305F 60		STA LDA AND BEQ RTS	CIA2IR #\$Ø1 TEST	;		0 0
3053 A9 09 3055 8D 0E DD 3058 AD 0D DD 305B 29 01 305D F0 F9		STA LDA AND BEQ	CIA2IR #\$Ø1 TEST	;	STATUS BIT	
3053 A9 Ø9 3055 8D ØE DD 3058 AD ØD DD 305B 29 Ø1 305D FØ F9 305F 60		STA LDA AND BEQ RTS	CIA2IR #\$Ø1 TEST	;	STATUS BIT	
3053 A9 Ø9 3055 8D ØE DD 3058 AD ØD DD 305B 29 Ø1 305D FØ F9 305F 60		STA LDA AND BEQ RTS	CIA2IR #\$Ø1 TEST	;	STATUS BIT	



HILISTER - A Study and Teaching Aid

(*Part 1*)



Move easily within your programs and highlight parts of text or listings to add emphasis, drama or clarity

by J. Morris Prosser

HiLister is a machine language program which may be called from either Applesoft or the monitor to invert one line at a time on the screen display, thus "highlighting" that line. In addition, an Applesoft program, a block of disassembled memory locations, a disk catalog (either drive), a memory dump (in both hex and ASCII), or almost anything else may be listed to the screen, after which one can jump to the beginning or end of the listing, move forward or backward by screen "pages", scroll either up or down, or step up or down one line at a time. Lines may be highlighted in this mode

HiLister began as a simple line inverter, to highlight lines on the screen while teaching a beginner's programming class. The instructor sat at the keyboard and used a separate monitor to show the class what was happening. In order to point out a particular line for discussion, he had to get up and point to it on the monitor. HiLister made it possible for him to remain seated, pointing out the line by causing it to be printed in inverse characters.

At that point, it was possible to highlight only those lines already on the screen display, so I added a list function to allow an entire Applesoft program to be examined with the highlighter. When the list function is in effect, if the highlight is moved to the bottom of the screen and an attempt is made to move it further, the screen scrolls up one line, and the bottom line is again highlighted. A similar action occurs at the top of the screen. The additional functions of jumping to beginning or end, paging, scrolling, and stepping are icing on the cake.

Once the Applesoft list function was in operation, I found that the program was very helpful for studying program listings at any time, rather than being useful only in a teaching situation. It was at this point that I decided to add a list function for machine language disassembly listings.

It also appeared that some other functions might be useful, so I added a command to dump a block of memory to the screen in hex and ASCII and another to allow the listing of long catalogs from either drive. The final

step was to add a method of listing other things I had perhaps overlooked.

HiLister is initialized by "BRUN HILISTER" or by "BLOAD HILISTER" and "CALL 3276 8". The initialization consists of setting the ampersand (&) and ctrl-Y vectors. The program is then accessed by entering ctrl-Y from the monitor (for the highlighter function only), or "&" from Applesoft (for all functions). "&LIST" causes the Applesoft program in memory to be listed in its entirety to both the screen and to a buffer area used by HiLister for the list function. Commas or hyphens and beginning and ending addresses may be used as in the standard Applesoft LIST command to obtain a partial listing.

To get a listing of a machine language program or other disassembled machine code, the command is an ampersand followed by a dollar sign and the start address (in hex) of the memory to be disassembled. Thus, "&\$8000" would print 256 lines of disassembled code starting at \$8000 (a partial listing of HiLister, for example). "&\$8000L" would produce the same result. Addition of a plus sign

after the address (for example, &\$8000) causes 512 lines of disassembled code to be listed. Note that "&\$8000L" would produce only 256 lines of code, since the program looks for only one character following the address.

To obtain a memory dump, the command is "&\$" followed by the range of memory to be dumped. For example, "&\$8000.84FF" would dump the range \$8000 to \$84FF, just as in the normal monitor command.

Disk catalogs are listed by using the command "\$C" for the default drive, or "&C1" or "&C2" to specify the drive.

To list anything else to the program buffer, use "&B" to initialize the output detour and the buffer, then list or print whatever is desired, then enter the HiLister program with "&E".

While the program is listing to the screen and buffer, ctrl-S and ctrl-C may be used to pause and end the listing, respectively, just as with the normal Applesoft LIST command. Note, however, that ctrl-C is not effective in a catalog listing.

If a program is too long to be completely listed to the buffer, the bell sounds and a message is displayed offering the options of using the part of the program already listed or leaving the HiLister program and re-entering it with only an elected part of the program to be listed. The buffer normally starts at \$4000, so an Applesoft program of more than 57 sectors would overwrite it. The Applesoft program length is checked by HiLister, however, and if necessary the start of the buffer is moved up in memory. In this event, of course, the buffer size is decreased and it will not hold as long a listing.

Applesoft programs of this length or longer may be too long for complete listing. For very long programs it is better to load the program, delete those lines not required for study, and then invoke the list function of HiLister. This will provide for a larger buffer and make the maximum number of lines available for study. Note that an Applesoft program longer than 120 sectors will overwrite the HiLister program itself. In this case it is possible to load the Applesoft program, delete part of it, then BRUN HILISTER.

The assembly listing for HiLister is quite long and is liberally commented, so only a brief description of how the program works will be provided here (Listing 1).

Upon first running the program, the ampersand and ctrl-Y vectors are set up and control is returned to BASIC. Upon entry to the main program, the program determines whether the highlighter alone is requested, or one of the other options is desired. If a listing is required, the program sets the output vector (subroutine OUTSET) to cause all output to pass through the program, so that it may be listed to the buffer as well as to the screen. It also fills the buffer with carriage returns so there will be no extraneous material at the end of the listing. If an Applesoft listing, the program goes to a portion of code which replaces the standard Applesoft "LIST" routine. The standard routine could not be used, since it does not normally return to the caller and, in addition, some special formatting was required.

If a disassembly listing is requested, the program determines the start address for the listing, then checks to see whether 256 or 512 lines should be listed. This is done in subroutine "MEMLST," which also checks to see whether "DEF" is part of the address entered. The reason this is needed is that Applesoft would interpret this as

the beginning of a "DEF FN" command, and so would replace it with the token for "DEF" (\$B8). If this happens, the "DEF" address must be restored so the listing will start at the correct address. While this situation will seldom arise, I thought it should be covered.

MEMLST also checks to determine if a memory dump is desired rather than a disassembly listing. It does this by looking for a period between addresses.

When all is well, if a disassembly listing is requested, the program goes to "MONLIST," which replaces the monitor "LIST2" subroutine. It is called twice if 512 lines are to be listed.

If a memory dump is required, the program jumps to "DUMP," which performs a function similar to the "XAM" function in the monitor, with the added feature that the hex code is converted to ASCII and shown at the same time. Control [non-printing] characters are shown as blanks.

If a catalog listing has been requested, the program jumps to "CTLG," which first removes the pause from the DOS CATALOG routine, then calls it. When the catalog

			<u></u>		
Listing 1					
Ø8ØØ	* HILIS	STER1	(REV	Ø4/16/84)	0
Ø8ØØ	*				•
Ø8ØØ	* Wi	ritten by			
Ø8ØØ	*	•			
Ø8ØØ	* J. Mo	orris Pros	ser		0
Ø8ØØ	*				
ØØØ6	LINE	EQU \$Ø6		;LINE NUMBER FOR HIGHLIGHTER	
ØØØ7	TEMPY	EQU \$Ø7		; TEMPORARY STORAGE FOR Y REGISTER	_
ØØØ9	TEMPX	EQU \$Ø9		; TEMPORARY STORAGE FOR X REGISTER	9
ØØ19	FLAG	EQU \$19		; FLAG FOR USE BY HIGHLIGHTER	
ØØ1A	LSTFLG	EQU \$1A		; A/S LIST FLAG	
ØØ1B	COUNT	EQU \$1B		; COUNTER	0
ØØ1C	PLUSFLG	EQU \$1C		;FLAG FOR EXTENDED MONITOR LIST	
ØØ1D	CATFLG	EQU \$1D		; FLAG FOR CATALOG LISTING	
ØØ1E	DIRFLG	EQU \$1E		;FLAG FOR STEP DIRECTION	
ØØ24	CH	EQU \$24		; CURSOR HORIZONTAL POSITION	0
ØØ25	CV	EQU \$25		;CURSOR VERTICAL POSITION	
ØØ31	MODE	EQU \$31		; MODE OF MONITOR COMMAND	
ØØ36	CSWL	EQU \$36		; CHARACTER OUTPUT VECTOR	0
ØØ3A	PCL	EQU \$3A		;PROGRAM COUNTER	•
. ØØ3C	A1L	EQU \$3C		; GENERAL PURPOSE COUNTER	
ØØ3E	A2L	EQU \$3E		;GENERAL PURPOSE COUNTER	
ØØ4Ø	A3L	EQU \$4Ø		; GENERAL PURPOSE COUNTER	0
ØØ42	A4L	EQU \$42		;GENERAL PURPOSE COUNTER	
ØØ5Ø	LINNUM	EQU \$5Ø		;GENERAL PURPOSE 16-BIT REGISTER	
ØØ85	FORPNT	EQU \$85		;GENERAL POINTER	0
ØØ9B	LOWTR	EQU \$9B		; GENERAL PURPOSE REGISTER	9
ØØ9 D	DSCTMP	EQU \$9D		; TEMP STRING DESCRIPTOR	
ØØB1	CHRGET	EQU \$B1		;GET CHAR., INCREMENT POINTER	
ØØB7	CHRGOT	EQU \$B7		;GET CHAR., NO INCREMENT	0
ØØF9	MEMFLG	EQU \$F9		;MONITOR LIST FLAG	_
ØØFA	BUFST	EQU \$FA		; BEGINNING OF LIST BUFFER	

		******	***************************************	
Listing 1 (continue	2d)			
ØØFC	SCRST	FOII	\$FC	; BEGINNING OF SCREEN BUFFER
ØØFE	LSTEND		\$FE	;END OF LISTING
0200	IN	=	\$200	:Input buffer
Ø3DØ	BASIC	=	\$3DØ	;Soft entry to BASIC
Ø3EA	TELLDOS	=	\$3EA	;DOS routine to get change in
◎ Ø3F5	AMP	=	\$3F5	;Ampersand vector
Ø3F8	CTRLY	=	\$3F8	;Control-Y vector
4000	BUFLE	=	\$4000	;Buffer low end
COMM	KBD	=	\$CØØØ	;Keyboard input address
● CØ1Ø	KBDSTRB	=	\$CØ1Ø	;Keyboard strobe
D61A	FNDLIN	=	\$D61A	;Find mem. loc. of line in LINNUM
DAØC	LINGET	=	\$DAØC	;Get line no. from input buffer
♠ DAFB	CRDO	=	\$DAFB	Print carriage return
DB5C	OUTDO	=	\$DB5C	Print character in accumulator
DEC9	SYNERR	=	\$DEC9	;Syntax error routine
ED24	LINPRT	=	\$ED24	;Print line number
F8DØ	INSTDSP	=	\$F8DØ	;Print disassembled instruction
F94Ø	PRNTYX	=	\$F94Ø	;Print Y and X registers
F953	PCADJ	=	\$F953	;Adjust program counter
● FBC1	BASCALC	=	\$FBC1	;Calc. start addr. of screen line
FC22	VTAB	=	\$FC22	;Set cursor vertical position
FC58	HOME	=	\$FC58	;Clear screen - home cursor
FC9C	CLREOL	=	\$FC9C	;Clear to end of line
● FCBA	NXTA1	=	\$FCBA	;Increment pointer A1L,A1H
FDDA	PRBYTE	=	\$FDDA	;Print accumulator as hex
				byte
FDED 63	COUT	=	\$FDED	;Print to output device
● _{FDFØ}	COUT1	=	\$FDFØ	;Print to screen
FE2C	MOVE	=	\$FE2C	;Move memory block
FF3A	BELL	=	\$FF3A	;Sound bell
FFA7	GETNUM	=	\$FFA7	;Get hex bytes from input buffer
FFC7	ZMODE	=	\$FFC7	;Set MODE for GETNUM
8 ø øø		ORG	\$ 8ØØØ	•
8øøø		NOG		
⊗ 8ØØØ	*			
8 ø øø		perse	and and ct	rl-Y vectors
8ØØØ	*			
8000 A9 4C	START		#\$4C	
כש לז עם בששט		STA		
8ØØ5 8D F8 Ø3			CTRLY	
8ØØ8 A9 8Ø			/BEGIN	
● 800A 8D F6 03			AMP+1	
8ØØD 8D F9 Ø3			CTRLY+1	
8Ø1Ø A9 1B				
			#BEGIN	
8Ø12 8D F7.Ø3		STA	AMP+2	
8Ø12 8D F7 Ø3 ●8Ø15 8D FA Ø3		STA STA	AMP+2 CTRLY+2	
8Ø12 8D F7 Ø3 ● 8Ø15 8D FA Ø3 8Ø18 4C DØ Ø3	DECTN	STA STA JMP	AMP+2 CTRLY+2 BASIC	.Clean flogs
8Ø12 8D F7 Ø3 ● 8Ø15 8D FA Ø3 8Ø18 4C DØ Ø3 8Ø1B A2 ØØ	BEGIN	STA STA JMP LDX	AMP+2 CTRLY+2 BASIC #Ø	;Clear flags
8Ø12 8D F7 Ø3 8Ø15 8D FA Ø3 8Ø18 4C DØ Ø3 8Ø1B A2 ØØ 8Ø1D 86 1D	BEGIN	STA STA JMP LDX STX	AMP+2 CTRLY+2 BASIC #Ø CATFLG	;Clear flags
8012 8D F7 03 8015 8D FA 03 8018 4C D0 03 801B A2 00 801D 86 1D 801F 86 1A	BEGIN	STA STA JMP LDX STX STX	AMP+2 CTRLY+2 BASIC #Ø CATFLG LSTFLG	;Clear flags
8012 8D F7 03 8015 8D FA 03 8018 4C D0 03 801B A2 00 801D 86 1D 801F 86 1A 8021 86 F9	BEGIN	STA STA JMP LDX STX STX STX	AMP+2 CTRLY+2 BASIC #Ø CATFLG LSTFLG MEMFLG	;Clear flags
8012 8D F7 03 8015 8D FA 03 8018 4C DØ 03 801B A2 00 801D 86 1D 801F 86 1A 8021 86 F9 8023 86 1C	BEGIN	STA STA JMP LDX STX STX STX STX	AMP+2 CTRLY+2 BASIC #Ø CATFLG LSTFLG MEMFLG PLUSFLG	;Clear flags
8012 8D F7 03 8015 8D FA 03 8018 4C DØ 03 801B A2 00 801D 86 1D 801F 86 1A 8021 86 F9 8023 86 1C 8025 86 1E		STA STA JMP LDX STX STX STX STX STX	AMP+2 CTRLY+2 BASIC #Ø CATFLG LSTFLG MEMFLG PLUSFLG DIRFLG	
8012 8D F7 03 8015 8D FA 03 8018 4C DØ 03 801B A2 00 801D 86 1D 801F 86 1A 8021 86 F9 8023 86 1C 8027 C9 00	BEGIN HILITER	STA STA JMP LDX STX STX STX STX STX STX	AMP+2 CTRLY+2 BASIC #Ø CATFLG LSTFLG MEMFLG PLUSFLG DIRFLG #Ø	;Other command
8012 8D F7 03 8015 8D FA 03 8018 4C DØ 03 801B A2 00 801D 86 1D 801F 86 1A 8021 86 F9 8023 86 1C 8027 C9 00 8029 FØ 03		STA STA JMP LDX STX STX STX STX STX CMP BFL	AMP+2 CTRLY+2 BASIC #Ø CATFLG LSTFLG MEMFLG PLUSFLG DIRFLG #Ø HILITER1	
8012 8D F7 03 8015 8D FA 03 8018 4C DØ 03 801B A2 00 801D 86 1D 801F 86 1A 8021 86 F9 8023 86 1C 8027 C9 00 8029 FØ 03 802B 4C CF 80		STA STA JMP LDX STX STX STX STX STX CMP BFL	AMP+2 CTRLY+2 BASIC #Ø CATFLG LSTFLG MEMFLG PLUSFLG DIRFLG #Ø	;Other command
8012 8D F7 03 8015 8D FA 03 8018 4C DØ 03 801B A2 00 801D 86 1D 801F 86 1A 8021 86 F9 8023 86 1C 8027 C9 00 8029 FØ 03 802B 4C CF 80 802E	HILITER	STA JMP LDX STX STX STX STX CMP BFL JMP	AMP+2 CTRLY+2 BASIC #Ø CATFLG LSTFLG MEMFLG PLUSFLG DIRFLG #Ø HILITER1 LISTER	;Other command ;No - HILITER
8012 8D F7 03 8015 8D FA 03 8018 4C DØ 03 801B A2 00 801D 86 1D 801F 86 1A 8021 86 F9 8023 86 1C 8027 C9 00 8029 FØ 03 802B 4C CF 80 802E 802E A2 00	HILITER	STA JMP LDX STX STX STX STX STX CMP BFL JMP	AMP+2 CTRLY+2 BASIC #Ø CATFLG LSTFLG MEMFLG PLUSFLG DIRFLG #Ø HILITER1 LISTER	;Other command
8012 8D F7 03 8015 8D FA 03 8018 4C DØ 03 801B A2 00 801D 86 1D 801F 86 1A 8021 86 F9 8023 86 1C 8025 86 1E 8027 C9 00 8029 F0 03 802B 4C CF 80 802E 802E A2 00 8030 86 19	HILITER	STA STA JMP LDX STX STX STX STX CMP BFL JMP	AMP+2 CTRLY+2 BASIC #Ø CATFLG LSTFLG MEMFLG PLUSFLG DIRFLG #Ø HILITER1 LISTER #Ø FLAG	;Other command ;No - HILITER
8012 8D F7 03 8015 8D FA 03 8018 4C DØ 03 801B A2 00 801D 86 1D 801F 86 1A 8021 86 F9 8023 86 1C 8027 C9 00 8029 FØ 03 8028 4C CF 80 8026 A2 00 8030 86 19 8032 86 06	HILITER	STA STA JMP LDX STX STX STX STX STX CMP BFL JMP LDX STX STX	AMP+2 CTRLY+2 BASIC #Ø CATFLG LSTFLG MEMFLG PLUSFLG DIRFLG #Ø HILITER1 LISTER #Ø FLAG LINE	;Other command;No HILITER;Set FLAG and LINE to zero
8012 8D F7 03 8015 8D FA 03 8018 4C DØ 03 801B A2 00 801D 86 1D 801F 86 1A 8021 86 F9 8023 86 1C 8027 C9 00 8029 FØ 03 8028 4C CF 80 8026 A2 00 8030 86 19 8032 86 06 8034 FØ 5B	HILITER * HILITER1	STA STA JMP LDX STX STX STX STX CMP BFL JMP LDX STX STX STX	AMP+2 CTRLY+2 BASIC #Ø CATFLG LSTFLG MEMFLG PLUSFLG DIRFLG #Ø HILITER1 LISTER #Ø FLAG LINE NXTLN	;Other command;No - HILITER ;Set FLAG and LINE to zero ;Branch always
8012 8D F7 03 8015 8D FA 03 8018 4C DØ 03 801B A2 00 801D 86 1D 801F 86 1A 8021 86 F9 8023 86 1C 8027 C9 00 8029 FØ 03 8028 4C CF 80 8028 4C CF 80 8028 4C CF 80 8030 86 19 8030 86 19 8032 86 06 8034 FØ 5B 8036 2C 00 C0	HILITER	STA STA JMP LDX STX STX STX STX STX STX STX STX BFL JMP	AMP+2 CTRLY+2 BASIC #Ø CATFLG LSTFLG MEMFLG PLUSFLG DIRFLG #Ø HILITER1 LISTER #Ø FLAG LINE NXTLN KBD	;Other command;No - HILITER ;Set FLAG and LINE to zero ;Branch always;Check keyboard
8012 8D F7 03 8015 8D FA 03 8018 4C DØ 03 801B A2 0Ø 801D 86 1D 801F 86 1A 8021 86 F9 8023 86 1C 8027 C9 0Ø 8029 FØ 03 8028 4C CF 80 8028 4C CF 80 8030 86 19 8030 86 19 8032 86 06 8034 FØ 5B 8036 2C 0Ø CØ 8039 10 FB	HILITER * HILITER1	STA STA JMP LDX STX STX STX STX CMP BFL JMP LDX STX STX STX BFL BIT BPL	AMP+2 CTRLY+2 BASIC #Ø CATFLG LSTFLG MEMFLG PLUSFLG DIRFLG #Ø HILITER1 LISTER #Ø FLAG LINE NXTLN KBD KEYCHK	;Other command ;No - HILITER ;Set FLAG and LINE to zero ;Branch always ;Check keyboard ;Key not pressed
8012 8D F7 03 8015 8D FA 03 8018 4C DØ 03 801B A2 00 801D 86 1D 801F 86 1A 8021 86 F9 8023 86 1C 8027 C9 00 8029 FØ 03 8028 4C CF 80 8028 4C CF 80 8028 4C CF 80 8030 86 19 8030 86 19 8031 86 06 8034 FØ 5B 8036 2C 00 C0 8039 10 FB 8038 AD 00 C0	HILITER * HILITER1	STA STA JMP LDX STX STX STX STX STX STX STX STX BFL JMP LDX STX BFL BDL LDA	AMP+2 CTRLY+2 BASIC #Ø CATFLG LSTFLG MEMFLG PLUSFLG DIRFLG #Ø HILITER1 LISTER #Ø FLAG LINE NXTLN KBD KEYCHK KBD	;Other command ;No - HILITER ;Set FLAG and LINE to zero ;Branch always ;Check keyboard ;Key not pressed ;Key pressed - get it
8012 8D F7 03 8015 8D FA 03 8018 4C DØ 03 801B A2 0Ø 801D 86 1D 801F 86 1A 8021 86 F9 8023 86 1C 8027 C9 0Ø 8029 FØ 03 8028 4C CF 80 8028 4C CF 80 8028 4C CF 80 8030 86 19 8030 86 19 8031 86 19 8032 86 06 8034 FØ 5B 8036 2C 0Ø CØ 8039 1Ø FB 8038 AD 0Ø CØ 8038 2C 10 CØ	HILITER * HILITER1	STA JMP LDX STX STX STX STX STX STX STX BFL JMP LDX STX BFL LDA BIT	AMP+2 CTRLY+2 BASIC #Ø CATFIG LSTFIG MEMFLG PLUSFLG DIRFLG #Ø HILITER1 LISTER #Ø FLAG LINE NXTLN KBD KEYCHK KBD KBDSTRB	;Other command ;No - HILITER ;Set FLAG and LINE to zero ;Branch always ;Check keyboard ;Key not pressed ;Key pressed - get it ;Reset keyboard strobe
8012 8D F7 03 8015 8D FA 03 8018 4C DØ 03 801B A2 0Ø 801D 86 1D 801F 86 1A 8021 86 F9 8023 86 1C 8027 C9 0Ø 8029 FØ 03 8028 4C CF 80 8028 4C CF 80 8028 4C CF 80 8030 86 19 8030 86 19 8031 86 19 8032 86 06 8034 FØ 5B 8036 2C 0Ø CØ 8039 1Ø FB 8038 AD 0Ø CØ 8038 2C 1Ø CØ 8041 C9 9B	HILITER * HILITER1	STA JMP LDX STX STX STX STX STX STX STX BFL JMP LDX STX BFL LDA BIT CMP	AMP+2 CTRLY+2 BASIC #Ø CATFIG LSTFIG MEMFLG PLUSFLG DIRFLG #Ø HILITER1 LISTER #Ø FLAG LINE NXTLN KBD KEYCHK KBD KBDSTRB #\$9B	;Other command; No - HILITER ;Set FLAG and LINE to zero ;Branch always; Check keyboard; Key not pressed; Key pressed - get it; Reset keyboard strobe; Is it 'ESC'
8012 8D F7 03 8015 8D FA 03 8018 4C DØ 03 801B A2 00 801D 86 1D 801F 86 1A 8021 86 F9 8023 86 1C 8025 86 1E 8027 C9 00 8029 F0 03 8028 4C CF 80 8028 A2 00 8032 86 19 8032 86 06 8034 F0 5B 8036 80 06 8037 10 FB 8038 AD 00 C0 8039 D0 C0 8039 D0 C0 8039 D0 C0 8031 C9 9B 8041 C9 9B 8043 D0 05	HILITER * HILITER1	STA A JMP LDX STX STX STX STX STX STX STX BFL JMP LDX STX BFL LDA BIT CMP BTR	AMP+2 CTRLY+2 BASIC #Ø CATFIG LSTFIG MEMFLG PLUSFLG DIRFLG #Ø HILITER1 LISTER #Ø FLAG LINE NXTLN KBD KEYCHK KBD KBDSTRB #\$9B NOTESC	;Other command; No - HILITER ;Set FLAG and LINE to zero ;Branch always; Check keyboard; Key not pressed; Key pressed - get it; Reset keyboard strobe; Is it 'ESC'; No - branch
8012 8D F7 03 8015 8D FA 03 8018 4C DØ 03 801B A2 0Ø 801D 86 1D 801F 86 1A 8021 86 F9 8023 86 1C 8027 C9 0Ø 8029 FØ 03 8028 4C CF 80 8028 4C CF 80 8030 86 19 8030 86 19 8031 86 19 8032 86 06 8034 FØ 5B 8036 2C 0Ø CØ 8039 1Ø FB 8036 2C 0Ø CØ 8039 1Ø FB 8038 AD 0Ø CØ 8041 C9 9B 8043 DØ 05 8045 85 19	HILITER * HILITER1	STA A JMP LDX STX STX STX STX STX STX STX STX BFL JMP LDX STX BFL LDA BIT CMP BTR STA	AMP+2 CTRLY+2 BASIC #Ø CATFIG LSTFIG MEMFLG PLUSFLG DIRFLG #Ø HILITER1 LISTER #Ø FLAG LINE NXTLN KBD KEYCHK KBD KBDSTRB #\$9B NOTESC FLAG	;Other command; No - HILITER ;Set FLAG and LINE to zero ;Branch always; Check keyboard; Key not pressed; Key pressed - get it; Reset keyboard strobe; Is it 'ESC'; No - branch; Yes - set FLAG
8012 8D F7 03 8015 8D FA 03 8018 4C DØ 03 801B A2 00 801D 86 1D 801F 86 1A 8021 86 F9 8023 86 1C 8025 86 1E 8027 C9 00 8029 F0 03 8028 4C CF 80 8028 A2 00 8032 86 19 8032 86 06 8034 F0 5B 8036 80 06 8037 10 FB 8038 AD 00 C0 8039 D0 C0 8039 D0 C0 8039 D0 C0 8031 C9 9B 8041 C9 9B 8043 D0 05	HILITER * HILITER1	STA JMP LDX STX STX STX STX STX STX STX STX BFL JMP LDX STX BFL LDA BIT CMP BTR STA JMP	AMP+2 CTRLY+2 BASIC #Ø CATFIG LSTFIG MEMFLG PLUSFLG DIRFLG #Ø HILITER1 LISTER #Ø FLAG LINE NXTLN KBD KEYCHK KBD KBDSTRB #\$9B NOTESC	;Other command;No - HILITER ;Set FLAG and LINE to zero ;Branch always;Check keyboard;Key not pressed;Key pressed - get it;Reset keyboard strobe;Is it 'ESC';No - branch

listing is complete, the program restores the pause to DOS.

When listing is completed, the program pages back one screenful and sets the address at that point as the start of the screen buffer and as the address of the end of the listing. It then reprints this screen, sounds the bell, and prints a "LISTING COMPLETED" message.

The operation of the jumps to beginning and end of the listing is fairly obvious - simply a matter of setting the start of the screen buffer to the start of the listing buffer or the end address of the listing, as mentioned above.

The paging and scrolling are based on checking the buffer for the next previous or next following carriage return. For paging, 23 returns are counted before the next screen is printed, while for scrolling the screen is reprinted after each return is found, and then the next one is searched for.

Stepping one line at a time is accomplished by use of the space bar. The program checks to see whether the last movement called for was forward or backward (by looking at DIRFLG), then calls UPDO or DOWNDO, as appropriate. Default is UPDO, to scroll forward one line.

Commands available for manipulating the listing are:

- B jump to the beginning of the listing
- E jump to the end of the listing
- + or ; page forward (previous bottom line becomes top line)
- or = page back (previous top line becomes bottom line)

Right arrow - scroll up (stops on any keypress)

Left arrow - scroll down (stops on any keypress)

Space bar - step forward or backward one line.

& - calls highlighter

ESC - returns to BASIC

If the highlighter was requested, the top line of the screen is changed to the inverse of what it was; that is, normal characters become inverse, inverse characters become normal, and

flashing characters are unchanged. The program then looks for keyboard input. If a right arrow is pressed, the top line is restored and the next line is inverted. Further presses of the right arrow key cause the highlighting line to move on down the screen in this manner. The left arrow works the same way, except that it moves the "highlight" up the screen.

If the highlighter was called from any list routine, then when the highlighted line is at the bottom of the screen, further right arrows make the screen scroll up one line. Left arrows work in an analogous fashion when the highlighted line is at the top of the screen. The "ESC" key causes the currently highlighted line to be restored and the program returns to the caller.

One problem occurs with the highlighter if your listing includes lower case letters, in that the Apple II cannot show lower case letters in inverse. I thought the best thing to do in this event was to convert the lower case to upper case before highlighting. Naturally, when the highlighting is removed the material remains in all upper case. If the list function is in effect, the lower case will be restored as soon as the screen is reprinted for any reason, such as scrolling, paging, or stepping. Another way of handling this situation would be to show all characters except lower case in inverse, leaving the lower case characters normal. If you would like to try this option, get into the monitor with CALL-151, then type "809C:B0 16 EA EA" and press RETURN - after having BLOADed HILISTER, of course.

While the highlighter is in operation, all keys except "ESC" and the right and left arrows are ignored.

The assembly listing for the highlighter portion of the program is included here as Listing 1. This is a stand-alone program as shown, so it can be put to use immediately after keying it in. It should be saved as HiListerl. If you are entering the code without using an assembler, the command is:

BSAVE HILISTER1, A\$8000, L\$D0.

Part 2 of this article will present a listing of the remainder of the program, and will include instructions for adding it on. Some of the code in the first part of the listing appears redundant, but it is necessary for interfacing to the other parts of the program.

AICRO"

٦			4.		20		
ı	Listing 1 (c	ontii	nued)				
ı	04/0 Pd 4E			חשם	NOTE DE	. Wa haranah	
ı	8Ø4C DØ 1F				NOTLFT	;No - branch	0
١	8Ø4E A6 Ø6				LINE	;Yes - get LINE	
ı	8Ø5Ø CA			DEX	LFT1	; and decrement it	
ı	8051 10 14				TLIT	;Not top of screen	٥
١	8Ø53 E8			INX	T CORPT O	;Top of screen	١
ı	8Ø54 A5 1A				LSTFLG	;List in effect	
ı	8Ø56 Ø5 F9				MEMFLG		
ı	8Ø58 Ø5 1D				CATFLG	. We househ	0
١	8Ø5A FØ ØB				LFT1	;No - branch	
ı	8Ø5C 85 19	0.01			FLAG	;Yes	
ı	8Ø5E 2Ø 91				NXTLN	;Restore top line	
١	8061 20 83				DOWNDO	;Scroll down one line	0
ı	8Ø64 4C 91	8Ø			NXTLN	;Invert it	
ı	8Ø67 86 Ø9		LFT1		TEMPX		
ı	8Ø69 A2 ØØ			LDX	-		
ı	8Ø6B FØ 23				INVERT	;Put in highlight	0
ı	8Ø6D C9 95		NOTLFT		#\$95	;Is it right arrow	
ı	8Ø6F DØ C5				KEYCHK	;No - get next keypress	
ı	8Ø71 A6 Ø6				LINE	;Get line number	0
ı	8Ø73 E8			INX		; and increment it	٦
ı	8Ø74 EØ 18				#24	;Bottom line	
ı	8Ø76 DØ 14			BTR	RT1	;No - branch	- 1
ı	8Ø78 CA			DEX		;Yes	0
ı	8Ø79 A5 1A				LSTFLG	;List in effect	
ı	8Ø7B Ø5 F9			ORA	MEMFLG		
1	8Ø7D Ø5 1D			ORA	CATFLG		_
ı	8Ø7F FØ ØB			BFL	RT1	;No - branch	0
ı	8Ø81 85 19			STA	FLAG	;Yes	- 1
ı	8Ø83 2Ø 91	8Ø		JSR	NXTLN	;Restore line	
ı	8Ø86 2Ø 65			JSR	UPDO	;Scroll up one line	0
ı	8Ø89 4C 91	8Ø		JMP	NXTLN	;Invert it	۱۳
ı	8Ø8C 86 Ø9		RT1	STX	TEMPX	;Save line number	
١	8Ø8E A2 ØØ			LDX	#Ø		- 1
١	8Ø9Ø CA		INVERT	DEX			0
1	8Ø91 A5 Ø6		NXTLN	LDA	LINE	;Get line number	Ĭ
١	8Ø93 2Ø C1	FB		JSR	BASCALC	;Find address of left end	
ı	8Ø96 AØ 27			LDY	#39	;Start at end of line	_
l	8Ø98 B1 28		GETCH	LDA	(\$28),Y	;Get character	•
ı	8Ø9A C9 EØ			CMP	#\$EØ	;Is it lower case	
ı	8Ø9C 9Ø Ø2				NOTLC	;No - check further	
ı	8Ø9E 29 DF			AND	#\$DF	;Yes - make it upper case	_
١	8ØAØ C9 AØ		NOTLC	CMP	#\$AØ	;Is it normal	0
ı	8ØA2 9Ø Ø4				INV	;No - check further	
ı	8ØA4 29 3F			AND	#\$3F	;Yes - invert it	
۱	8ØA6 BØ ØC				DISP	;and display it	0
1	8ØA8 C9 4Ø		INV		#\$4Ø	;Is it flashing	-
ı	8ØAA BØ ØA			BGE	NXTCH	;Yes - don't change it	
١	8ØAC 69 8Ø			ADC	#\$8Ø	;Must be inverse - make it normal	
ı	8ØAE C9 AØ			CMP	#\$AØ	;Normal now	0
ı	8ØBØ BØ Ø2			BGE	DISP	;Yes - display it	
١	8ØB2 69 4Ø			ADC	#\$4Ø	;No - make it so	
1	8ØB4 91 28		DISP		(\$28),Y	;And print it	0
ı	8ØB6 88		NXTCH	DEY		;Get next character	
Ì	8ØB7 1Ø DF			BPL	GETCH	;Not done yet	
ı	8ØB9 A5 19			LDA	FLAG	;Is FLAG set	
ı	8ØBB FØ Ø5				CONT	;No - check X	0
1	8ØBD A2 ØØ			LDX		;Yes - clear it	
ı	8ØBF 86 19			STX	FLAG		
١	8ØC1 6Ø			RTS		;Done	_
	8ØC2 8A		CONT	TXA		; X=Ø	0
١	8ØC3 DØ Ø3				CONT1	;No - branch	
1	8ØC5 4C 36	80			KEYCHK	;Yes - get next command	
-	8ØC8 A5 Ø9	- 6	CONT1		TEMPX	;Invert next line	0
	8ØCA 85 Ø6				LINE		_
	8ØCC E8			INX			
	8ØCD FØ C2				NXTLN	;Branch always	
-	8ØCF		*			,	0
	8ØCF D8		LISTER	RTS			
	8ØDØ			ENI)		
	0,00						
							_

Super Simple Numeric Sort

by Robert L. Martin WB2KTG

Arrange a list in numerical order without a user supplied sorting program

Everyone, at some time, has had to take a list of numbers and arrange them in numerical order. The effort involved in accomplishing this task can, of course, be minimized by the use of a computer and a sorting program. Explained in this article is a sorting technique which doesn't require a user supplied program, but instead uses a built-in BASIC feature-automatic program statement sequencing.

All BASIC interpreters will allow non-sequential program statement entry. That is, the line numbers of statements need not be entered in any specific order. The BASIC interpreter will automatically LIST them in ascending order.

To arrange a list of numbers in ascending order, input each number followed by a period, asterisk, or some other non-numeric character. For non-integer values the decimal point will serve as the non-numeric character.

The Basic interpreter assumes that any digits input preceding a non-numeric character are line numbers. All alphanumeric characters entered following the first non-numeric character are assumed to be BASIC program statements. As long as no attempt is made to RUN the program, no error message will be given.

The example shown is the actual printed output from my Sharp PC-1500 pocket computer and CE-150 printer/plotter.

The use of this technique was discovered at work when I was given a

list of 140 repair orders to sequence. Each repair order number was four digits long. Fortunately, I had my PC-1500 with me, along with a bit of imagination. I hope this example of

using a computer's "hidden" talents will result in other non-standard techniques being developed to save the time and patience of the human interface.

Sample Printout From Sharp PC-1500/CE-150

29	29.
36.5	36.5
414	414.
13.2	13.2
5	5.
1019	1019.
7.25987	7.25987

a)List of Numbers

b) Numbers as Input to the Computer (note Decimal Points).

5:. 7:.25987 13:.2 29:. 36:.5 414:.

c)Output of Computer in Response to a "LLIST" command.

1019:.

FLOPPY DISKS SALE *\$1.19 ea. **Economy Model or Cadillac Quality**

LORAN_COMPUTER DISK. We have the lowest prices! LORAN_COMPUTER DISK.

*ECONOMY DISKS

Good quality 51/4" single sided double density with hub rings.

Bulk Pac

100 Qty.

\$1.19 ea.

Total Price

\$119.00

10 Qty.

1.39 ea.

Total Price

13.90

CADILLAC QUALITY

 Free replacement lifetime warranty Each disk certified Automatic dust remover

For those who want cadillac quality we have the Loran Floppy Disk. Used by professionals because they can rely on Loran Disks to store important data and programs without fear of loss! Each Loran disk is 100% certified (an exclusive process) plus each disk carries an exclusive FREE REPLACEMENT LIFETIME WARRANTY. With Loran disks you can have the peace of mind without the frustration of program loss after hours spent in program development.

100% CERTIFICATION TEST

Some floppy disk manufacturers only sample test on a batch basis the disks they sell, and then claim they are certified. Each Loran disk is individually checked so you will never experience data or program loss during your lifetime!

FREE REPLACEMENT LIFETIME WARRANTY

We are so sure of Loran Disks that we give you a free replacement warranty against failure to perform due to faulty materials or workmanship for as long as you own your Loran disk.

AUTOMATIC DUST REMOVER

Just like a record needle, disk drive heads must travel hundreds of miles over disk surfaces. Unlike other floppy disks the Loran smooth surface finish saves disk drive head wear during the life of the disk. (A rough surface will grind your disk drive head like sandpaper). The lint free automatic CLEANING LINER makes sure the disk-killers (dust & dirt) are being constantly cleaned while the disk is being operated. PLUS the Loran Disk has the highest probability rate of any other disk in the industry for storing and retaining data without loss for the life of the disk.

Loran is definitely the Cadillac disk in the world

Just to prove it even further, we are offering these super LOW INTRODUCTORY PRICES List \$4.99 ea. INTRODUCTORY SALE PRICE \$2.99 ea. (Box of 10 only) Total price \$29.90 \$3.33 ea. (3 quantity) Total price \$9.99

All disks come with hub rings and sleeves in an attractive package.

DISK DRIVE CLEANER \$19.95

Everyone needs a disk drive doctor

FACTS

- 60% of all drive downtime is directly related to poorly maintained drives.
- · Drives should be cleaned each week regardless of use.
- Drives are sensitive to smoke, dust and all micro particles.
- Systematic operator performed maintenance is the best way of ensuring error free use of your computer system.

The Cheetah disk drive cleaner can be used with single or double sided 54" disk drives. The Cheetah is an easy to use fast method of maintaining efficient floppy diskette drive operation.

The Cheetah cleaner comes with 2 disks and is packed in a protective plastic folder to prevent contamination. List \$29.95 / Sale \$19.95


Add \$10.00 for shipping, handling and insurance. Illinois residents please add 6% tax. Add \$20.00 for CANADA, PUERTO RICO, HAWAII orders. WE DO NOT EXPORT TO OTHER COUNTRIES.

Enclose Cashiers Check, Money Order or Personal Check. Allow 14 days for delivery, 2 to 7 days for phone orders, 1 day express mail! Canada orders must be in U.S. dollars. Visa - MasterCard - C.O.D. PROTECTO ENTERPRIZES INVELOVE OUR CUSTOMERSI

BOX 550, BARRINGTON, ILLINOIS 60010 Phone 312/382-5244 to order

DAISY WHEEL PRINTER SALE \$37900


COMSTAR 13"



computer printer

COMSTAR 13" "DAISY WHEEL" POWER TYPE PRINTER is typewriter friendly. It uses a simple drop in cassette ribbon. Just turn on the COMSTAR 13" for Crip executive quality correspondence at 18 CPS with a daisy wheel that prints 96 power type flawless characters, bidirectional. Designed for personal and business applications. COMSTAR 13" carriage accepts paper from letter to legal size, continuous computer paper or single sheets, you can set right and left margins, vertical and horizontal tabs. (Serial and parallel interface). LIST PRICE *599° SALE PRICE *379°

OLYMPIA "DAISY WHEEL" COMBINATION PRINTER/TYPEWRITER SALE \$48900



Olympia (world's finest)

THE Olympia COMPUTER PRINTER ELECTRONIC TYPEWRITER is the ultimate for Home, Office, and Word Processing. You get the best Electronic Typewriter made and used by the world's largest corporations (better than IBM Selectric) plus a Superb Executive Correspondence Computer Printer!! (Two machines in one!) Just flick the switch for the option you want to use. The extra large carriage allows 14%" printer paper width. It has cassette ribbon lift off correction. Baud rates, Jumper selectable 75 through 19,200 (parallel interface) LIST 37990 SALE 348900

• 15 DAY FREE TRIAL — 90 DAY FREE REPLACEMENT GUARANTEE

Add \$17.50 for shipping and handling!!

Enclose Cashiers Check, Money Order or Personal Check. Allow 14 days for delivery, 2 to 7 days for phone orders, 1 day express mail! Canada orders must be in U.S. dollars. VISA — MASTER CARD ACCEPTED. We ship C.O.D.

PROTECTO

ENTERPRIZES (WE LOVE OUR CUSTOMERS)

BOX 550, BARRINGTON, ILLINOIS 60010 Phone 312/382-5244 to order

SANYO MONITOR SALE!!



9" Data Monitor

- 80 Columns × 24 lines
- Green text display
- · Easy to read no eye strain
- Up front brightness control
- High resolution graphics
- Quick start no preheating
- Regulated power supply
- Attractive metal cabinet
- UL and FCC approved

• 15 Day Free Trial - 90 Day Immediate Replacement Warranty

9" Screen - Green Text Display

\$ 69.00

12" Screen - Green Text Display (anti-reflective screen)

\$ 99.00

12" Screen - Amber Text Display (anti-reflective screen)

\$ 99.00

12" Screen-Super 1000 Line Amber Text Display

\$129.00

14" Screen - Color Monitor (national brand)

\$249.00

Dispiay Monitors From Sanyo

With the need for computing power growing every day, Sanyo has stepped in to meet the demand with a whole new line of low cost, high quality data monitors. Designed for commercial and personal computer use. All models come with an array of features, including upfront brightness and contrast controls. The capacity 5×7 dot characters as the input is 24 lines of characters with up to 80 characters per line.

Equally important, all are built with Sanyo's commitment to technological excellence. In the world of Audio/Video, Sanyo is synonymous with reliability and performance. And Sanyo quality is reflected in our reputation. Unlike some suppliers, Sanyo designs, manufactures and tests virtually all the parts that go into our products, from cameras to stereos. That's an assurance not everybody can give you!



• LOWEST PRICES • 15 DAY FREE TRIAL • 90 DAY FREE REPLACEMENT WARRANTY
• BEST SERVICE IN U.S.A. • ONE DAY EXPRESS MAIL • OVER 500 PROGRAMS • FREE CATALOGS

Add \$10.00 for shipping, handling and insurance. Illinois residenta please add 6% tax. Add \$20.00 for CANADA, PUERTO RICO, HAWAII orders. WE DO NOT EXPORT TO OTHER COUNTRIES.

Enclose Cashiers Check, Money Order or Personal Check. Allow 14 days for delivery, 2 to 7 days for phone orders, 1 day express mail! Canada orders must be in U.S. dollars. Visa - MasterCard - C.O.D.

PROTECTO ENTERPRIZES (WE LOVE OUR CUSTOMERS)

BOX 550, BARRINGTON, ILLINOIS 60010 Phone 312/382-5244 to order



CMPRSS — Improved Applesoft Compression Program

Compress large programs easily and retain comments without overflowing Called Line Number Table

by Ian R. Humphreys

•					
)		V V			
		;**APPLESC)FT S	UBROUTIN	NES**
	D 61A	FNDLIN	EQU	\$D61A	;Find start of
	Ø8ØØ		-		givn Applesft ln
•	D697	STXTPT	EQU	\$D697	;Init TXTPTR for
	Ø8ØØ				;pass of program
	DAØC	LINGET	EQU	\$DAØC	;Convrt dec to hex
	DAFB	CRDO	EQU	\$DAFB	;Output carriage
•	Ø8ØØ				;return to screen
	DB3A	STROUT	EQU	\$DB3A	;Output a text
	Ø8ØØ				string to screen
)	ED24	LINPRT	EQU	\$ED24	;Print a hex line
	Ø8ØØ				;# in decimal
	ØØB7	CHRGOT	EQU	\$ØØB7	;Get curr byte
	Ø8ØØ				;w/o inc TXTPTR
•	ØØB1	CHRGET	EQU	\$ØØB1	; Inc TXTPTR and
	Ø8ØØ				get next byte
•					
		; ;**ZERO PA	ACE I	OCATIONS	c**
•		;^^ZERU FI	AGE I	OCHITOM	5
	adda	, MAXX	FOII	\$ØØØ7	;Loop ctrl for
	ØØØ7 Ø8ØØ	MAAA	-		INBUF to new prog
9	ØØØ5	OLDBEG		\$0005	;Ptr to last EOS
	Ø8ØØ	OLDDEG	E.C.	ψυνυν	;in orig prog
	nØØ4	LASTX	FOII	\$0004	;Ptr to last EOS
	08ØØ	TWDIV	740	₹₽₽₽ ¬	;in LINBUF
•	ØØØ3	NEWPTR+1	EOH	\$0003	, III BINDOI
	0002 0003	NEWPTR	•	\$ØØØ2	;Ptr to curr posn
	Ø8ØØ	IIDWI III	740	₩₽₽₽ ~	;in compr prog
		IFFLAG	FOU	\$0001	;Flag set when IF
•	F - F F		760	+ ppp-	-
•	ØØØ1	IFFLAG			round in line
)	ØØØ1 Ø8ØØ		EOU	\$0000	;found in line :Flag for errors
)	ØØØ1 Ø8ØØ ØØØØ	ERRORS	EQU	\$0000	;Flag for errors
	ØØØ1 Ø8ØØ ØØØØ Ø8ØØ	ERRORS			;Flag for errors ;during PASS #1
	ØØØ1 Ø8ØØ ØØØØ Ø8ØØ ØØØA			\$ØØØØ \$ØØØA	;Flag for errors ;during PASS #1 ;Last EOS token
)	ØØØ1 Ø8ØØ ØØØØ Ø8ØØ	ERRORS	EQU	\$ØØØA	;Flag for errors ;during PASS #1

Editor's Note: This program improves on programs previously done by: Barton M. Bauers (MICRO 52:89); Peter J.G. Meyer (MICRO 55:26).

Requirements:

Apple II or Apple II Plus; 48K and Applesoft BASIC in ROM

I had just finished writing a large, well-commented Applesoft program which was part of a major System I was working on. Unfortunately, when I came to test it, there was not enough room for its several large arrays and various string variables, and the program would not run. Coincidentally, on that same day, I purchased the September 1982 edition of MICRO magazine and was excited to see that it contained an article by Barton M. Bauers, giving a source listing of a machine language routine which compressed Applesoft programs. I eagerly hurried home, read the article and proceeded to key it into my Apple. I tested it on several small programs first and found that it seemed to work as described, so I set about running COMPRESS on my large program. Much to my dismay, COMPRESS aborted with ERROR #3 which meant that the Called Line Number Table had overflowed and so I couldn't use it! Not only does Barton Bauers' program

impose a limit of 256 called line numbers, but it doesn't even check for duplicates, so for anything but a very small program the table soon fills up and overflows. One of the major reasons for wanting to compress the Applesoft code cannot be accommodated! Also, Mr. Bauers' program contains an error. Applesoft allows a statement of the form:

100 NEXT I, J, K

Mr. Bauers' COMPRESS reduces this to:

100 NEXT

instead of:

100 NEXT : NEXT : NEXT

introducing a logic error into your Applesoft program!

Not being able to COMPRESS my large program, I resorted to removing all the REMs manually and finally, after several hours work, my program was small enough to run. Unfortunately, my source version has suffered as it now lacked comments and was consequently difficult to read. I resolved that I would redesign and rewrite the compression routine and I hereunder present my results. I have called my routine CMPRSS because it will compress an Applesoft program even more than COMPRESS does; it also uses less RAM space.

What CMPRSS does

CMPRSS compresses an Applesoft program by:

- (a) Concatenating as many statements as possible onto one line, thus eliminating many of the unreferenced line numbers
- (b) Removing the text of REM statements and where possible the REM itself (in some instances even when a REM line is referenced)*
- (c) Removing LETs
- (d) Removing the variable names from NEXT statements (correctly!)
- (e) Truncating variable names to a maximum of two characters*
- * Additional features not performed by COMPRESS.

;at beg of PASS#2 0051 LINNUM+1 EQU \$0051 0050 LINNUM EQU \$0050 ;Line num returnd 0800 ;by LINGET	
0050 LINNUM EQU \$0050 ;Line num returnd	
7,200	0
	•
9809 ;by LINGET 9067 TXTTAB EQU \$0067 ;Ptr to start of	
Ø8ØØ ;Applesoft prog	
ØØ6E EARS+1 EQU \$ØØ6E	•
006D EARS EQU \$006D ;Ptr to end of	
dodd	
9800 ;array space 906C ARS+1 EQU \$006C	_
	•
dodd	
, , -	
	0
<pre>ØØ69 LOMEM EQU \$0Ø69 ;Lomem pointer ØØ68</pre>	
0074 HIMEM+1 EQU \$0074	
<pre>ØØ73 HIMEM EQU \$ØØ73 ;Himem pointer ØØ9C LSTLIN+1 EQU \$ØØ9C</pre>	0
and the second of the second o	
7- 1- 1- 1- 1- 1- 1- 1- 1- 1- 1- 1- 1- 1-	
	_
ØØAF EPROG EQU \$ØØAF ;Ptr to end of	•
Ø8ØØ ;Applesoft prog	
ØØB9 TXTPTR+1 EQU \$ØØB9	
00B8 TXTPTR EQU \$00B8 ;Ptr to current	0
Ø8ØØ ;byte of program	•
ØØFD LN2+1 EQU \$ØØFD	
ØØFC LN2 EQU \$ØØFC ;Hex line number	
0800 ;of undefind line	0
ØØFB LN1+1 EQU \$ØØFB	
<pre>ØØFA LN1 EQU \$ØØFA ;Hex line number</pre>	
Ø8ØØ ;containing error	_
ØØF9 TOKEN EQU \$F9	•
Ø8ØØ ;GOSUB,THEN token	
00B8 OLDPTR EQU \$00B8 ;Ptr to curr posn	
Ø8ØØ ;in old program	0
ddDA MDMD DOW AddDA W I I DOG I I	
<pre>ØØFC TEMP EQU \$ØØFC ;Holds EOS byte</pre>	•
0800 ;until put into LSTEOS	
Ø8ØØ ;until put into LSTEOS	-
Ø8ØØ ;until put into LSTEOS	
<pre> ; intil put into LSTEOS ; ;**OTHER LOCATIONS**</pre>	
Ø8ØØ ;until put into LSTEOS ; ;**OTHER LOCATIONS** ;	
<pre> intil put into LSTEOS ; ;**OTHER LOCATIONS** ; DOSWS EQU \$03D0 ;DOS warmst vector ; ; ; ; ; ; ; ; ; ; ; ; ; ; ; ; ; ;</pre>	
<pre> intil put into LSTEOS ; ;**OTHER LOCATIONS** ; Ø3DØ DOSWS EQU \$Ø3DØ ;DOS warmst vector Ø3F5 BJP EQU \$Ø3F5 ;& vector </pre>	
; until put into LSTEOS ; **OTHER LOCATIONS** ; **OTHER LOCATIONS** ; DOSWS EQU \$03D0 ; DOS warmst vector 03F5 BJP EQU \$03F5 ; & vector 9500 LINBUF EQU \$9500 ; Base address of	
<pre> intil put into LSTEOS ; ;**OTHER LOCATIONS** ; Ø3DØ DOSWS EQU \$Ø3DØ ;DOS warmst vector Ø3F5 BJP EQU \$Ø3F5 ;& vector </pre>	
; until put into LSTEOS ; **OTHER LOCATIONS** ; **OTHER LOCATIONS** ; DOSWS EQU \$03D0 ; DOS warmst vector 03F5 BJP EQU \$03F5 ; & vector 9500 LINBUF EQU \$9500 ; Base address of	•
; until put into LSTEOS ; **OTHER LOCATIONS** ; **OTHER LOCATIONS** ; DOSWS EQU \$03D0 ; DOS warmst vector 03F5 BJP EQU \$03F5 ; & vector 9500 LINBUF EQU \$9500 ; Base address of	•
; ; **OTHER LOCATIONS** ; ; **OTHER LOCATIONS** ; DOSWS EQU \$Ø3DØ ; DOS warmst vector Ø3F5 BJP EQU \$Ø3F5 ; & vector 95ØØ LINBUF EQU \$95ØØ ; Base address of 98ØØ ; cmprssd ln buffer	•
; until put into LSTEOS ; **OTHER LOCATIONS** ; **OTHER LOCATIONS** ; DOSWS EQU \$03D0 ; DOS warmst vector 03F5 BJP EQU \$03F5 ; & vector 9500 LINBUF EQU \$9500 ; Base address of	•
; ; **OTHER LOCATIONS** ; ; **OTHER LOCATIONS** ; DOSWS EQU \$Ø3DØ ; DOS warmst vector Ø3F5 BJP EQU \$Ø3F5 ; & vector 95ØØ LINBUF EQU \$95ØØ ; Base address of 98ØØ ; cmprssd ln buffer	•
; **OTHER LOCATIONS** ; **OTHER LOCATIONS** ; DOSWS EQU \$03D0 ; DOS warmst vector 03F5 BJP EQU \$03F5 ; & vector 9500 LINBUF EQU \$9500 ; Base address of 0800 ; cmprssd ln buffer ; **CONSTANTS**	•
; **OTHER LOCATIONS** ; **OTHER LOCATIONS** ; DOSWS EQU \$Ø3DØ ; DOS warmst vector \$03F5 BJP EQU \$Ø3F5 ; & vector \$95ØØ LINBUF EQU \$95ØØ ; Base address of \$08ØØ ; cmprssd ln buffer \$15000; cmprssd ln buffer \$150000; cmprssd ln buffer \$1500000; cmprssd ln buffer \$1500000; cmprssd ln buffer \$1500000; cmprssd ln buffer \$150000000; cmprssd ln buffer \$1500000000000; cmprssd ln buffer \$15000000000000000000000000000000000000	•
; ; ; ; ; ; ; ; ; ; ; ; ;	•
; **OTHER LOCATIONS** ; **OTHER LOCATIONS** ; DOSWS EQU \$Ø3DØ ; DOS warmst vector Ø3F5 BJP EQU \$Ø3F5 ; & vector 95ØØ LINBUF EQU \$95ØØ ; Base address of Ø8ØØ ; cmprssd ln buffer ; **CONSTANTS** ; POØØØ ENDLIN EQU \$ØØ ; Non-referenced Ø8ØØ ; line token	•
; **OTHER LOCATIONS** ; **OTHER LOCATIONS** ; **OTHER LOCATIONS** ; DOSWS EQU \$Ø3DØ ; DOS warmst vector Ø3F5 BJP EQU \$Ø3F5 ; & vector 95ØØ LINBUF EQU \$95ØØ ; Base address of Ø8ØØ ; cmprssd ln buffer ; **CONSTANTS** ; #*CONSTANTS** ; Ine token Ø8ØØ ; line token Ø822 QUOTE EQU \$22 ; ASCII quote	•
	•

000000000000000000000000000000000000000	0	9000						\$9000	
0000000	•	9000 9002				START		#< BEGIN BJP1	;Establish &
		9005			כש			#> BEGIN	, vector
	0	9007			Ø3		_	BJP2	
000000	•	9ØØA						#< START	;Reset HIMEM to
		9ØØC 9ØØE	-	-				HIMEM #> START	; protect CMPRSS
	•	9010						HIMEM+1	
		9Ø12	6Ø				RTS		
					DA				;Output CR to screen
	0	9Ø16 9Ø18					LDY	#< PASSIA #> PASSIA	;Print PASS #1
		9Ø1A			DB			STROUT	, message
		9Ø1D							;Init error mess
	0	9Ø1F			D /			ERRORS	T 11 mmpmp
		9Ø21				NXTLIN			;Init TXTPTR ;Get next byte
	_	9027			שש	MAIDIN		#\$Ø1	, det next by te
	0	9029							;End-of-prog?
		9Ø2B			5 .				;No-so branch
l	_	9Ø2D 9Ø3Ø			DA			CRDO	;Print End Pass1
	•	9032						#> PASS1B	JIIIII ENG 1 door
		9Ø34			DB			STROUT	
	_	9037			DA				;CR to screen
	0	9Ø3A 9Ø3C							;Any errors-Pass1 ;No-so Pass2
		9Ø3E			DA			CRDO	, no bo rubbe
	_	9041	A9	7C			LDA	#< ERRMES	;Print Not Com-
l	©	9043			DD				;pressed message
		9Ø45 9Ø48						STROUT	;Remove \$FF tokens
	0	9Ø4B							;BASIC via DOS
	•		-			PASS2	JSR	SECOND	;Perform Pass2
		9Ø51 9Ø54		DØ	Ø3	SAVLIN			;BASIC via DOS ;Save Line#
	@	9055		в8		SAALTIN		(TXTPTR),Y	· - '
l	_	9057						LN1	
		9Ø59					INY	(mmmmm)	
	0	9Ø5A 9Ø5C						(TXTPTR),Y LN1+1	
		9Ø5E	-					TXTPTR	
		9Ø6Ø					CLC		
	0	9061						#\$Ø3	; Inc TXTPTR to
		9Ø63 9Ø65	_					TXTPTR SCANLN	;first byte in ;text of prog ln
		9067	-					TXTPTR+1	, toke or prog in
	0	9Ø69	2Ø	В1	ØØ	SCANLN		CHRGET	;Search for End
		9Ø6C	-					#ENDLIN	; of Line Token
	_	9Ø6E 9Ø7Ø						NXTLIN #REFLIN	;Unref and refnd
	0	9072						NXTLIN	
		9074	-						;THEN token?
	_	9076							;No-so branch
	0	9Ø78 9Ø7A						#\$Ø1 (TXTPTR),	í
		9Ø7C					SEC		
	<u> </u>	9Ø7D						#\$ 3Ø	
	•	9Ø7F						#\$ØA SCANLN	
		9Ø81 9Ø83						#THENTK	;Restore THEN
	0	9Ø85						STORE	; token in accum
	-	9Ø87	C9	AB		NEXT		#GOTOTK	;GOTO token?
1		9089					•	STORE #GOSBTK	;Yes-so branch ;GOSUB token?
	0	9Ø8B 9Ø8D						SCANLN	;No-so branch
	-	9Ø8F				STORE		TOKEN	;Save token
		9Ø91	20	B1	ØØ	READLN	JSR	CHRGET	;Inc Ptrto ln#
1									

How CMPRSS works

CMPRSS operates in two passes of your Applesoft program. The first pass consists of scanning the program for referenced line numbers which are found in the following Applesoft statement types:

GOTO
GOSUB
IF...THEN
ON...GOTO
ON...GOSUB

CMPRSS does not check the following commands for referenced line numbers:

LIST RUN DEL

These statements are not commonly used and can be adjusted manually after running CMPRSS if they should occur.

In this first pass, each time a line number is referenced, somehow it must be recorded so that when the Applesoft program is compressed during Pass #2, referenced line numbers will not be removed. Mr. Bauers' COMPRESS uses a Called Line Number Table which severely limits the number of referenced lines you can have in your program, especially as it does not check for duplicates. I have decided to use a method of recording a line number as being referenced which imposes no restriction upon the amount. It involves flagging the referenced lines within the Applesoft program itself. For example, take the following simple program:

1Ø INPUT J 2Ø IF J=Ø THEN 5Ø 3Ø PRINT J 4Ø GOTO 1Ø 5Ø END

Each Applesoft program line is represented in memory as follows:

(a) Two bytes in lo-byte, hi-byte order which point to the beginning of the next Applesoft line in memory. This 2-byte address is in hexadecimal.

(b) Two bytes in lo-byte, hi-byte order representing the line number (in hexadecimal) of the Applesoft line.

(c) Following the initial 4 bytes of the line is the 'text' of the Applesoft line itself. All reserved words (commands) are represented in a single byte by a 'token'. For example, INPUT is

represented by the token \$84 (adopting the usual convention of preceding a hexadecimal number with \$1. All tokens can be recognized as bytes with their high bit set (i.e., \$80 or greater). Applesoft tokens range from \$80 (END) to \$EA (MID\$). All the rest of the text line (which is not represented by an Applesoft token) is represented character by character by each character's ASCII code (including line numbers in GOTOs etc.). All spaces are eliminated by the Interpreter except those within quoted strings.

(d) The end of the Applesoft line is marked by a \$00 byte. The hexadecimal representation of our sample program in memory thus would be as follows, starting at address \$800:

```
$800 00 08 08 0A 00 84 4A 00
$808 14 08 14 00 AD 4A D0 30
$810 14 35 30 00 1B 08 1E 00
$818 BA 4A 00 23 08 28 00 AB
$820 31 30 00 29 08 32 00 80
$828 00 00 00
```

The end of the entire Applesoft program is marked by a sequence of three \$00 bytes.

Because the end of each Applesoft line is marked by a \$00 byte, there is also a \$00 byte immediately preceding each following line. Note that there is also a \$00 byte preceding the first line which usually begins at \$801 in memory.

The method I have devised of flagging a referenced line is to set the \$00 byte immediately preceding the referenced line to \$FF (note that in a normal Applesoft program no byte is ever set to \$FF so therre can be no confusion).

After Pass #1 through the sample program, it will look like this:

```
$800 FF 08 08 0A 00 84 4A 00
$808 14 08 14 00 AD 4A D0 30
$810 C4 35 30 00 1B 08 1E 00
$818 B4 4A 00 23 08 28 00 AB
$820 31 30 FF 29 08 32 00 80
$828 00 00 00
```

During Pass #1, while CMPRSS is flagging all referenced lines with \$FF tokens, it occurred to me that the routine might as well check that these line numbers actually exist and so I have incorporated Peter Meyer's GOTO/GOSUB checker from the December 1982 edition of MICRO. The

	TOD I THOUTH	.Dana 1#44	
	JSR LINGET	;Read ln# and st	
	LDA LINNUM		0
	LDY LINNUM+1		
	STA LN2	:Save LINNUM in	
	STY LN2+1	•	
		•	0
			•
	BCS CHKCOM	;Found-so branch	
	INC ERRORS	:Inc err count	
NOLINE	JSR CRDO	,	_
NOLINE			0
	JSR LINPRT	;Print ln# w err	
	LDA TOKEN	,	0
		· (FILIEN	0
		*	
	LDA #< THEN	;Print THEN on	
	LDY #> THEN		0
		, bereen	
NEXT1		;GOSUB token?	
	BEQ NEXT2	:Yes-so branch	0
	LDA #< COTO		0
		_	
			_
NEXT2	LDA #< GOSUB	;Print GOSUB	0
DDTNT		Dodne undered	
FRINI		•	
	LDA LN2+1	;line #	0
	LDX LN2		•
	JSR LIMPRT		
CHKCOM	LDX-#REFLIN	;Put \$FF in prog	0
	JSR WRTBYT	;to flag ref ln	
CHK1	ISB CHROOT	_	
OIIICI			
		-	^
	BEQ READLN	;Yes-so branch	0
	LDA TXTPTR	:Dec TXTPTR in	
	-	, prep for charact	
			0
NEXT3	DEC TXTPTR		
NEXT3			
-	JMP SCANLN	·Pu+ \$66 or \$EE	
NEXT3 WRTBYT	JMP SCANLN	;Put \$00 or \$FF	•
-	JMP SCANLN CLC LDA LSTLIN	;in byte preceed	0
-	JMP SCANLN		0
-	JMP SCANLN CLC LDA LSTLIN ADC #\$FF	;in byte preceed ;a partic Apple	0
-	JMP SCANLN CLC LDA LSTLIN ADC #\$FF STA LSTLIN	;in byte preceed ;a partic Apple	0
-	JMP SCANLN CLC LDA LSTLIN ADC #\$FF STA LSTLIN LDA LSTLIN+1	;in byte preceed ;a partic Apple	⊗
-	JMP SCANLN CLC LDA LSTLIN ADC #\$FF STA LSTLIN LDA LSTLIN+1 ADC #\$FF	;in byte preceed ;a partic Apple	_
-	JMP SCANLN CLC LDA LSTLIN ADC #\$FF STA LSTLIN LDA LSTLIN+1 ADC #\$FF STA LSTLIN+1	;in byte preceed ;a partic Apple	_
-	JMP SCANLN CLC LDA LSTLIN ADC #\$FF STA LSTLIN LDA LSTLIN+1 ADC #\$FF STA LSTLIN+1 TXA	;in byte preceed ;a partic Apple ;soft line ;X-reg contains	_
-	JMP SCANLN CLC LDA LSTLIN ADC #\$FF STA LSTLIN LDA LSTLIN+1 ADC #\$FF STA LSTLIN+1 TXA	;in byte preceed ;a partic Apple ;soft line ;X-reg contains	•
-	JMP SCANLN CLC LDA LSTLIN ADC #\$FF STA LSTLIN LDA LSTLIN+1 ADC #\$FF STA LSTLIN+1 TXA LDY #\$00	;in byte preceed ;a partic Apple ;soft line ;X-reg contains ;\$00 or \$FF	_
-	JMP SCANLN CLC LDA LSTLIN ADC #\$FF STA LSTLIN LDA LSTLIN+1 ADC #\$FF STA LSTLIN+1 TXA LDY #\$ØØ STA (LSTLIN),	;in byte preceed ;a partic Apple ;soft line ;X-reg contains ;\$00 or \$FF	•
WRTBYT	JMP SCANLN CLC LDA LSTLIN ADC #\$FF STA LSTLIN LDA LSTLIN+1 ADC #\$FF STA LSTLIN+1 TXA LDY #\$ØØ STA (LSTLIN), RTS	;in byte preceed ;a partic Apple ;soft line ;X-reg contains ;\$00 or \$FF	•
-	JMP SCANLN CLC LDA LSTLIN ADC #\$FF STA LSTLIN LDA LSTLIN+1 ADC #\$FF STA LSTLIN+1 TXA LDY #\$ØØ STA (LSTLIN), RTS LDA TXTTAB	;in byte preceed ;a partic Apple ;soft line ;X-reg contains ;\$00 or \$FF Y ;All \$00 to \$FF	
WRTBYT	JMP SCANLN CLC LDA LSTLIN ADC #\$FF STA LSTLIN LDA LSTLIN+1 ADC #\$FF STA LSTLIN+1 TXA LDY #\$ØØ STA (LSTLIN), RTS LDA TXTTAB	;in byte preceed ;a partic Apple ;soft line ;X-reg contains ;\$00 or \$FF Y ;All \$00 to \$FF	•
WRTBYT	JMP SCANLN CLC LDA LSTLIN ADC #\$FF STA LSTLIN LDA LSTLIN+1 ADC #\$FF STA LSTLIN+1 TXA LDY #\$ØØ STA (LSTLIN), RTS LDA TXTTAB STA LSTLIN	;in byte preceed ;a partic Apple ;soft line ;X-reg contains ;\$00 or \$FF Y ;All \$00 to \$FF ;Init LSTLIN to	
WRTBYT	JMP SCANLN CLC LDA LSTLIN ADC #\$FF STA LSTLIN+1 ADC #\$FF STA LSTLIN+1 TXA LDY #\$ØØ STA (LSTLIN), RTS LDA TXTTAB STA LSTLIN LDA TXTTAB+1	;in byte preceed ;a partic Apple ;soft line ;X-reg contains ;\$00 or \$FF Y ;All \$00 to \$FF	
WRTBYT	JMP SCANLN CLC LDA LSTLIN ADC #\$FF STA LSTLIN+1 ADC #\$FF STA LSTLIN+1 TXA LDY #\$ØØ STA (LSTLIN), RTS LDA TXTTAB STA LSTLIN LDA TXTTAB+1 STA LSTLIN+1	;in byte preceed ;a partic Apple ;soft line ;X-reg contains ;\$00 or \$FF Y ;All \$00 to \$FF ;Init LSTLIN to	
WRTBYT	JMP SCANLN CLC LDA LSTLIN ADC #\$FF STA LSTLIN+1 ADC #\$FF STA LSTLIN+1 TXA LDY #\$ØØ STA (LSTLIN), RTS LDA TXTTAB STA LSTLIN LDA TXTTAB+1 STA LSTLIN+1 LDX #ENDLIN	;in byte preceed ;a partic Apple ;soft line ;X-reg contains ;\$00 or \$FF Y ;All \$00 to \$FF ;Init LSTLIN to ;start of prog	0
WRTBYT	JMP SCANLN CLC LDA LSTLIN ADC #\$FF STA LSTLIN+1 ADC #\$FF STA LSTLIN+1 TXA LDY #\$ØØ STA (LSTLIN), RTS LDA TXTTAB STA LSTLIN LDA TXTTAB+1 STA LSTLIN+1 LDX #ENDLIN	;in byte preceed ;a partic Apple ;soft line ;X-reg contains ;\$00 or \$FF Y ;All \$00 to \$FF ;Init LSTLIN to ;start of prog	
WRTBYT	JMP SCANLN CLC LDA LSTLIN ADC #\$FF STA LSTLIN LDA LSTLIN+1 ADC #\$FF STA LSTLIN+1 TXA LDY #\$ØØ STA (LSTLIN), RTS LDA TXTTAB STA LSTLIN LDA TXTTAB+1 STA LSTLIN+1 LDX #ENDLIN JSR WRTBYT	;in byte preceed ;a partic Apple ;soft line ;X-reg contains ;\$00 or \$FF Y ;All \$00 to \$FF ;Init LSTLIN to ;start of prog ;Put \$00 before	0
WRTBYT	JMP SCANLN CLC LDA LSTLIN ADC #\$FF STA LSTLIN LDA LSTLIN+1 ADC #\$FF STA LSTLIN+1 TXA LDY #\$ØØ STA (LSTLIN), RTS LDA TXTTAB STA LSTLIN LDA TXTTAB+1 STA LSTLIN+1 LDX #ENDLIN JSR WRTBYT LDY #\$Ø1	;in byte preceed ;a partic Apple ;soft line ;X-reg contains ;\$00 or \$FF Y ;All \$00 to \$FF ;Init LSTLIN to ;start of prog ;Put \$00 before ;current line	0
WRTBYT	JMP SCANLN CLC LDA LSTLIN ADC #\$FF STA LSTLIN LDA LSTLIN+1 ADC #\$FF STA LSTLIN+1 TXA LDY #\$ØØ STA (LSTLIN), RTS LDA TXTTAB STA LSTLIN LDA TXTTAB+1 STA LSTLIN+1 LDX #ENDLIN JSR WRTBYT LDY #\$Ø1 LDA (LSTLIN),	;in byte preceed ;a partic Apple ;soft line ;X-reg contains ;\$00 or \$FF Y ;All \$00 to \$FF ;Init LSTLIN to ;start of prog ;Put \$00 before ;current line Y ;Loed lo-byte	acccc
WRTBYT	JMP SCANLN CLC LDA LSTLIN ADC #\$FF STA LSTLIN LDA LSTLIN+1 ADC #\$FF STA LSTLIN+1 TXA LDY #\$ØØ STA (LSTLIN), RTS LDA TXTTAB STA LSTLIN LDA TXTTAB+1 STA LSTLIN+1 LDX #ENDLIN JSR WRTBYT LDY #\$Ø1 LDA (LSTLIN),	;in byte preceed ;a partic Apple ;soft line ;X-reg contains ;\$00 or \$FF Y ;All \$00 to \$FF ;Init LSTLIN to ;start of prog ;Put \$00 before ;current line Y ;Load lo-byte ;of next line ptr trans	0
WRTBYT	JMP SCANLN CLC LDA LSTLIN ADC #\$FF STA LSTLIN LDA LSTLIN+1 ADC #\$FF STA LSTLIN+1 TXA LDY #\$ØØ STA (LSTLIN), RTS LDA TXTTAB STA LSTLIN LDA TXTTAB+1 STA LSTLIN+1 LDX #ENDLIN JSR WRTBYT LDY #\$Ø1 LDA (LSTLIN),	;in byte preceed ;a partic Apple ;soft line ;X-reg contains ;\$00 or \$FF Y ;All \$00 to \$FF ;Init LSTLIN to ;start of prog ;Put \$00 before ;current line Y ;Loed lo-byte	acccc
WRTBYT	JMP SCANLN CLC LDA LSTLIN ADC #\$FF STA LSTLIN LDA LSTLIN+1 ADC #\$FF STA LSTLIN+1 TXA LDY #\$ØØ STA (LSTLIN), RTS LDA TXTTAB STA LSTLIN LDA TXTTAB+1 STA LSTLIN+1 LDX #ENDLIN JSR WRTBYT LDY #\$Ø1 LDA (LSTLIN), TAX INY	;in byte preceed ;a partic Apple ;soft line ;X-reg contains ;\$00 or \$FF Y ;All \$00 to \$FF ;Init LSTLIN to ;start of prog ;Put \$00 before ;current line Y ;Load lo-byte ;of next line ptr trans ;to X-Register	acccc
WRTBYT	JMP SCANLN CLC LDA LSTLIN ADC #\$FF STA LSTLIN LDA LSTLIN+1 ADC #\$FF STA LSTLIN+1 TXA LDY #\$ØØ STA (LSTLIN), RTS LDA TXTTAB STA LSTLIN LDA TXTTAB+1 STA LSTLIN+1 LDX #ENDLIN JSR WRTBYT LDY #\$Ø1 LDA (LSTLIN), TAX INY LDA (LSTLIN),	;in byte preceed ;a partic Apple ;soft line ;X-reg contains ;\$00 or \$FF Y ;All \$00 to \$FF ;Init LSTLIN to ;start of prog ;Put \$00 before ;current line Y ;Load lo-byte ;of next line ptr trans ;to X-Register Y ;load hi-byte	acccc
WRTBYT	JMP SCANLN CLC LDA LSTLIN ADC #\$FF STA LSTLIN LDA LSTLIN+1 ADC #\$FF STA LSTLIN+1 TXA LDY #\$ØØ STA (LSTLIN), RTS LDA TXTTAB STA LSTLIN LDA TXTTAB+1 STA LSTLIN+1 LDX #ENDLIN JSR WRTBYT LDY #\$Ø1 LDA (LSTLIN), TAX INY LDA (LSTLIN), STA LSTLIN+1	;in byte preceed ;a partic Apple ;soft line ;X-reg contains ;\$00 or \$FF Y ;All \$00 to \$FF ;Init LSTLIN to ;start of prog ;Put \$00 before ;current line Y ;Load lo-byte ;of next line ptr trans ;to X-Register	acccc
WRTBYT	JMP SCANLN CLC LDA LSTLIN ADC #\$FF STA LSTLIN+1 ADC #\$FF STA LSTLIN+1 TXA LDY #\$ØØ STA (LSTLIN), RTS LDA TXTTAB STA LSTLIN LDA TXTTAB+1 STA LSTLIN+1 LDX #ENDLIN JSR WRTBYT LDY #\$Ø1 LDA (LSTLIN), TAX INY LDA (LSTLIN), STA LSTLIN+1	;in byte preceed ;a partic Apple ;soft line ;X-reg contains ;\$00 or \$FF Y ;All \$00 to \$FF ;Init LSTLIN to ;start of prog ;Put \$00 before ;current line Y ;Load lo-byte ;of next line ptr trans ;to X-Register Y ;load hi-byte	0 0
WRTBYT	JMP SCANLN CLC LDA LSTLIN ADC #\$FF STA LSTLIN LDA LSTLIN+1 ADC #\$FF STA LSTLIN+1 TXA LDY #\$ØØ STA (LSTLIN), RTS LDA TXTTAB STA LSTLIN LDA TXTTAB+1 STA LSTLIN+1 LDX #ENDLIN JSR WRTBYT LDY #\$Ø1 LDA (LSTLIN), TAX INY LDA (LSTLIN), STA LSTLIN+1	;in byte preceed ;a partic Apple ;soft line ;X-reg contains ;\$00 or \$FF Y ;All \$00 to \$FF ;Init LSTLIN to ;start of prog ;Put \$00 before ;current line Y ;Load lo-byte ;of next line ptr trans ;to X-Register Y ;load hi-byte	0 0
WRTBYT	JMP SCANLN CLC LDA LSTLIN ADC #\$FF STA LSTLIN LDA LSTLIN+1 ADC #\$FF STA LSTLIN+1 TXA LDY #\$ØØ STA (LSTLIN), RTS LDA TXTTAB STA LSTLIN LDA TXTTAB+1 STA LSTLIN+1 LDX #ENDLIN JSR WRTBYT LDY #\$Ø1 LDA (LSTLIN), TAX INY LDA (LSTLIN), STA LSTLIN+1 STA LSTLIN+1 STA LSTLIN+1 STA LSTLIN), TAX	;in byte preceed ;a partic Apple ;soft line ;X-reg contains ;\$00 or \$FF Y ;All \$00 to \$FF ;Init LSTLIN to ;start of prog ;Put \$00 before ;current line Y ;Load lo-byte ;of next line ptr trans ;to X-Register Y ;load hi-byte ;Update LSTLIN	0 0
WRTBYT	JMP SCANLN CLC LDA LSTLIN ADC #\$FF STA LSTLIN LDA LSTLIN+1 ADC #\$FF STA LSTLIN+1 TXA LDY #\$ØØ STA (LSTLIN), RTS LDA TXTTAB STA LSTLIN LDA TXTTAB+1 STA LSTLIN+1 LDX #ENDLIN JSR WRTBYT LDY #\$Ø1 LDA (LSTLIN), TAX INY LDA (LSTLIN), STA LSTLIN+1 STX LSTLIN+1 STX LSTLIN+1 STX LSTLIN+1 STX LSTLIN), STA LSTLIN+1 STX LSTLIN DEY LDA (LSTLIN),	;in byte preceed ;a partic Apple ;soft line ;X-reg contains ;\$00 or \$FF Y ;All \$00 to \$FF ;Init LSTLIN to ;start of prog ;Put \$00 before ;current line Y ;Load lo-byte ;of next line ptr trans ;to X-Register Y ;load hi-byte ;Update LSTLIN Y ;End of Prog?	
WRTBYT	JMP SCANLN CLC LDA LSTLIN ADC #\$FF STA LSTLIN LDA LSTLIN+1 ADC #\$FF STA LSTLIN+1 TXA LDY #\$ØØ STA (LSTLIN), RTS LDA TXTTAB STA LSTLIN LDA TXTTAB+1 STA LSTLIN+1 LDX #ENDLIN JSR WRTBYT LDY #\$Ø1 LDA (LSTLIN), TAX INY LDA (LSTLIN), STA LSTLIN+1 STX LSTLIN+1 STX LSTLIN+1 STX LSTLIN DEY LDA (LSTLIN), BNE REST1	;in byte preceed ;a partic Apple ;soft line ;X-reg contains ;\$00 or \$FF Y ;All \$00 to \$FF ;Init LSTLIN to ;start of prog ;Put \$00 before ;current line Y ;Load lo-byte ;of next line ptr trans ;to X-Register Y ;load hi-byte ;Update LSTLIN Y ;End of Prog?	0 0
WRTBYT RESTOR REST1	JMP SCANLN CLC LDA LSTLIN ADC #\$FF STA LSTLIN LDA LSTLIN+1 ADC #\$FF STA LSTLIN+1 TXA LDY #\$ØØ STA (LSTLIN), RTS LDA TXTTAB STA LSTLIN LDA TXTTAB+1 STA LSTLIN+1 LDX #ENDLIN JSR WRTBYT LDY #\$Ø1 LDA (LSTLIN), TAX INY LDA (LSTLIN), STA LSTLIN+1 STX LSTLIN+1 STX LSTLIN+1 STX LSTLIN DEY LDA (LSTLIN), STA LSTLIN+1 STX LSTLIN DEY LDA (LSTLIN), BNE REST1 RTS	;in byte preceed ;a partic Apple ;soft line ;X-reg contains ;\$00 or \$FF Y ;All \$00 to \$FF ;Init LSTLIN to ;start of prog ;Put \$00 before ;current line Y ;Load lo-byte ;of next line ptr trans ;to X-Register Y ;load hi-byte ;Update LSTLIN Y ;End of Prog? ;No-so loop	
WRTBYT	JMP SCANLN CLC LDA LSTLIN ADC #\$FF STA LSTLIN LDA LSTLIN+1 ADC #\$FF STA LSTLIN+1 TXA LDY #\$ØØ STA (LSTLIN), RTS LDA TXTTAB STA LSTLIN LDA TXTTAB+1 STA LSTLIN+1 LDX #ENDLIN JSR WRTBYT LDY #\$Ø1 LDA (LSTLIN), TAX INY LDA (LSTLIN), STA LSTLIN+1 STX LSTLIN+1 STX LSTLIN+1 STX LSTLIN DEY LDA (LSTLIN), STA LSTLIN+1 STX LSTLIN DEY LDA (LSTLIN), BNE REST1 RTS	;in byte preceed ;a partic Apple ;soft line ;X-reg contains ;\$00 or \$FF Y ;All \$00 to \$FF ;Init LSTLIN to ;start of prog ;Put \$00 before ;current line Y ;Load lo-byte ;of next line ptr trans ;to X-Register Y ;load hi-byte ;Update LSTLIN Y ;End of Prog?	
	PRINT CHKCOM CHK1	NOLINE STY LN2+1 JSR FNDLIN BCS CHKCOM INC ERRORS NOLINE JSR CRDO LDA LN1+1 LDX LN1 JSR LINPRT LDA TOKEN CMP #THENTK BNE NEXT1 LDA #< THEN LDY #> THEN LDY #> THEN LDY #> THEN LDY #> GOTO LDY #> GOTO LDY #> GOTO LDY #> GOSUB LDY #> GOSUB LDY #> GOSUB PRINT NEXT2 LDA #< GOSUB LDY #> GOSUB LDY #> GOSUB LDY #> GOSUB LDY #> GOSUB COSUB LDY LN2+1 LDA LN2+1 LDA LN2+1 LDA LN2+1 LDX LN2 JSR LINPRT JMP CHK1 CHKCOM LDX-#REFLIN JSR WRTBYT CHK1 JSR CHRGOT CMP #COMMA BEQ READLN LDA TXTPTR BNE NEXT3 DEC TXTPTR+1	STA LN2 ;Save LINNUM in STY LN2+1 ;LN2 JSR FNDLIN ;Look for ln# BCS CHKCOM ;Found—so branch INC ERRORS ;Inc err count NOLINE JSR CRDO LDA LN1+1 LDX LN1 JSR LINPRT ;Print ln# w err LDA TOKEN CMP #THENTK ;THEN token? BNE NEXT1 ;No—so branch LDA #< THEN ;Print THEN on LDY #> THEN ; screen JMP PRINT NEXT1 CMP #GOSBTK ;GOSUB token? BEQ NEXT2 ;Yes—so branch LDA #< GOTO ;Must have GOTO LDY #> GOTO ;so print GOTO JMP PRINT ;on screen NEXT2 LDA #< GOSUB ;Print GOSUB LDY #> GOSUB PRINT JSR STROUT ;Print undefd LDA LN2+1 ;line # LDX LN2 JSR LINPRT JMP CHK1 CHKCOM LDX—#REFLIN ;Put \$FF in prog JSR WRTBYT ;to flag ref ln CHK1 JSR CHRGOT ;Re—get curbyte CMP #COMMA ;Comma? BEQ READLN ;Yes—so branch LDA TXTPTR ;Dec TXTPTR in BNE NEXT3 ;prep for CHRGET

	9125 A9 8F		LDA #< PASS2A	;Print PASS2 mes
0	9127 AØ 94		LDY #> PASS2A	•
	9129 20 3A DB 912C 20 FB DA		JSR STROUT JSR CRDO	
	912F A9 FF			;Init variables
0	9131 85 Ø4		STA LASTX	,1111 (41145165
	9133 A5 67		LDA TXTTAB	
	9135 85 9B		STA LSTLIN	
0	9137 85 Ø2		STA NEWPTR	
	9139 85 B8 913B A5 68		STA OLDPTR LDA TXTTAB+1	
	913D 85 9C		STA LSTLIN+1	
0	913F 85 Ø3		STA NEWPTR+1	
	9141 85 B9		STA OLDPTR+1	
	9143 A5 AF		LDA EPROG	
0	9145 85 Ø8		STA OLDEOP LDA EPROG+1	
	9147 A5 BØ 9149 85 Ø9		STA OLDEOP+1	
	914B A9 ØØ		LDA #ENDLIN	
0	914D 85 ØA		STA LSTEOS	
	914F 85 Ø1		STA IFFLAG	
	9151 20 05 94		JSR DECOLD	
•	9154 20 F7 93 9157 20 C5 93		JSR DECNEW JSR GETLIN	;Get 1st ln#
1	915A 2Ø 39 93			;Init LINBUF
		GETBYT		Get next byte
0	916Ø C9 FF		CMP #REFLIN	;EOLine Ref
	9162 FØ Ø4			;Yes-so branch
	9164 C9 ØØ 9166 DØ 17		CMP #ENDLIN BNE GB2	;EOLine Unref
0	9168 85 ØA	GB1		;No-so branch ;Recall last End
	916A 85 FC	UDI		of Statmt Token
	916C 2Ø DØ 91		JSR EOL	;Deal with EOL
	916F 9Ø EC	GB1A	BCC GETBYT	
0	9171 2Ø 6E 93		JSR EOP	;Deal w EOProg
	9174 A9 9A 9176 AØ 94		LDA #< PASS2B	;Print END PASS2
	9178 20 3A DB		JSR STROUT	
8	917B 2Ø FB DA		JSR CRDO	
	917E 6Ø		RTS	
	917F C9 3A	GB2	CMP #COLON	
0	9181 DØ Ø6 9183 2Ø Ø2 92		BNE GB3 JSR EOS	;No-so branch ;Deal w EOStmt
	9186 4C 5D 91		JMP GETBYT	Get next byte
	9189 C9 AA	GB3	CMP #LETTOK	;LET token?
0	918B FØ DØ		BEQ GETBYT	;Yes - ignore
	918D C9 B2		CMP #REMTOK	;REM token?
	918F DØ Ø6 9191 2Ø 1D 92		BNE GB4 JSR REMARK	;No-so branch
0	9194 4C 6F 91		JMP GB1A	;Deal with REM ;Check EOP
	9197 C9 82	GB4	CMP #NXTTOK	;NEXT token?
	9199 DØ Ø6		BNE GB5	;No-so branch
0	919B 2Ø 59 92		JSR NEXTX	;Deal w NEXT
	919E 4C 5D 91 91A1 C9 22	GR5	JMP GETBYT CMP #QUOTE	·Te it a aucto?
	91A3 DØ Ø6	GB5	BNE GB6	;Is it a quote? ;No-so branch
0	91A5 2Ø 85 92		JSR STRING	;Deal with quote
	91A8 4C 5D 91		JMP GETBYT	_
	91AB 2Ø 2A 94	GB6	JSR LETTER	;Is it a letter?
0	91AE BØ Ø6 91BØ 2Ø A6 92		BCS GB7 JSR VARIBL	;No-so branch ;Yes-must be var
	91B3 4C 5D 91		JMP GETBYT	, res-must be var
	91B6 C9 AD	GB7	CMP #IFTOK	;IF token?
0	91B8 DØ Ø8		BNE GB8	;No-not special
	91BA A4 Ø1		LDY IFFLAG	; If IFFLAG isn't
	91BC DØ Ø4		BNE GB8	;Ø then leave
0	91BE A4 Ø4 91CØ 84 Ø1		LDY LASTX STY IFFLAG	;Remem beg of IF
	9100 84 01 9102 20 1B 94	GB8	JSR PUTBUF	;Byte in LINBUF
	9105 90 96		BCC GETBYT	;LINBUF not full
				MICOC

46

process of Pass #1 goes something like this:

(a) Locate a GOTO, GOSUB or THEN token.

(b) Call the Applesoft Interpreter routine LINGET to get the 'decimalized' line number and convert it to hexadecimal.

(c) Call the Applesoft Interpreter routine FNDLIN to locate the line number in the Applesoft program.

(d) If it is found, store \$FF in the byte immediately preceding the line; otherwise print an error message on the screen and set the error flag.

(e) Repeat until the end of the Applesoft program is reached.

Other Applesoft Interpreter routines used are:

CH-

RGET increment TXTPTR, the text pointer and load the next byte of the Applesoft program into the Accumulator.

CH-RGOT

same as CHRGET but does not increment TXTPTR.

STX-

TPT initialize TXTPTR to the byte immediately preceding the start of the Applesoft program in preparation for scanning through it.

CRDO output a carriage return to the screen

STR-

OUT prints a text string to the screen (used for messages).

LINPRT prints a two-byte

hexadecimal number as a decimal number to the screen.

By using these routines, I was able to considerably reduce the amount of memory occupied by CMPRSS; it occupies 3 pages of memory less than COMPRESS and, in addition, it also checks for unreferenced line numbers.

If any unreferenced line numbers are encountered during Pass #1, the Applesoft program will not be compressed. CMPRSS cannot just return control to Applesoft however, because the Applesoft program will be sprinkled with \$FF tokens. Before returning control to the Interpreter, a routine called RESTOR is executed which replaces all \$FF bytes with \$00 bytes. Return is then made via the DOS warm start vector at \$3D0.

MICRO No. 73 - July 1984

If no unreferenced line numbers are encountered, CMPRSS enters Pass #2 which is the compression phase. Our sample program, after compression will look like this:

10 INPUT J : IF J = 0 THEN 50 30 PRINT J : GOTO 10 50 END

which in memory will look like:

\$800 00 10 08 0A 00 84 4A 3A \$808 AD 4A D0 30 C4 35 30 00 \$810 1B 08 1E 00 BA 4A 3A AB \$818 31 30 00 21 08 32 00 80 \$820 00 00 00

All \$FFs have been replaced by \$00 again. This program has been compressed by 8 bytes or 20% of the original size. Programs containing REMs and long variable names show much more spectacular reductions after compression.

Techniques used by CMPRSS for Compression

(a) Concatenation of statements and removal of line numbers.

As many statements as possible are concatenated onto each line (to a maximum of 255 characters per line). This often results in longer lines than can ever be keyed in manually through the keyboard. Referenced lines cannot be concatenated, so the process stops when an \$FF token is encountered. Also, if an IF statement occurs in the Applesoft line, then the next line cannot be concatenated on the end or it will alter the logic flow of the program. E.g.,

100 IF A = B THEN A = A + 1 110 B = B + 1

cannot be compressed as:

100 IF A = B THEN A = A + 1 : B = B + 1

because in the original program, B = B + 1 is always performed regardless of the values of A and B, whereas in the "compressed" version B = B + 1 is only executed when A = B. This is of paramount importance. Take the following example from Mr. Bauers' article:

(1) 10 GOTO 50 20 J = 5 50 END

91C7 2Ø AE 93		JSR BAKTRK	;LINBUF full so	0
91CA 2Ø 39 93		JSR NEWLIN	;backtrk, start	0
91CD 4C 5D 91 91DØ C9 FF	EOL	JMP GETBYT CMP #REFLIN	;new ln,nxt byte ;Deal w EOL	
91D2 DØ 15	EOL	BNE EOL2	;Ref line - No	•
91D4 A9 ØØ	EOLX	LDA #ENDLIN	;Yes Replace \$FF	0
91D6 2Ø 1B 94		JSR PUTBUF	;w \$ØØ in LINBUF	
91D9 2Ø 9B 93		JSR TRNBUF	;Transfer LINBUF	
91DC			; to new program	0
91DC 20 C5 93	EOLØ	JSR GETLIN	Get nxt Ap ln#	
91DF BØ Ø4		BCS EOL1	;Branch if EOP	
91E1 2Ø 39 93		JSR NEWLIN	;Newln in LINBUF	0
91E4 18 91E5 20 D5 92	EOL1	CLC JSR RESOLD	;Flag not EOP ;Rset OLDBEG ptr	
91E8 6Ø	FOLI	RTS	, RSet OLDDEG Ptr	
91E9 A5 Ø1	EOL2	LDA IFFLAG	;Force EOL?	0
91EB DØ E7		BNE EOLX	;Yes-so branch	•
91ED A9 3A		LDA #COLON	;Colon-mark EOS	
91EF 86 Ø4		STX LASTX	;Updte LASTX ptr	•
91F1 2Ø 1B 94		JSR PUTBUF	;Colon in LINBUF	0
91F4 9Ø Ø5		BCC EOL4	;Not full-branch	
91F6 CA	EOL3	DEX	- Former EOT	
91F7 A9 FF 91F9 DØ D5		LDA #REFLIN BNE EOL	;Force EOL ;Always branch	0
91FB 2Ø C5 93	EOL4	JSR GETLIN	Get new ln#	
91FE BØ F6	LOD	BCS EOL3	;EOP - branch	
92ØØ 9Ø E3		BCC EOL1	;Not EOP-branch	0
9202 86 04	EOS	STX LASTX	;Deal w EOS	
92Ø4 2Ø 1B 94		JSR PUTBUF	;Updte LASTX ptr	
92Ø7 9Ø ØC		BCC EOS1	;LINBUF not full	0
92Ø9 CA		DEX		•
92ØA A9 ØØ		LDA #ENDLIN	;terminate ln	
92ØC 2Ø 1B 94		JSR PUTBUF	;\$ØØ in LINBUF	
92ØF 2Ø 9B 93 9212 2Ø 39 93		JSR TRNBUF JSR NEWLIN	Stant a new line	0
9212 20 39 93		SOU MEMPIN	;Start a new line ;in LINBUF	
9215 2Ø D5 92	EOS1	JSR RESOLD	;Reset OLDBEG ptr	
9218 A9 ØØ		LDA #ENDLIN	,	0
921A 85 ØA		STA LSTEOS	;Set last EOS to	
921C 6Ø		RTS	;\$ØØ	
921D 2Ø 22 94	REMARK	JSR GETOLD	;Deal with REM	0
922Ø C9 FF		CMP #REFLIN	;1st loop reading	•
9222 FØ Ø8 9224 C9 ØØ		BEQ REM1	;bytes until EOL ;(\$00 or \$FF) is	
9224 C9 WW 9226 DØ F5		CMP #ENDLIN BNE REMARK	; reached	_
9228 AØ ØØ		LDY #\$ØØ	;Set Y-reg to re-	0
922A		" + F F	;member that	
922A FØ Ø2		BEQ REM2	;\$ØØ was EOL	_
922C AØ Ø1	REM1	LDY #\$Ø1	;or \$FF was EOL	0
922E 85 FC	REM2	STA TEMP	;Temp store EOL	
923Ø EØ Ø4		CPX #\$Ø4	; Is REM on sep ln?	
9232 FØ Ø4		BEQ REM3	;Yes, so branch ;No, so drop REM	0
9234 CA 9235 4C DØ 91		DEX JMP EOL	ino, so arop ren	
9238 A5 ØA	REM3	LDA LSTEOS	;Is Rem referencd	
923A DØ Ø7		BNE REM4	;Yes, so branch	0
923C CØ ØØ		CPY #\$ØØ	; Is nxt ln ref?	
923E FØ 11		BEQ REM5	;No, so branch	
924Ø 4C DC 91		JMP EOLØ	;Drop Rem line	0
9243 CØ ØØ	REM4	CPY #\$ØØ	;Is nxt ln ref?	U
9245 FØ ØA		BEQ REM5	;No, so branch	
9247 A9 B2 9249 20 1B 94		LDA #REMTOK JSR PUTBUF	;Retain REM, put ;token in LINBUF	_
9249 20 1B 94 924C A9 FF		LDA #REFLIN	; Force EOL	0
924E 4C DØ 91		JMP EOL	,10100 101	
9251 A5 ØA	REM5	LDA LSTEOS	;Carry LSTEOS	
9253 85 FC		STA TEMP	;to next line	0
9255 2Ø C5 93		JSR GETLIN	;Get nxt ln #	
9258 6Ø		RTS		

	0	9259	2 0 1 B	94	NEXTX	JSR	PUTBUF	;Deal w NEXT stm
	•	925C				BCC	NEXTA	;NEXT token in
		925E 2	2Ø AE	93				;LINBUF, branch
	0	9261				•		lse backtrack
	•	9261	າດເກ	02		-	previous E	.05
		9261 2 9264 6		93		RTS	NEWLIN	
	_	9265 2		94	NEXTA		GETOLD	
	•	9268					#REFLIN	
		926A I	FØ 15			BEQ	NEXTB	
	_	926C (#ENDLIN	
	0	926E 1	-			•	NEXTB	707 IA
		927Ø (#COLON NEXTB	;EOS yet? ;Yes, so branch
		9274				•	#COMMA	;More than one
	®	9276	0 , 20			0.11	,, 0011111	;var in NEXT?
		9276 I	DØ ED)		BNE	NEXTA	;No, so branch
		9278				LDA	#COLON	;Write a : NEXT
	0	927A 2					PUTBUF	; for each comma
		927D I	-				#NXTTOK	;Load NEXT into
		927F I			MEVTED.		NEXTX	;Accum, always BR
	•	9281 2 9284 (94	NEXTB	RTS	DECOLD	;Backstep OLDPTR ;and return
		9285		94	STRING		PUTBUF	;Deal w Quoted Str
		9288			22112110		COPYST	;Put quote in LIN
	®	928A						;BUF, BR not full
	•	928A 2			SBAK		BAKTRK	;Full, so backtrak
		928D 2		93			NEWLIN	; to end of prev
	_	9290	5Ø			RTS		;stm, start new ;line in LINBUF
	0	9291 9291	od 22) QL	COPYST	TSR	GETOLD	; IIIIe IN LINDUF
		9294			001 101		PUTBUF	
		9297		-			SBAK	; If LINBUF full BR
	0	9299				DEX		
		929A					#QUOTE	;Is char just
		929C I		-			LINBUF,X	;placed a quote
	0	929F 1		,		INX	CLQUOT	;Yes,so branch ;Restore X-reg
		92A1 1)			COPYST	;Always branch
		92A4 1	-		CLQUOT	INX	001 101	;Restore X-reg
	®	92A5			•	RTS		
		92A6 2	-	94	VARIBL		PUTBUF	;Truncate var
		92A9		_				num 2 chars
	0	92A9			T/D A I/		VAR1 BAKTRK	;LINBUF not full BR
		92AB :			VBAK		NEWLIN	
		92B1		, ,,		RTS	11211211	
	0	92B2		94	VAR1	JSR	GETOLD	Get next byte
	•	92B5	2Ø 2A	94			LETTER	; Is it a letter?
		92B8 ⁹					VAR2	;Yes, so branch
8	®	92BA					NUMBER VAR4	;Is it a number? ;No, so branch
	•	92BD 1 92BF 1			VAR2		PUTBUF	;Put 2nd char in
		9202			VAILE		VBAK	;LINBUF,if full BR
		9204			VAR3		GETOLD	•
	0	9207	2Ø 2£	94		JSR	LETTER	
		92CA					VAR3	
	_	9200					NUMBER	
	0	92CF			VAR4		VAR3 DECOLD	;Dec OLDPTR and
		92D1 92D4) 74	17114	RTS		;return
		92D5		L	RESOLD		IFFLAG	;Reset OLDBEG
	®	92D7					RS1	;ptr except in
1		92D9	A5 B8	3			OLDPTR	;mid of an IF
1		92DB					OLDBEG	
1	0	92DD					OLDPTR+1 OLDBEG+1	
١		92DF 92E1		,	RS1	RTS		
		/	J.					

His COMPRESS would leave this program as it is, because although line #20 is not referenced, he says that concatenating it onto line #10:

(11) 1Ø GOTO 5Ø : J = 5 5Ø END

would cause the I = 5 statement never to be executed. This is true, but in fact, if you carefully examine the original program, (i), you will see that it will not even be executed in the original! So the program at (ii) is perfectly acceptable because it behaves identically to the original. It is perhaps preferable to (i) because it emphasizes the "dead code". As soon as you see the J = 5 appended to the GOTO statement, you can see that there is something wrong. If there is no ''dead code" in your program, then all lines following a terminal statement such as GOTO, RETURN, STOP or END will always be referenced and there is no need for CMPRSS to take any special action.

(b) Removal of REMs

It is important, especially in a large program, to liberally sprinkle the program with meaningful REMarks - it makes the program listing much easier to follow. But REM statements are included in a program for documentation purposes only and serve no useful purpose during execution. In fact, the text of a REM occupies many valuable bytes of memory and often is assigned a line number of its own so that, apart from the text of the REM (one byte per character), an additional four bytes for the line number and link bytes, one byte for the REM token and one byte for the end-of-statement token are wasted. If the REM statement occupies a line of its own, then CMPRSS will remove it entirely if it is not referenced. If it is referenced but the following line is not referenced, the REM line is also removed as shown below:

```
50 GOSUB 1000 ...
1000 REM THIS IS A SUBROUTINE
1010 A = 10 ...
1090 RETURN
```

If line #1010 is not referenced, it does					
not matter whether it has line #1010 or					
line #1000, so the REM will be					
completely removed and the					
unreferenced line, A = 10, will be					
given the line number of the referenced					
REM. E.g.,					

1000 A = 10

This does not alter the performance of the program and saves 6 bytes more than Mr. Bauers' COMPRESS which would compress the same statements as:

1000 REM 1010 A = 10

The only time that a REM token has to remain in the program is when it is a referenced REM and the following line is also referenced. E.g.,

```
15 GOSUB 500
```

...

500 REM THIS IS A REM

51Ø INPUT X,Y

52Ø IF X = Ø OR Y = Ø THEN 51Ø

53Ø RETURN

This would compress to:

15 GOSUB 500

•••

500 REM

510 INPUT X,Y: IF X = 0 OR Y = 0 THEN 510

53Ø RETURN

If the REM is at the end of a multistatement line, it is always removed completely and, if possible, other lines will be concatenated in its place. E.g.,

100 X1 = X : REM SAVE X-COORDINATE 110 Y1 = Y : REM SAVE Y-COORDINATE 120 INPUT X,Y

would compress as:

100 X1 = X : Y1 = Y : INPUT X, Y

a very spectacular compression of the original 68 bytes into 21 bytes! This is 70% compression.

(c) Removal of LETs

Because the two statements, LET A = B and A = B mean exactly the same thing, CMPRSS removes the unnecessary LET token, saving one byte.

92E2 2Ø FB DA	SUMARY	JSR CRDO ;Print result of	
92E5 A9 A6		LDA #< MESS1 ; cmpress to scrn	•
92E7 AØ 94		IDI #/MESSI ;prnt orig ingth	
92E9 2Ø 3A DB 92EC 38		JSR STROUT SEC	
92ED A5 Ø8		LDA OLDEOP	0
92EF E5 67		SBC TXTTAB	
92F1 AA		TAX	
92F2 A5 Ø9		LDA OLDEOP+1	0
92F4 E5 68		SBC TXTTAB+1	•
92F6 2Ø 24 ED		JSR LINPRT	
92F9 2Ø 2E 93		JSR PRT1A	0
92FC A9 CØ 92FE AØ 94		LDA # <mess2 #="" ;prnt="" ldy="" lngth="" of="">MESS2 ;compressd prog</mess2>	
93ØØ 2Ø 3A DB		JSR STROUT	
93Ø3 38		SEC	_
9304 A5 AF		LDA EPROG	0
93Ø6 E5 67		SBC TXTTAB	
93Ø8 AA		TAX	
93Ø9 A5 BØ		LDA EPROG+1	0
93ØB E5 68		SBC TXTTAB+1	
93ØD 2Ø 24 ED 931Ø 2Ø 2E 93		JSR LINPRT JSR PRT1A	
9313 A9 D7		LDA #< MESS3 ;prnt # of bytes	0
9315 AØ 94		LDY #> MESS3 ; compressed	
9317 2Ø 3A DB		JSR STROUT	
931A 38		SEC	0
931B A5 Ø8		LDA OLDEOP	•
931D E5 AF		SBC EPROG	
931F AA		TAX	
932Ø A5 Ø9 9322 E5 BØ		LDA OLDEOP+1 SBC EPROG+1	0
9324 2Ø 24 ED		JSR LINPRT	
9327 2Ø 2E 93		JSR PRT1A	
932A 2Ø FB DA		JSR CRDO	0
932D 6Ø		RTS	
932E A9 E7	PRT1A	LDA #< MESS1A ;prnt the word	
933Ø AØ 94		LDY #> MESSIA ; bytes after the	•
9332 20 3A DB 9335 20 FB DA		JSR STROUT ;above 3 messge JSR CRDO	
9338 6Ø		RTS	
9339 A9 ØØ	NEWLIN		0
933B 85 Ø1		STA IFFLAG ; in LINBUF, 1st	
933D		;reset OLDBEG and IFFLAG	
933D 2Ø D5 92		JSR RESOLD	(a)
934Ø 2Ø 5F 93		JSR WRTLNK ; Write the link	•
9343 A5 Ø2 9345		LDA NEWPTR ; bytes at beg ; of last compressed line	
9345 85 9B		STA LSTLIN ; Remember positn	•
9347 A5 Ø3		LDA NEWPTR+1 ; of strt of new	0
9349 85 90		STA LSTLIN+1 ; ln just being	
934B		; commenced	_
934B 2Ø F7 93		JSR DECNEW ; reset NEWPTR	0
934E A2 Ø2		LDX #\$02 ;Write nxt ln #	
9350 A5 FA 9352 9D 00 95		LDA LN1 ; at start of LINBUF	
9355 E8		STA LINBUF,X INX	0
9356 86 Ø4		STX LASTX ; Init LASTX for	
9358 A5 FB		LDA LN1+1 ; new line	
935A 9D ØØ 95		STA LINBUF, X	0
935D E8		INX	
935E 6Ø		RTS	
935F AØ ØØ	WRTLNK	LDY #\$00 ;Write link bytes JSR INCNEW ;at start of last	0
9361 20 E9 93 9364 A5 02		JSR INCNEW ; at start of last LDA NEWPTR ; compressed line	-
		STA (LSTLIN),Y	
		DIR CINIDINA I	
9366 91 9B		, , , , , ,	
9366 91 9B 9368 C8		INY LDA NEWPTR+1	0
9366 91 9B		INY	0

	936D 6Ø		RTS
0	936E 2Ø 5F 93	EOP	JSR WRTLNK ; Deal with EOP
	9371 2Ø 97 D6		JSR STXTPT ;Put \$00 before LDA #\$00 ;1st byte of new
	9374 A9 ØØ 9376 A8		TAY ; prog in case a
0	9377 91 B8		STA (TXTPTR),Y ;Write two
	9379 91 Ø2		STA (NEWPTR),Y ;extra \$00
	937B 2Ø E9 93		JSR INCNEW ; bytes to new
•	937E 91 Ø2 938Ø 2Ø E9 93		STA (NEWPTR),Y ;prog (3 in a JSR INCNEW ;row is EOP)
	9383 A5 Ø2		LDA NEWPTR
	9385 85 AF		STA EPROG ;Set new EOP ptr
0	9387 85 69		STA LOMEM ;Set new LOMEM
	9389 85 6B		STA ARS ;Set new strt of
	938B 938B 85 6D		; array space STA EARS ; Set new end of
0	938D A5 Ø3		LDA NEWPTR+1 ; array space
	938F 85 BØ		STA EPROG+1
	9391 85 6A		STA LOMEM1
0	9393 85 6C		STA ARS+1
	9395 85 6E 9397 2Ø E2 92		STA EARS+1 JSR SUMARY ; Print results
	939A 6Ø		RTS ;of compression
9	939B CA	TRNBUF	
	9390		; to New Program Area
	939C 86 Ø7		STX MAXX ;Store max loop
0	939E A2 ØØ 93AØ		LDX #\$00 ;Reset X-reg for ;transfer loop
	93AØ BD ØØ 95	LOOP1	LDA LINBUF,X ;Load next byte
	93A3		;from LINBUF
0	93A3 2Ø 13 94		JSR PUTNEW ; Trans to new
	93A6 E8 93A7 E4 Ø7		INX ;program area CPX MAXX ;Loop complete?
	93A9 FØ F5		BEQ LOOP1 ; No, so do again
0	93AB 9Ø F3		BCC LOOP1 ; No, so do again
	93AD 6Ø		RTS
	93AE A6 Ø1	BAKTRK	
❷	93BØ 93BØ DØ Ø2		;EOS or start of IF statemt BNE BK1
	93B2 A6 Ø4		LDX LASTX ; Reset X-reg to
	93B4 A9 ØØ	BK1	LDA #ENDLIN ;prev EOS
0	93B6 2Ø 1B 94		JSR PUTBUF
	93B9 A5 Ø5 93BB 85 B8		LDA OLDBEG STA OLDPTR
	93BD A5 Ø6		LDA OLDBEG+1
0	93BF 85 B9		STA OLDPTR+1
	93C1 2Ø 9B 93		JSR TRNBUF
	9304 60	GETLIN	RTS LDY #\$Ø2 ;Get ln # of
0	93C5 AØ Ø2 93C7 B1 B8	GEILIN	LDA (OLDPTR),Y ; curr old ln
	n3C9 FØ 1C		BEQ GET1 ; If hibyte of link-
0	93CB C8		INY ; byte pair is zero
٦	93CC		; then this is EOP
	93CC B1 B8 93CE 85 FA		LDA (OLDPTR),Y ;Get lobyte STA LN1 ;remember it
0	93DØ C8		INY ;Update last
	93D1		;EOS byte
	93D1 B1 B8		LDA (OLDPTR),Y;Get hibyte
0	93D3 85 FB 93D5 A5 FC		STA LN+1 ; remember it LDA TEMP ; Update last
	93D7		;EOS byte
	93D7 85 ØA		STA LSTEOS ;Get OLDPTR just
0	93D9 2Ø FØ 93		JSR INCOLD ; before 1st byte
	93DC 2Ø FØ 93		JSR INCOLD ;of actual Apple JSR INCOLD ;soft line
	93DF 2Ø FØ 93 93E2 2Ø FØ 93		JSR INCOLD ; soft line JSR INCOLD
0	93E5 18		CLC ;Flag not EOP
	93E6 6Ø		RTS
	93E7 38	GET1	SEC ;Flag EOP
L			

(d) Removal of Variable Names from NEXT Statements

Not only does the removal of the variable name(s) associated with a NEXT token save memory, but it also enables the Applesoft interpreter to execute the FOR..NEXT loop(s) faster, because it obviates the need for it to check that the variable name refers to the currently active FOR. CMPRSS correctly performs this removal even in the instance where more than one FOR..NEXT loop terminates on the same statement:

100 NEXT I1, I2

CMPRSS will transform this into:

100 NEXT : NEXT

saving one byte for each character of each variable name removed.

(e) Truncation of Variable Names To a Maximum of 2 Characters

No longer is it necessary for you to name all your variables with meaningless names like A\$,C1%, Q2 etc. to save space. You can give your variables longer, more meaningful names like AMOUNT, NAME\$ etc. and retain these in the listable 'source' version for ease of understanding what the program is doing. But the Applesoft interpreter only recognizes the first 2 characters of a variable name, so variables AMOUNT and AMT would be identical as far as Applesoft is concerned. It will only recognize the AM. CMPRSS uses this fact to reduce your program as much as possible. AMOUNT becomes AM and NAME\$ becomes NA\$. The compressed version is hard to read, but you should never list the compressed version. It will certainly operate the same as the original, but much more efficiently. You should always keep two versions of your program, the original, readable version and the compressed one.

Executing CMPRSS

- 1. Type BRUN CMPRSS (RETURN). This will load CMPRSS at \$9000 and reset HIMEM to protect itself. It also installs the '&' vector to enable CMPRSS to be easily run.
- 2. If your Applesoft program is already in memory, type & (RETURN) and your program will be compressed; otherwise key in or LOAD your Applesoft program from disk and then type & (RETURN). Compression takes a mere 5 seconds or so for the largest program.

It is important to note that you should always SAVE the "uncompressed" version BEFORE you run CMPRSS, or the valuable REMs and meaningful variable names will be lost forever.

If there are no non-existent line numbers, the display on the screen will look something like:

*** PASS 1 *** *** END PASS 1 ***

*** PASS 2 ***

OLD PROGRAM LENGTH: 16224 BYTES NEW PROGRAM LENGTH: 9528 BYTES PROGRAM COMPRESSED BY: 6696 BYTES

*** END PASS 2 ***

If, however, non-existent line numbers have been encountered during Pass #1, they will be reported and your program will not be compressed. The display, in this case, will look something like this:

*** PASS 1 *** 8560 GOSUB4170 9000 GOTO3010 9050 THEN9095 ***END PASS 1 ***

*** NOT COMPRESSED ***

The line numbers of the offending statements are 8560, 9000 and 9050. The non-existent lines are 4170, 3010 and 9095.

The program resides just below DOS from \$9000 to \$94FF and the space from \$9500 to \$95FF is used for the Compressed Line Buffer where the current compressed line is assembled before being written back into the Applesoft program.

Once CMPRSS is installed, your Applesoft programs may be LOADed, changed, SAVEd and CMPRSSed by merely keying & (RETURN). You can even run them and, provided that they never alter HIMEM, POKE any values into memory locations \$9000 to \$94FF, or alter the & vector, CMPRSS will remain unharmed and may be used again and again. If, however, you need the 1.5K bytes which CMPRSS occupies because you are running a very large program, you can reset HIMEM to just below DOS (\$9600) and then, next time CMPRSS is required, you will have to BRUN it from disk again. AICRO"

93E8 6Ø		RTS	
93E9 E6 Ø2	INCNEW	INC NEWPTR ; Incr NEWPTR	0
93EB DØ Ø2		BNE IN1	
93ED E6 Ø3	T114	INC NEWPTR+1	
93EF 6Ø	IN1	RTS	0
93FØ E6 B8 93F2 DØ Ø2	INCOLD	INC OLDPTR ;Incr OLDPTR BNE IN2	
93F4 E6 B9		INC OLDPTR+1	
93F6 6Ø	IN2	RTS	
93F7 18	DECNEW	CLC ;Decr NEWPTR	0
93F8 A5 Ø2		LDA NEWPTR	
93FA 69 FF		ADC #\$FF	_
93FC 85 Ø2		STA NEWPTR	0
93FE A5 Ø3		LDA NEWPTR+1	
9400 85 03		ADC #\$FF	
94Ø2 69 FF 94Ø4 6Ø		STA NEWPTR+1 RTS	0
9405 18	DECOLD		
94Ø6 A5 B8	риосы	LDA OLDPTR	
94Ø8 69 FF		ADC #\$FF	0
94ØA 85 B8		STA OLDPTR	•
94ØC A5 B9		LDA OLDPTR+1	
94ØE 69 FF		ADC #\$FF	0
941Ø 85 B9		STA OLDPTR+1	0
9412 6Ø	DUTATE	RTS	
9413 20 E9 93 9416 A0 00	PUTNEW	JSR INCNEW ;Store Accum in LDY #\$00 ;new prog area	_
9418 91 Ø2		STA (NEWPTR),Y	0
941A 6Ø		RTS	
941B 9D ØØ 95	PUTBUF	STA LINBUF, X ; Put Accum into	
941E E8		INX ;LINBUF	0
941F EØ FD		CPX #\$FD ;Set if LINBUF	
9421 60	OTMOT D	RTS ;is full	
9422 20 FØ 93 9425	GETOLD	JSR INCOLD ;Get a byte from	0
9425 AØ ØØ	GOTOLD	;the old prog LDY #\$00	
9427 B1 B8	doroza	LDA (OLDPTR),Y	
9429 60		RTS	0
942A C9 41	LETTER	CMP #LETTRA ; Is byte a lettr	•
942C 9Ø Ø6		BCC NOLETR ; If < 'A' then	
942E C9 5A		CMP #LETTRZ ; not a letter	_
9430 90 04		BCC ISLETR ; If < 'Z', is 1tr	0
9432 FØ Ø2	NOT FIND	BEQ ISLETR ; If = 'Z', is 1tr	
9434 38 9435 6Ø	NOLETR	SEC ;Set carry, not a letter RTS	
9436 18	ISLETR	CLC ;Clear carry, is letter	0
9437 6Ø	1000111	RTS	
9438 C9 3Ø	NUMBER	CMP #ZERO ; Is byte number?	
943A 9Ø Ø6		BCC NONUMB ; If < 'Ø', not #	0
943C C9 39		CMP #NINE	
943E FØ Ø4		BEQ ISNUMB ; If = '9', is #	
9440 90 02	NONTRE	BCC ISNUMB ;If < '9',is #	0
9442 38 9443 6Ø	NONUMB	SEC ;Set carry,not a number RTS	•
9444 18	ISNUMB	CLC ;Clear carry, is number	
9445 60	IONOID	RTS	0
9446 20 20 20	GOTO	ASC ' GOTO '	
944F 2Ø 2Ø 2Ø	GOSUB	ASC ' GOSUB '	
9458 20 20 20	THEN	ASC ' THEN '	_
946Ø 2A 2A 2A	PASS1A	ASC '*** PASS 1 '	0
946B 2A 2A 2A	PASS1B	ASC I*** END PASS1 '	
9479 2A 2A 2A 948C 2A 2A 2A	ERRMES PASS2A	ASC '*** NOT COMPRESSED ' ASC '*** PASS 2 '	
9497 2A 2A 2A	PASS2B	ASC 1*** END PASS 2 '	0
94A6 4F 4C 44	MESS1	ASC 'OLD PROGRAM LENGTH: '	
94BC 4E 45 57	MESS2	ASC 'NEW PROGRAM LENGTH: '	
94D1 50 52 4F		ASC 'PROGRAM COMPRESSED BY '	0
94E7 2Ø 2Ø 42		ASC ' BYTES '	-
94 e f		END	



Save time and mathematical aggrevation with a compilation of defined functions in a very friendly program

USEFUL

EDITOR'S NOTE

In last month's issue we printed a This program includes the formulas for program that allowed you to easily trigonometric ratios, two formulas access various defined functions. This dealing with matters related to aviation saved time and aggravation when the effect of wind on ground speed and working with mathematical formulas. As a converting temperatures from continuation of this approach, we Fahrenheit to Celsius and vice versa, present the second of three programs plus the formulas that comprise Ohm's which will put a host of valuable Law and determine the resistance formulas and functions at your factor of electrical wires, and finally fingertips. Again we invite you to send the formula that determines future in any defined functions you may be values based on compound interest, using that are not mentioned. The present value and the time span to be submissions we receive will be examined. The structure of the collected and published in a future program is identical to the one

PROGRAM #2

complicated density altitude), the formulas for described above.

Part 2

by Paul Garrison

```
0
            1 REM FUNCTIONS (DELETE THOSE NOT USED IN A PROGRAM)
            2 PI=3.14159
            3 RAD=57.2958
0
                                                                             REM FIND
            47 DEF FNHYP(X,Y)=SQR(X^2+Y^2):
            HYPOTENUSE
                                                                             REM FIND SIDE
            48 DEF FNHX(H,Y)=SQR(H\uparrow2-Y\uparrow2):
            X, HORIZONAL
            49 DEF FNVY(H,X)=SQR(H^{\dagger}2-X^{\dagger}2):
                                                                             REM FIND SIDE
            Y, VERTICAL
                                                                             REM FIND ANGLE A OR B
            5Ø DEF FNANGL(A)=9Ø-A:
                                                                             REM FIND SIDE X
            51 DEF FNX(H,A)=H*COS(A*(PI/180)):
            BY H
             & A
             52 DEF FNY(H,A)=H*SIN(A*(PI/18Ø)):
                                                                             REM FIND SIDE Y
0
            BY H
                                                                             REM FIND A OR B BY
             53 DEF FNB(X,Y)=(ATN(X/Y))*(18\emptyset/PI):
0
             & Y
             6Ø DEF FNWC(WV, WD, MC, MV) =-1*WV*COS((WD-MC-MV)/RAD):
                                                                             REM WIND
             COMPONENT.AI CRAFT
0
             61 DEF FNDENALT(PA,F)=(145426*(1-(((288.15-
             PA*.ØØ1981)/288.15) \dagger{5.2563/((273.15+F)/288.15)) \dagger{1.235})
0
```

```
0
                                                           REM DENSITY ALTITUDE
63 DEF FNFC(F)=(F-32)/1.8:
                                                           REM DEG.F. TO DEG.C.
                                                                                                    0
64 DEF FNCF(C)=(C*1.8)+32:
                                                           REM DEG.C. TO DEG.F.
65 DEF FNVA(V,A)=V/A:
                                                           REM OHM=VOLT/AMPERE
66 DEF FNVO(V,0)=V/O:
                                                           REM AMP=VOLT/OHM
                                                                                                    0
67 DEF FNAO(A,0)=A*0:
                                                           REM VOLT=AMP*OHM
68 DEF FNWR(M,L)=10.4*L/M:
                                                           REM WIRE RESISTENCE
69 DEF FNCP(PV,I,CP)=PV*(1+(I/1ØØ))↑CP:
                                                            REM COMPOUND INTEREST1ØØ REM (PRO-
GRAM TITLE, AUTHOR)
                                                                                                    0
110 REM (TYPE OF BASIC USED)
12Ø GOTO 2ØØ
130 ?"-
14Ø HOME: VTAB(1Ø): RETURN
                                                                                                    0
150 ?: INPUT "Press > RETURN< (Q to quit)
                                              ",R$
155 IF R$="Q" THEN 160 ELSE RETURN
16Ø GOSUB 14Ø:GOSUB 13Ø:?TAB(33) "End.":GOSUB 13Ø:END
                                                                                                    0
19Ø
                                                           REM TESTING FUNCTIONS
200 GOSUB 140:?"Menu:":GOSUB 130:?"Aviation functions:":GOSUB 130
210 ?1, "Wind component"
220 ?2, "Density altitude"
                                                                                                    0
222 ?3, "Convert degrees F. to degrees C."
224 ?4, "Convert degrees C. to degrees F.": GOSUB 130
230 ?"Ratios for right triangles:":GOSUB 130
                                                                                                    0
240 ?5, "Find hypotenuse"
250 ?6, "Find horizontal side (X)"
260 ?7, "Find vertical side (Y)"
270 ?8, "Find angles A and B"
                                                                                                    0
280 ?9, "Find two sides (X & Y) by hypotenuse & angle"
290 ?10, "Find angles A and B by X and Y": GOSUB 130
291 ?"Electrical:":GOSUB 130
292 ?11, "Find ohms"
                                                                                                    0
293 ?12, "Find amperes"
294 ?13, "Find volts"
295 ?14, "Find wire resistence": GOSUB 130
                                                                                                    0
296 ?15, "Compound interest": GOSUB 130
300 ?16, "Exit program": GOSUB 130
310 INPUT "Which?
                           ",WHICH:GOSUB 140
320 ON WHICH GOTO 400,500,600,700,2000,2050,2100,2150,2190,2280,2400,2500,2600,2700,2800,160
                                                                                                    0
400 ?"Find wind component (effect on aircraft in flight)":GOSUB 130
410 INPUT "Wind direction?
                                                   ".WD
420 INPUT "Wind velocity? (knots)
                                                   ",WV
430 INPUT "Magnetic course?
                                                   ",MC
                                                                                                    0
440 INPUT "Magnetic variation? (E= - / W= +)
                                                   ",MV
450 X=FNWC(WV,WD,MC,MV):GOSUB 130
                                               ";X:GOSUB 150:GOTO 200
460 ?"The wind component factor is
                                                                                                    0
500 ?"Find the density altitude":GOSUB 130
                                                   ",PA
510 INPUT "Pressure altitude?
520 INPUT "Temperature? (degrees centigrade)
                                                   ",F
53Ø X=FNDENALT(PA,F):GOSUB 13Ø
                                                                                                    0
540 ?"The density altitude is ";X;" feet.":GOSUB 150:GOTO 200
600 ?"Convert degrees F. to degrees C.":GOSUB 130
610 INPUT "Degrees F.?
                                                                                                    O
62Ø X=FNFC(F):GOSUB 13Ø
630 ?F; " degrees F. equal "; X; " degrees C": GOSUB 150: GOTO 200
700 ? "Convert degrees C. to degrees F.":GOSUB 130
71Ø INPUT "Degrees C.?
                                                                                                    0
72Ø X=FNCF(C):GOSUB 13Ø
730 ?C; degrees C. equal ";X; degrees F.":GOSUB 150:GOTO 200
2000 ?"Find the length of the hypotenuse of a right triangle": GOSUB 130
                                                                                                    O
2010 INPUT "Enter the horizontal length (X)
```

0

```
0
          2020 INPUT "Enter the vertical length (Y)
          2030 X=FNHYP(X,Y):GOSUB 130
0
                                                        ";X:GOSUB 150:GOTO 200
          2040 ?"The length of the hypotenuse is
          2050 ?"Find the length of the horizontal side (X) of a right triangle": GOSUB 130
          2060 INPUT "Enter the vertical length (Y)
                                                             ".Y
          2070 INPUT "Enter the diagonal length (hypotenuse)",H
0
          2080 X=FNHX(H,Y):GOSUB 130
          2090 ?"The horizontal length is
                                                        ";X:GOSUB 15Ø:GOTO 200
          2100 ?"Find the length of the vertical side (Y) of a right triangle": GOSUB 130
                                                        ` ",X
          2110 INPUT "Enter the horizontal length (X)
          2120 INPUT "Enter the diagonal length (hypotenuse)",H
          213Ø XX=FNVY(H,X):GOSUB 13Ø
          2140 ?"The vertical length is
                                                        ";XX:GOSUB 150:GOTO 200
0
          2150 ?"Find the angle opposite side X or Y in a right triangle": GOSUB 130
          2160 INPUT "Enter degrees of one angle
          217Ø X=FNANGL(A):GOSUB 13Ø
          2180 ?"The other angle is ";X;" degrees":GOSUB 150:GOTO 200
0
          2190 ?"Find the two other sides by hypotenuse and the angle"
          2195 ?"between the hypotenuse and the horizontal side":GOSUB 130
          2200 INPUT "Enter length of hypotenuse
0
          2210 INPUT "Enter the degrees of the angle
          222Ø X=FNX(H,A):GOSUB 13Ø
          2225 XX=FNY(H,A)
          2230 ?"The horizontal length is
                                                         ";X
                                                         ";XX:GOSUB 15Ø:GOTO 200
          2275 ?"The vertical side is
          2280 ? "Find the degrees of two angles by sides X and Y": GOSUB 130
          2290 INPUT "Enter horizontal side (X)
                                                             ",X
          2300 INPUT "Enter vertical side
                                            (Y)
0
          231Ø XX=FNB(X,Y):GOSUB 13Ø
          2320 ?"Angle A (opposite X) is ";XX;" degrees":BB=90-XX
          2330 ?"Angle B (opposite Y) is ";BB;" degrees":GOSUB 150:GOTO 200
2400 ?"Find ohms by volts and amperes":GOSUB 130
          2410 INPUT "Volts?
                                                             ",∀
          2420 INPUT "Amperes?
                                                             ",A
          243Ø X=FNVA(V,A):GOSUB 13Ø
0
          244Ø ?X; " ohms ": GOSUB 15Ø: GOTO 2ØØ
          2500 ?"Find amperes by volts and ohms":GOSUB 130
          2510 INPUT "Volts?
          2520 INPUT "Ohms?
❷
                                                             ",0
          253Ø X=FNVO(V,0):GOSUB 13Ø
          2540 ?X; " amperes":GOSUB 150:GOTO 200
          2600 ?"Find volts by amperes and ohms":GOSUB 130
❷
          2610 INPUT "Amperes?
          2620 INPUT "Ohms?
                                                             ",0
          263Ø X=FNAO(O,A):GOSUB 13Ø
          264Ø ?X; " volts":GOSUB 15Ø:GOTO 2ØØ
0
          2700 ?"Find wire resistence by length and mils":GOSUB 130
          2710 INPUT "Length of wire (inches)
          272Ø INPUT "Diameter of wire (mils)
                                                             ",M
0
          273Ø X=FNWR(M,L):GOSUB 13Ø
          2740 ?"Resistence is ";X;" ohms":GOSUB 150:GOTO 200
          2800 ?"Find future value based on interest and compounding periods":GOSUB 130
          2810 INPUT "Present value?
                                                                  $",PV
                                                                  %",I
          2820 INPUT "Annual interest rate?
          283Ø INPUT "Compounding periods (day/month/year)(D/M/Y) ",CP$
          284Ø IF CP$="D" THEN I=I/365.25
          285Ø IF CP$="M" THEN I=I/12
          2860 INPUT "Period of how many years?
                                                                   ",CP
          287Ø IF CP$="D" THEN CP=CP*365.25
          2875 IF CP$="M" THEN CP=CP*12
0
          288Ø X=FNCP(PV,I,CP):GOSUB 13Ø
          2890 ?"The future value is $"; X:GOSUB 150:GOTO 200
0
```

feature

Commodore to to Apple Cassette File Loader

by Art Matheny

Your Apple can read cassette files written by a Commodore VIC-20 or C64 computer with this assembly language program. The file is written into a sequential text file on the Apple's disk. Three types of files are discussed--data files, BASIC programs, and memory ranges.

Requires: Apple II with disk drive and optional printer, Commodore VIC-20 or C64 with C2N cassette drive.

I have a Commodore VIC-20 and a C64 as well as my trusty old Apple II. Of course I have a disk drive for the Apple, but for mass storage with the Commodores I use a C2N cassette tape drive ("Datassette") which works amazingly well. This article shows how the Apple can read cassette files written by either Commodore computer. The method described here can be used to transfer various kinds of data. For example, since I do not presently have an interface to connect my printer to my Commodores, I am using this utility to move BASIC programs to my Apple, where I can make hardcopy listings. It also saves a lot of retyping when I want to convert a Commodore BASIC program to Applesoft. Sorry, though, this program only goes one way. I have not yet taught the Apple to write cassette files that Commodore computers can read, but, with the information given here, I think such a program would not be very

The assembler listing of the main program is shown in Listing 1.

Listing 1 ;COMMODORE-TO-APPLE CASSETTE FILE LOADER 0 ;BY ART MATHENY Copyright @ 1984 0 The Computerist, Inc. Chelmsford, MA Ø1824 ; RUNS ON APPLE II. 0 ;LOADS A TEXT FILE FROM A ; CASSETTE TAPE WRITTEN BY A ; COMMODORE COMPUTER, AND SAVES 0 ; IT AS AN APPLE DISK FILE. : CONSTANTS 0 ØØØ6 SLOT EQU 6 ;SLOT # FOR SAVING FILE 0001 DRIVE EQU 1 ;DRIVE # FOR SAVING FILE ØØCØ ;# OF CHARS IN A BLOCK BLOKLEN EOU 192 0 ØØ1E NAMLEN EQU 3Ø ;# OF CHARS IN FILE NAME ; PAGE Ø VARIABLES 0 ØØØ6 BYTE EQU 6 ;BYTE NOW BEING READ ; ZPAGE TEMP STORAGE 0007 TEMP EQU 7 0008 PTR EQU 8 ; POINTER INTO DATA BUFFER 0 ØØØA ADR EQU \$A ; ADDR OF MESSAGE TO PRINT ØØØC FMPL EQU \$C ;FILE MGR PARMLIST POINTER ; PAGE 3 VARIABLES 0 CHSUM Ø3ØØ EQU \$300 ; CHECK SUM BYTE ; PARITY Ø3Ø1 PAR EQU \$301 Ø3Ø2 KNT EQU \$3Ø2 ;BIT COUNTER 0 ;FLAG: DOING SECOND SCAN 0303 SCAN EQU \$3Ø3 Ø3Ø4 **KDOWN** EQU \$3Ø4 ; COUNT-DOWN COUNTER Ø3Ø5 START EQU \$3Ø5 ; ADDR WHERE BLOCK STARTS 0 Ø3Ø7 FIN EQU \$307 ; ADDR WHERE BLOCK ENDS ;DOS SYSTEM CALLS 0 ;LOCATE PARMLIST ADDR Ø3DC LOCFPL EQU \$3DC Ø3D6 DOSFM EQU \$3D6 ;DOS FILE MANAGER OTHER ADDRESSES 0 LOMEM Ø8Ø1 EQU \$801 ;START OF USABLE MEMORY Ø8Ø6 NAME EQU LOMEM+5 ; FILENAME LOCATION 0 Ø8C2 BODY EQU LOMEM+BLOKLEN+1 ;START OF FILE CØ6Ø TAPEIN EQU \$CØ6Ø ; CASSETTE INPUT PORT ; ROM ROUTINES 0

difficult to do.

	**	
	ECEO Listing 1	
	でしつの	HOME EQU \$FC58 ;CLEAR TEXT SCREEN PRBYTE EQU \$FDDA ;PRINT A HEX BYTE COUT1 EQU \$FDFØ ;OUTPUT TO SCREEN
	FDDA (continued)	PRBYTE EQU \$FDDA ;PRINT A HEX BYTE
0	FDFØ	COUT1 EQU SFDFØ :OUTPUT TO SCREEN
٦		;
		·
	Oddd	OPC COMM
	9000	ORG \$9000
0		;
		;
		;SET IRQ MASK TO PREVENT INTERRUPTS
_		;
0	9000 78	PROG SEI
	7000 10	
		;PRINT HEADING
0		
۳	0444 04 50 70	;
	9001 20 58 FC	JSR HOME
	9004 A9 A3	LDA #MESG5
	9006 85 0A	STA ADR
0	9008 A9 91	LDA /MESG5
	900a 85 0B	STA ADR+1
1	9ØØC 2Ø 62 93	JSR PRMESG
0	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	:
10		;PUT 1ST BLOCK AT BEGINNING OF THE BUFFER
1		•
	ONNE AO MA	; LDA #LOMEM ;FIN = LOMEM
	900F A9 01	LDA #LOMEN ; FIN = LOMEM
0	לע וע כט בבער	STA FIN
	9Ø14 A9 Ø8	LDA /LOMEM
	9Ø16 8D Ø8 Ø3	STA FIN+1
0		;
"		;
		;SET UP POINTERS FOR NEXT BLOCK
0		;
_	9Ø19 AD Ø7 Ø3	
	9Ø1C 8D Ø5 Ø3	STA START ;START —>
	9Ø1F 18	
0	9020 69 CØ	ADC #BLOKLEN ; FIN = START+BLOKLEN
	9022 8D 07 03	STA FIN ;FIN —> LDA FIN+1 ; END OF BLOCK + 1
	9025 AD 08 03	
0	9Ø28 8D Ø6 Ø3	STA START+1
_	9Ø2B 69 ØØ	ADC #Ø
	902D 8D 08 03	STA FIN+1
	9030 C9 90	CMP /PROG ;BUFFER FULL
0	9Ø32 BØ 36	BCS ERR9 ; IF SO, QUIT READING
"	יע עם געע ט∪	
		;
		DEAD A DIOCK
0		;READ A BLOCK
٦		j
		;
	9ø34 A9 Øø	LDA #Ø ;SCAN=Ø:
0	9Ø36 8D Ø3 Ø3	STA SCAN ; LOAD THE BLOCK
"	9039 20 19 92	JSR BLOCK
	903C A9 01	LDA #1 ;SCAN=1:
	9Ø3E 8D Ø3 Ø3	STA SCAN ; VERIFY THE BLOCK
0	9041 20 19 92	JSR BLOCK
		LDA #'.' ;PRINT A PERIOD
	9044 A9 2E	•
	9ø46 2ø fø fd	JSR COUT1
0		;
1		j
		;CHECK FOR END OF FILE
		;
0		DA CMADE DED - CTARE
١٧	9ø49 AD Ø5 Ø3	LDA START ,FIR - START
	904C 85 08	STA PTR
	904E AD 06 03	LDA START+1
0	9051 85 09	STA PTR+1
ľ	9Ø53 AØ ØØ	
1		LDY #Ø ;LOOK AT 1ST CHAR LDA (PTR),Y ; OF BLOCK
	9Ø55 B1 Ø8	CMP #5 ; EOF MARKER
0	9Ø57 C9 Ø5	
١٣	9Ø59 FØ 31	
	9Ø5B C9 Ø2	CMP #2 ;DATA BLOCK
	905D DØ BA	BNE LOOP ; BRANCH IF NOT

Apple has less than 48K of memory, move the origin down to fit the program below DOS, but start it at the beginning of a memory page. Moving the origin will change the machine code for every JSR and JMP.

There are three types of files which I would like to transfer-data files, BASIC programs, and memory ranges. It will be sufficient, though, to transfer data files because, as will be shown later, BASIC programs and memory dumps can both be converted into data files prior to the transfer.

Transfer of Data Files

With a Commodore computer, any kind of data can be written into a tape file. To see how this is done, let's work through a simple example. First put a scratch cassette in the C2N tape drive and either rewind it to the beginning or record the tape counter value. A filename must be selected, say "ANYFILE". A logical file number between 1 and 127 must also be selected. In the following example, the logical file number is 5:

OPEN 5,1,2, "ANYFILE"

The device number is 1, which denotes the cassette drive. The 2 indicates an intention to write to the file and to put an end-of-file marker at the end. Once the file has been opened, data can be written to it with PRINT # statements such as the following:

PRINT #5, "ANY CHARACTER STRING"; CHR\$(13)

FOR K=1 TO 10: PRINT #5,K;CHR\$(13): NEXT

Since more than one file can be open at once (i.e. on other devices), the logical file number, 5 in this example, must be specified. When the program is finished writing, it should close the file:

CLOSE 5

The logical file number used here indicates which file is to be closed. The data file on the tape is now ready for transfer.

Rewind the tape to the beginning of the file and move the tape to a tape player connected to the Apple's cassette input. Now BRUN the cassette file loader. Figure 1 shows the Apple's TV display after a successful load operation. The program prints a period for every "block" that it reads successfully. That lets you know that it is still working, which is a comfort when long files are being loaded.

TEXT FILE READER ROLL TAPE ..END OF FILE

SAVING: ANYFILE

DONE

Figure 1. Typical video display of CTACFL.

If anything goes wrong, the program prints an error message and executes a "break" instruction, thus leaving you in the monitor. To try again, rewind the tape and enter:

9000G

The most likely cause of any error is a misreckoning of the loudness control of the tape player. This is a very touchy setting, and it may take several trials to find the right spot. My advice is to start very loud and to work down in small increments. Other causes of error are less likely. It is possible that there may actually be bad data on the tape, in which case you have to go back to the Commodore and save the file again. Test the Commodore C2N tape drive by saving and then verifying any BASIC program. Maybe the tape medium is bad; try a different tape. If all else fails, try a different tape player, preferably one that is not so noisy.

Listing the File

The cassette file loader puts the data into a sequential text file on the disk. The program in Listing 2, called TEXTLISTER, can list this or any other sequential file. The output can be directed either to the TV or to a printer. RUN this program and give the name of the data file. Compare the output with what the original Commodore program wrote. Such data files can be used as input for Apple programs. See the chapter on sequential files in *The DOS Manual*.

TEXTLISTER replaces any unprintable characters by an "@" sign to show at least that there is a character present.

BASIC Programs

Although there are similarities in syntax between Commodore BASIC

SEARCH THE BLOCK FOR FILE TERMINATION BYTE 9061 B1 08 9663 B0 20 BEQ HOWERUN FILE TERMINATION O DEY BEQ LOOP BRANCH ALWAYS SAVE THE DATA ON DISK > ****** SAVE THE DATA ON DISK > ***** SAVE THE DATA ON DISK > **** SAVE THE DATA ON D	Listing 1 (continued)					
905 F A0 BF 9061 B1 08 F1 LDY #BLOXIEN-1 9063 F0 2D BEQ HOMERUN ; FILE TERMINATION DEF 18 BEQ HOMERUN ; BYTE = 0 9066 D0 P9 BEQ LOOP ; BRANCH ALWAYS 9066 D0 P9 BEQ LOOP ; BRANCH ALWAYS ; ******	; ;		THE B	LOCK FOR F	ILE TERMINATION BYTE	0
9663 FØ 2D 9666 DØ P9 9666 DØ P9 9668 FØ AF 9666 DØ P9 9668 FØ AF SEC LOOP	9Ø5F AØ BF				1	
9068 FØ AF BEQ LOOP ;BRANCH ALWAYS ; ;****** END OF FILE > ****** ;****** SAVE THE DATA ON DISK > ****** ;****** SAVE THE DATA ON DISK > ****** ;****** SAVE THE DATA ON DISK > ****** 906A A9 78 ERR9 LDA #MESG9 906C 85 ØA STA ADR 906C 85 ØA STA ADR 906C 85 ØA STA ADR 90770 85 ØB STA ADR 90775 4C 9D 90 JUP FNAME 9078 C2 D5 C6 MESG9 ASC "BUFFER FULL" 9083 8D STT \$8D ;< RETURN> 9084 D3 C1 D6 ASC "SAVING:" 9088 ØØ EOFMARK LDA #Ø ;INSERT ZERO LDY #1 ; INTO DATA STA (PTR),Y 9099 91 Ø8 STA ADR 9094 85 ØA STA ADR 9095 85 ØB STA ADR 9096 89 ØB STA ADR 9098 85 ØB STA ADR 9098 90 A9 ØB ST	9063 F0 2D 9065 88		BEQ DEY	HOMERUN	;FILE TERMINATION ; BYTE = Ø	0
****** END OF FILE ****** ****** ****** ****** ******	9Ø68 FØ AF				;BRANCH ALWAYS	0
PRINT "BUFFER FULL" PRINT "BUFFER FULT"	;	*****	SAVE	END OF FIL THE DATA (LE > ***** ON DISK > ****	•
906A A9 78 ERR9 LDA #MESG9 906C 85 0A STA ADR 9070 85 0B STA ADR 9075 4C 9D 90 STA ADR 9078 C2 D5 C6 MESG9 ASC "BUFFER FULL" 9083 8D STA SED SC "ETURN> 9081 8D STA SED SC "SAVING:" 9083 8D STA SED SC "SAVING:" 9082 A9 00 EOFMARK LDA #0 ;INSERT ZERO 908E A0 01 STA (PTR), Y ;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;	;		BUFFE	R FULL"		٥
906A A9 78 ERR9 LDA #MESG9 906C 85 0A STA ADR 906C 85 0A STA ADR 906C 85 0A STA ADR 9070 85 0B STA ADR1 9072 20 62 93 JSR PRMESG 9078 C2 D5 C6 MESG9 ASC "BUFFER FULL" 9083 8D STA SEC "SAVING:" 9083 8D STA SEC "SAVING:" 9083 8D STA SEC "SAVING:" 9086 A9 00 EOFMARK LDA #0 ;INSERT ZERO 9088 A0 01 STA (PTR), Y ;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;	; ;					0
906E A9 90	9Ø6A A9 78					
9070 60 90 90 90 90 90 90 90 975 4C 9D 90 90 9076 C2 D5 C6 MESG9 ASC "BUFFER FULL" 9083 8D 9084 D3 C1 D6 ASC "SAVING:" 9088 00	9ø6e a9 9ø		LDA	/MESG9		_
9075 4C 9D 90						0
9083 8D 9084 D3 C1 D6 9088 00 Second	9Ø75 4C 9D 9Ø		JMP	FNAME		
9084 D3 C1 D6		MESG9	ASC BYT	"BUFFER FO	ull" ; < return>	0
;;HIT EOF MARKER BLOCK ;;HIT END GF FILE" ;;HIT EOF MARKER BLOCK ;;HIT END OF FILE" ;;HIT EOF MARKER BLOCK ;;HIT END OF FILE" ;;HIT EOF MARESG6 9094 85 ØA STA ADR 1 LDA /MESG6 9094 85 ØB STA ADR+1 9098 85 ØB STA ADR+1 9098 85 ØB STA ADR+1 9099 85 ØA STA ADR ;;HIND FILE NAME ;;FIND FILE NAME ;;FIND FILE NAME ;;HEADER FILE NAME 9091 89 ØB STA ADR+1 ;IS A FILENAME PRESENT ; 1 LDY #NAMLEN-1 9087 81 ØA FNAME1 LDA (ADR),Y 9089 C9 20 BNE FNAME2 9080 88 BPL FNAME1 ;IF NOT, USE DEFAULT NAME ; 9080 A9 FB	9084 D3 C1 D6		ASC	"SAVING: "		
908C A9 00			DII	ע		0
908C A9 00	;	HIT EOF	MARKI	ER BLOCK		
908E AØ Ø1 9090 91 Ø8 STA (PTR),Y ;; PRINT"END OF FILE" ;; PRINT"END OF FILE" ;; PRINT"END OF FILE" ;; PRINT"END OF FILE" ;; FRINT LDA #MESG6 9094 85 ØA 9096 A9 91 9098 85 ØB 909A 2Ø 62 93 ;; FIND FILE NAME ;	;					0
908E AØ Ø1 9090 91 Ø8 STA (PTR),Y ; ; ; ; ; ; ; ; ; ; ; ; ; ; ; ; ; ;		EOFMARK	LDA	#Ø	; INSERT ZERO	•
; PRINT"END OF FILE" ; PRINT"END OF FILE" ; SPA DR 9092 A9 CC HOMERUN LDA #MESG6 9094 85 ØA STA ADR 9096 A9 91 LDA /MESG6 9098 85 ØB STA ADR+1 9098 85 ØB STA ADR+1 9099 A2 Ø 62 93 JSR PRMESG ; FIND FILE NAME ; FOR ADR ; ADR —> 9091 A9 Ø8 LDA /NAME ; HEADER FILE NAME 9093 85 ØB STA ADR+1 ; IS A FILENAME PRESENT ; GAME I LDA (ADR), Y 9049 C9 20 CMP #\$20 ; SPACE 9048 DØ ØB BNE FNAME1 9047 B1 ØA FNAME1 LDA (ADR), Y 9049 C9 20 CMP #\$20 ; SPACE 9048 DØ ØB BNE FNAME2 9040 B8 BPL FNAME1 ; IF NOT, USE DEFAULT NAME ; IDA #DFALT ; ADR = DFALT 9080 A9 FB STA ADR 9084 A9 91 LDA /DFALT			LDY	#1	; INTO DATA	_
9092 A9 CC			DIR	(1 111/)1		0
9092 A9 CC 9094 85 ØA 9096 A9 91 9098 85 ØB 909A 20 62 93	;	PRINT "EN	VD OF	FILE"		
9094 85 0A STA ADR 9096 A9 91 LDA /MESG6 9098 85 0B STA ADR+1 9090 20 62 93 JSR PRMESG ;;FIND FILE NAME ;;ADR = NAME 9091 A9 08 STA ADR ; ADR —> 9081 A9 08 STA ADR+1 ;;IS A FILENAME PRESENT ;;IS A F	;				AMA AMA AMA	•
9096 A9 91		HOMERUN				
9098 85 0B						0
;;FIND FILE NAME ;;FIND	9ø98 85 ØB		STA	ADR+1		
;FIND FILE NAME ; 909D A9 06 FNAME LDA #NAME ;ADR = NAME 909F 85 0A 90A1 A9 08 90A3 85 0B STA ADR ;ADR> 90A5 A0 1D 90A7 B1 0A 90A9 C9 20 90A9 C9 20 90AB D0 0B 90			12K	PRIMEDG		0
909D A9 06 FNAME LDA #NAME ; ADR = NAME 909F 85 0A STA ADR ; ADR —> 90A1 A9 08 LDA /NAME ; HEADER FILE NAME 90A3 85 0B STA ADR+1 ;;IS A FILENAME PRESENT ;;IS A FILENAME PRESENT ;;IS A FILENAME PRESENT ; 90A5 A0 1D LDY #NAMLEN-1 90A7 B1 0A FNAME1 LDA (ADR),Y 90A9 C9 20 CMP #\$20 ;SPACE 90AB D0 0B BNE FNAME2 90AB B0 0B BNE FNAME2 90AB 10 F7 BPL FNAME1 ;;IF NOT, USE DEFAULT NAME ; 90B0 A9 FB LDA #DFALT ;ADR = DFALT 90B2 85 0A STA ADR 90B4 A9 91 LDA /DFALT	-		LE NAI	/E		_
909F 85 0A STA ADR ; ADR —> 90A1 A9 08 LDA /NAME ; HEADER FILE NAME 90A3 85 0B STA ADR+1 ;;IS A FILENAME PRESENT; ; 90A5 A0 1D LDY #NAMLEN-1 90A7 B1 0A FNAME1 LDA (ADR),Y 90A9 C9 20 CMP #\$20 ;SPACE 90AB D0 0B BNE FNAME2 90AB B0 0B BNE FNAME2 90AB 10 F7 BPL FNAME1 ;;IF NOT, USE DEFAULT NAME ; 90B0 A9 FB LDA #DFALT ; ADR = DFALT 90B2 85 0A STA ADR 90B4 A9 91 LDA /DFALT	;		·····			0
90A1 A9 08 90A3 85 0B STA ADR+1 ;;IS A FILENAME PRESENT ;; 90A5 A0 1D 90A7 B1 0A FNAME1 LDA (ADR),Y 90A9 C9 20 90AB D0 0B BNE FNAME2 90AB D0 0B 90AB 10 F7 BPL FNAME1 ;;IF NOT, USE DEFAULT NAME ; 90B0 A9 FB 90B2 85 0A 90B4 A9 91 LDA #DFALT ;ADR = DFALT 90B4 A9 91 LDA /DFALT		FNAME			,	
90A3 85 0B STA ADR+1 ;; IS A FILENAME PRESENT ; 90A5 A0 1D LDY #NAMLEN-1 90A7 B1 0A FNAME1 LDA (ADR),Y 90A9 C9 20 CMP #\$20 ;SPACE 90AB D0 0B BNE FNAME2 90AD 88 DEY 90AE 10 F7 BPL FNAME1 ;; IF NOT, USE DEFAULT NAME ; 90B0 A9 FB LDA #DFALT ;ADR = DFALT 90B2 85 0A STA ADR 90B4 A9 91 LDA /DFALT			LDA	/NAME		0
;IS A FILENAME PRESENT ; 90A5 A0 1D 90A7 B1 0A FNAME1 LDA (ADR),Y 90A9 C9 20 90AB D0 0B BNE FNAME2 90AD 88 90AE 10 F7 BPL FNAME1 ;;IF NOT, USE DEFAULT NAME ; 90B0 A9 FB 90B2 85 0A 90B4 A9 91 LDA #DFALT ;ADR = DFALT 90B4 A9 91 LDA /DFALT	9ØA3 85 ØB		STA	ADR+1		
90A5 A0 1D	;	IS A FII	LENAM	E PRESENT		_
90A7 B1 ØA FNAME1 LDA (ADR),Y 90A9 C9 20 CMP #\$20 ;SPACE 90AB DØ ØB BNE FNAME2 90AD 88 DEY 90AE 10 F7 BPL FNAME1 ;;IF NOT, USE DEFAULT NAME ; 90B0 A9 FB LDA #DFALT ;ADR = DFALT 90B2 85 ØA STA ADR 90B4 A9 91 LDA /DFALT						0
90AB DØ ØB BNE FNAME2 90AD 88 DEY 90AE 10 F7 BPL FNAME1 ;;IF NOT, USE DEFAULT NAME ; 90B0 A9 FB LDA #DFALT ;ADR = DFALT 90B2 85 ØA STA ADR 90B4 A9 91 LDA /DFALT	90A7 B1 0A	FNAME1			·SPACE	
9ØAE 1Ø F7 BPL FNAME1 ;;IF NOT, USE DEFAULT NAME ; 9ØBØ A9 FB LDA #DFALT ;ADR = DFALT 9ØB2 85 ØA STA ADR 9ØB4 A9 91 LDA /DFALT	9ØAB DØ ØB		BNE		, or non	0
;;IF NOT, USE DEFAULT NAME; 9ØBØ A9 FB				FNAME1		
; 9ØBØ A9 FB	;				ME	0
9ØB2 85 ØA STA ADR 9ØB4 A9 91 LDA /DFALT	;	-				
9ØB4 A9 91 LDA /DFALT					;ADR = DFALT	0
9086 85 0B STA ADR+1	9ØB4 A9 91		LDA	/DFALT		•
	9ØB6 85 ØB		STA	ADR+1		

```
Listing 1 (continued)
                     ;PRINT THE FILENAME
0
     9ØB8 AØ ØØ
                      FNAME2
                               LDY #Ø
     9ØBA A2 1E
                               LDX #NAMLEN
     9ØBC B1 ØA
                      FNAME3
                               LDA (ADR),Y
     9ØBE Ø9 8Ø
                               ORA #$8Ø
                                              ;SET BIT 7
     9ØCØ 91 ØA
                               STA (ADR),Y
     9ØC2 2Ø FØ FD
                               JSR COUT1
     9ØC5 C8
                               INY
     9ØC6 CA
                               DEX
     9ØC7 DØ F3
                               BNE FNAME3
0
                     ;LOCATE PARMLIST
     9ØC9 2Ø DC Ø3
                               JSR LOCFPL
     9ØCC 84 ØC
                               STY FMPL
                                              ;FMPL-->
     9ØCE 85 ØD
                               STA FMPL+1
                                              ; FILE MGR PARMLIST
0
                     ; PUT FILE NAME IN PARMLIST
9ØDØ A5 ØA
                               LDA ADR
     9ØD2 AØ Ø8
                               LDY #8
(3)
     9ØD4 91 ØC
                               STA (FMPL),Y
     9ØD6 A5 ØB
                               LDA ADR+1
     9ØD8 C8
                               INY
     9ØD9 91 ØC
                               STA (FMPL), Y
                     ;OPEN THE OUTPUT FILE
0
     9ØDB A9 Ø1
                               LDA #1
                                              ; CALL TYPE 1 = OPEN
❸
     9ØDD AØ ØØ
                               LDY #Ø
     9ØDF 91 ØC
                               STA (FMPL),Y
     9ØE1 A9 ØØ
                               LDA #Ø
     9ØE3 AØ Ø2
                               LDY #2
     9ØE5 91 ØC
                               STA (FMPL),Y
     9ØE7 C8
                               INY
                               STA (FMPL),Y
     9ØE8 91 ØC
(4)
     9ØEA C8
                               INY
                               STA (FMPL),Y
     9ØEB 91 ØC
     9ØED AØ Ø7
                               LDY #7
                               STA (FMPL),Y
     9ØEF 91 ØC
                                             ;TEXT FILE
     9ØF1 A9 Ø1
                               LDA #DRIVE
     9ØF3 AØ Ø5
                               LDY #5
     9ØF5 91 ØC
                               STA (FMPL),Y
     9ØF7 A9 Ø6
                               LDA #SLOT
     9ØF9 C8
                               INY
     9ØFA 91 ØC
                               STA (FMPL),Y
                     ; PUT BUFFER ADDRESSES IN PARMLIST
❸
                               LDA #WORKAREA
     9ØFC A9 76
                               LDY #$C
     9ØFE AØ ØC
0
     9100 91 0C
                               STA (FMPL), Y
     91Ø2 A9 93
                               LDA /WORKAREA
     91Ø4 C8
                               INY
     91Ø5 91 ØC
                               STA (FMPL),Y
     91Ø7 A9 A3
                               LDA #SECTOR
     91Ø9 C8
                               INY
     91ØA 91 ØC
                               STA (FMPL),Y
     91ØC A9 93
                               LDA /SECTOR
     91ØE C8
                               INY
```

...

and Applesoft BASIC, most programs written for a Commodore computer will require extensive revisions before they will run on an Apple. The cassette file loader could save a lot of retyping, though, by moving programs verbatim from the Commodore to the Apple. First, the BASIC program must be converted to a data file so that it can be transferred. The procedure is straightforward:

- 1. LOAD the program into the Commodore in the usual way.
- 2. Remove the program tape and put in a "scratch" tape.
- 3. Enter the following commands in immediate execution mode:

OPEN 1,1,2,"FILENAME.TXT"
CMD 1
LIST
PRINT #1
CLOSE 1

This writes the program listing into a data file on the tape. It does not make a copy of the original BASIC file, but rather a replica of the program *listing* just as it would appear on the TV. Do not panic if the LIST step above takes 3 times as long as you would expect.

- 4. Rewind the scratch tape and physically move it to the Apple's cassette tape player.
- 5. BRUN the cassette file loader and play the file through.
- 6. You now have a text file on the disk called "FILENAME.TXT". TEXTLISTER can be used to list it. It can be edited with any text editor that can work with "T" type files. In this step it is only necessary to fix the syntax so that it looks like an Applesoft program. Delete the extraneous lines at the beginning and end of the file. Change every "SYS" to "CALL". Make any other changes needed to make it conform to legal Applesoft syntax. It is not essential for the program to be logically correct at this point. Save the edited file.
- 7. Go into Applesoft, give a NEW command if necessary and then (here comes the exciting part) EXEC the text file. This step enters the text file just as if you were typing the whole thing.
- 8. The program is now in memory, and you can LIST it. Give it a name and save it. As a convention, I use the same filename without the ".TXT" suffix. Note that this program now shows up as an "A" type file in the catalog.

9. This program can be worked just like any other Applesoft program, so do whatever it takes to get it running on the Apple.

Memory Dumps & Dissassembly

It is also possible to transfer a range of memory from a Commodore to an Apple. Again, the trick is to first generate a data file. The program in Listing 3 is a Commodore BASIC program which does this. The user is asked to specify the starting and ending addresses of the memory range as well as a file name for the tape file. It then PEEKs each byte of the range and writes that value (as decimal digits) into the tape file. This serves as a useful example of the procedure discussed above for creating a data file. It also serves as an example of a BASIC program that has been transferred to the Apple to get a hardcopy listing, but the listing shown here has been doctored slightly. (The word "CLR" in line 10 was inserted by hand.)

The memory range is written into a data file on the tape. The tape is transferred to the other tape player and loaded into the Apple by the cassette file loader. The data is then loaded into the Apple's memory by the Applesoft program in Listing 4. Note that it does not necessarily have to be loaded into the same address range from whence it came. Use BSAVE to save the memory range as a conventional "B" type file if you wish. The disassembler of the monitor or autostart ROM will work on this.

Commodore Tape Format

This part gets technical, so I am going to start by defining a few terms.

A *cycle* is a complete wave cycle (both half-cycles; for a square wave, both the down and the up phases).

The duration of a cycle is the total time spanned by a complete cycle (both half-cycles).

There are 3 kinds of bits, each consisting of 2 cycles of different durations. The following table gives approximate cycle durations in microseconds:

:	lst cycle	2nd cycle
"1" BIT	500 μs	333 µs
"0" BIT	333	500
SYNC	667	500

Listing 1 (continued)		
91ØF 91 ØC	STA (FMPL),Y	
9111 A9 A3	LDA #BUFFER	_
9113 C8	INY	0
9114 91 ØC	STA (FMPL),Y	
9116 A9 94	LDA /BUFFER	
9118 C8	INY	0
9119 91 ØC	STA (FMPL),Y	•
911B A2 ØØ	LDX #Ø ; NEW FILE IS OK	
911D 2Ø D6 Ø3	JSR DOSFM	
912Ø BØ 6E	BCS DOSERR	0
	;	
	;	
	; POSITION FILE AT START	0
	j	•
0122 40 44	;	
9122 A9 ØA	LDA #\$A ; CALL TYPE \$A =	
9124 AØ ØØ	LDY #Ø ; POSITION	0
9126 91 ØC	STA (FMPL),Y	
9128 A9 ØØ	LDA #Ø	
912A AØ Ø4	LDY #4	_
912C 91 ØC	STA (FMPL),Y	0
912E C8	INY	
912F 91 ØC	STA (FMPL),Y	
9131 A2 Ø1	LDX #1	0
9133 2Ø D6 Ø3	JSR DOSFM	•
9136 BØ 58	BCS DOSERR	
		_
	;	0
	WRITE THE DATA	
4		0
Ø	;	
9138 A9 Ø4	LDA #4 ;CALL TYPE 4 = WRITE	
913A AØ ØØ	LDY #Ø	
913C 91 ØC	STA (FMPL),Y	0
913E A9 Ø1	LDA #1 ;ONE BYTE AT A TIME	_
914Ø C8	INY	
9141 91 ØC	STA (FMPL),Y	_
	THIETALIE DUDDED DOLLED EO	0
	; INITIALIZE BUFFER POINTER TO	
	;1ST BYTE OF ACTUAL DATA	
9143 A9 C2	; LDA #BODY ;PTR> BODY	0
		•
9145 85 Ø8 9147 A9 Ø8	STA PTR	
9147 R9 Ø8 9149 85 Ø9	LDA /BODY STA PTR+1	_
7147 07 07	. SIR FIRTI	0
	;SKIP EVERY 192ND BYTE (BLOCK-TYPE TOKENS)	
	,	
914B A2 BF	; PRINT1 LDX #BLOKLEN-1	0
914D 8E Ø2 Ø3	STX KNT ; CHAR COUNTER	•
9140 SE Ø2 Ø5 915Ø AØ ØØ	PRINT2 LDY #Ø	
9150 AV VV 9152 B1 Ø8	LDA (PTR),Y	
		0
	; ;WATCH FOR END OF FILE,	
	WHICH IS MARKED BY A ZERO BYTE	
		0
9154 FØ 21	; BEQ WRAPUP ;BRANCH IF ZERO	0
9156 Ø9 8Ø	ORA #\$8Ø ;SET BIT 7	
9158 AØ Ø8	LDY #8	
915A 91 ØC	STA (FMPL),Y ;BYTE TO BE WRITTEN	0
915C A2 Ø1	LDX #1	
915E 2Ø D6 Ø3	JSR DOSFM ;< WRITE THE BYTE >	
9161 BØ 2D	BCS DOSERR ; BRANCH IF ERROR	0
/101 DW 20	:	0
	; ;INCREMENT BUFFER POINTER	
	; INC PTR	0
9163 E6 Ø8	INC PTR	0
9163 E6 Ø8 9165 DØ Ø2	INC PTR BNE PRINT3	0
9163 E6 Ø8	INC PTR	0

	*	
List	ing 1 (continued)	
0	9169 CE Ø2 Ø3 916C DØ E2 916E E6 Ø8 917Ø DØ D9 9172 E6 Ø9	PRINT3 DEC KNT ;SKIP 1ST BYTE BNE PRINT2 ;OF EACH BLOCK INC PTR BNE PRINT1 INC PTR+1
0	9174 DØ D5 9176 ØØ	INC PTR+1 BNE PRINT1 BRK;
0		;CLOSE OUTPUT FILE
0	9177 A9 Ø2 9179 AØ ØØ 917B 91 ØC 917D A2 Ø1 917F 2Ø D6 Ø3	; WRAPUP LDA #2 ;CALL TYPE 2 = CLOSE LDY #Ø STA (FMPL),Y LDX #1 JSR DOSFM
	9182 BØ ØC	BCS DOSERR
0		;PRINT"DONE" AND EXIT TO BASIC
•	9184 A9 EØ 9186 85 ØA 9188 A9 91 918A 85 ØB	; LDA #MESG7 STA ADR LDA /MESG7 STA ADR+1 JSR PRMESG
0	918C 2Ø 62 93 918F 6Ø	JSR PRMESG RTS ;EXIT ;
0		; DOS ERROR
8	9192 85 ØA 9194 A9 91 9196 85 ØB	; DOSERR LDA #MESG8 STA ADR LDA /MESG8 STA ADR+1
8	9198 20 62 93 919B A0 0A 919D B1 0C 919F 20 DA FD 91A2 00	JSR PRMESG LDY #\$A LDA (FMPL),Y ;ERROR CODE JSR PRBYTE ;PRINT THE HEX CODE BRK ;ABANDON SHIP
0		; ; ;MESSAGES
0	91A3 AØ AØ AØ 91AF D4 C5 D8 91BF 8D 8D 8D 91C2 D2 CF CC	MESG5 ASC " " ASC "TEXT FILE LOADER" BYT \$8D,\$8D,\$8D ASC "ROLL TAPE"
0	91CB ØØ 91CC C5 CE C4 91D7 8D 91D8 D3 C1 D6	BYT Ø MESG6 ASC "END OF FILE" BYT \$8D ASC "SAVING:"
0	91DF ØØ 91EØ 8D 8D 91E2 C4 CF CE 91E6 8D 8D 8D	BYT Ø MESG7 BYT \$8D,\$8D ASC "DONE" BYT \$8D,\$8D,\$8D,0
0	91EA 8D 91EB C4 CF D3 91FA ØØ	MESG8 BYT \$8D ASC "DOS ERROR CODE:" BYT Ø
0		; ;DEFAULT FILE NAME (30 CHARS)
0	91FB C3 CF CD 92ØA AØ AØ AØ	DFALT ASC "COMMODORE FILE " ASC " " "

Note that the "1" and "0" bit have the same total duration. A byte of data is coded as follows:

sync bit 8 data bits (LSB first...MSB last) parity bit

The parity bit is "1" if the byte parity is even and "0" if the parity is odd. Figure 2 shows a typical byte frame.



Figure 2. Example of tape format for a single byte. The SYNC bit is followed by 8 data bits with the least significant bit first. The value of this byte is thus \$AC in hex. The last bit on the right is the parity bit. Since in this case the number of "1" bits is even, the parity is even, so the parity bit is "1". The parity bit helps to check for errors.

I will use the term "block" to describe the next level of structure. A block contains all the information in the cassette buffer, which is 192 bytes. The format of a block is as follows:

leader tone of continuous 333
microsecond cycles
9 count-down bytes, \$89...\$81
192 data bytes
checksum byte
a single 667 microsecond cycle
about 80 cycles of 333
microseconds [spacer]
9 count-down bytes, 9...1
data bytes (repeated)
checksum byte
a single 667 microsecond cycle
about 80 cycles of 333
microseconds (trailer)

The checksum byte is the EOR of all of the data bytes in the block.

A "file" is simply a sequence of blocks. The first block in the file is a header which contains the file name. The last block is a special End-Of-File marker block, although this can be omitted. The actual end of the file is indicated by a zero byte in the data after the last legitimate character in the final data block.

Overview of the Program

Toward the end of Listing 1 is a subroutine labeled "GETBIT". It watches the cassette input (TAPEIN) for two cycles (down, up, down, up).

The x-register measures the duration of the first cycle, and the y-register measures the duration of the second cycle. A comparison of the two tells whether it is a "1" or a "0". The bit is left in the carry flag so that it can easily be rotated into the data byte.

Obviously, the timing of this program is critical because the cycle durations are measured by counting trips through program loops. That is why the interrupt disable flag is set (SEI instruction) at the top of the program. However, any peripheral device which still slows down the 6502 will interfere with this program and must be removed.

The subroutine labeled "BLOCK" reads any block from a Commodore tape and adds it to a memory buffer. The memory buffer used here begins at \$801 and extends to \$8FFF. Since the data field is repeated on the tape, the program verifies that the second occurrence of the data matches what is in memory.

The end of the file is signaled by a zero byte in the data field. When the file is fully loaded, the program writes a "T" type file with the same name as it finds in the file header. If no name is found, the default name "COMMODORE FILE" is used.

This program uses the DOS File Manager for all disk operations. Beneath Apple DOS by Don Worth and Pieter Lechner explains in detail how to use the File Manager from assembly language.

Summary

Although there may be less cumbersome ways to transfer data between computers, I went with this method because it didn't cost me any money. One could call it a poor man's modem. The success of this program demonstrates the possibility of two other cheap tricks: (1) It should be possible for the Apple to write tape files that are readable by Commodore computers. (2) It should also be possible to have a direct link between the Commodore cassette interface and the Apple cassette interface. The read and write lines would, of course, be crossed over. In addition there would have to be a signal ground connection and a fourth connection from an annunciator output of the Apple's game port to the cassette sense input of the Commodore's cassette port. The latter connection would allow the Apple to simulate the button-down condition of the C2N tape drive.

Listing 1 (continued)	,	*****		
	;* ;* SUBR	* OUTINES *		0
	;*	*		
	;*****	*****		
	;			0
	; READ A	BLOCK		
	;		NIDAKAIN.	0
	; INITIAL.	IZE POINTER & C	CHECKSUM	
	BLOCK		;PTR = START	0
921C 85 Ø8 921E AD Ø6 Ø3		LDA START+1	;PTR> ; START OF BLOCK	
9221 85 Ø9 9223 A9 ØØ		STA PTR+1 LDA #Ø		
9225 8D ØØ Ø3		STA CHSUM		0
	; :READ COL	JNT-DOWN BYTES		
	;			0
9228 A9 Ø9 922A 8D Ø4 Ø3		LDA #9 STA KDOWN	;9 COUNT-DOWN BYTES :COUNTER	
922D A2 Ø6	BLOCK1	LDX #6	,	0
922F 2Ø DA 92 9232 A5 Ø6		JSR RDBYTE1 LDA BYTE		
9234 29 7F		AND #\$7F CMP KDOWN	;CLEAR BIT 7 ;IS IT CORRECT	
9236 CD Ø4 Ø3 9239 DØ 48			; IF NOT, THEN QUIT	0
923B CE Ø4 Ø3 923E DØ ED		DEC KDOWN BNE BLOCK1		
924Ø A2 Ø6		LDX #6		0
9242 DØ Ø2	:	BNE BLOCK3	;BRANCH ALWAYS	
	; READ DAT	TA BYTES		•
9244 A2 ØB	; BLOCK2	LDX #11		
9246 20 DA 92 9249 A5 06	BLOCK3	JSR RDBYTE1 LDA BYTE	; < NEXT DATA BYTE >	
924B 4D ØØ Ø3		EOR CHSUM		•
924E 8D ØØ Ø3 9251 AØ ØØ		STA CHSUM LDY #Ø	; EOR OF ALL DATA	
9253 A5 Ø6		LDA BYTE	TAID OD HEDTEN	0
9255 AE Ø3 Ø3 9258 FØ Ø6		LDX SCAN BEQ BLOCK4	DDANGER TO TOADTHO	
925A D1 Ø8		CMP (PTR),Y BNE ERR2	; VERIFY THIS CHAR	0
925C DØ 31 925E FØ Ø4		DD0 DT00***	;BRANCH ALWAYS	
926Ø 91 Ø8 9262 EA	BLOCK4	STA (PTR),Y NOP	; BRANCH ALWAYS ; STORE THIS CHAR ; TIME DELAY	
9263 EA		NOP		0
9264 E6 Ø8 9266 DØ Ø2	BLOCK5	INC PTR BNE BLOCK6	; INCREMENT ; BUFFER POINTER	
9268 E6 Ø9	DIOCH	INC PTR+1		0
926A A5 Ø8 926C CD Ø7 Ø3	BLOCK6	LDA PTR CMP FIN	;PTR < FIN	
926F A5 Ø9 9271 ED Ø8 Ø3		LDA PTR+1 SBC FIN+1	· I F SO	0
9274 9Ø CE		BCC BLOCK2	; GET ANOTHER CHAR	
	; :READ CHI	ECKSUM BYTE		0
9276 A2 ØB	;	LDX #11		9
9278 20 DA 92		JSR RDBYTE1		_
927B A5 Ø6 927D CD ØØ Ø3		LDA BYTE CMP CHSUM	;DOES IT CHECK	0
928Ø DØ 19		BNE ERR3 RTS	; IF NOT, THEN QUIT	
9282 6Ø	;			0
	;ERROR TI	RAPS		
	,			

L	isting 1 (continued	1)			
0	9285 85 ØA 9287 A9 92		LDA #MESG4 STA ADR LDA /MESG4		Listing 2
0	9289 85 ØB 928B 2Ø 62 93 928E ØØ 928F A9 A7	ERR2	STA ADR+1 JSR PRMESG BRK LDA #MESG2		10 HOME : PRINT "TEXTLISTER" 20 PRINT : PRINT "BY ART MATHENY"
0	9291 85 ØA 9293 A9 92 9295 85 ØB 9297 2Ø 62 93		STA ADR LDA /MESG2 STA ADR+1 JSR PRMESG		30 PRINT 40 PRINT TAB(6); "THIS PROGRAM WILL LIST
0	929A ØØ 929B A9 B4 929D 85 ØA 929F A9 92	ERR3	BRK LDA #MESG3 STA ADR LDA /MESG3		50 PRINT TAB(8); "SEQUENTIAL TEXT FILE." 60 PRINT 70 INPUT "GIVE THE FILE
0	92A1 85 ØB 92A3 2Ø 62 93 92A6 ØØ 92A7 D6 C5 D2		STA ADR+1 JSR PRMESG BRK ASC "VERIFY E		NAME: ";F\$ 80 PRINT 90 PRINT "WHAT SLOT IS THE
0	92B3 ØØ 92B4 C3 C8 C5 92C3 ØØ	MESG3	BYT Ø ASC "CHECK-SU BYT Ø		PRINTER IN (Ø FOR TV)": INPUT SLOT 100 IF SLOT > = Ø AND SLOT < = 7 THEN 110
•	92C4 C3 CF D5 92D4 ØØ 92D5 CE Ø4 Ø3	MESG4	ASC "COUNT-DO BYT Ø DEC KDOWN	WN ERROR"	105 PRINT "ENTER A NUMBER BETWEEN Ø AND 7.": GOTO 90
0		; ; ;READ A BY ;	TE		110 PRINT 120 D\$ = CHR\$ (4): REM < CTRL-D> 130 ONERR GOTO 330
0		; ;WAIT FOR ;			140 PRINT D\$;"PR #";SLOT 150 PRINT : PRINT : PRINT : PRINT
⊕	92DD EØ 43 92DF 9Ø F7 92E1 EØ 56 92E3 BØ F3	RDBYTE1	BCC RDBYTE CPX #\$56 BCS RDBYTE	;1500 HZ CYCLE	160 PRINT "LISTING OF FILE: ";F\$ 170 PRINT : PRINT 180 PRINT D\$;"OPEN ";F\$ 190 PRINT D\$; "READ ";F\$ 200 :
©	92E5 A2 Ø2 92E7 2Ø 55 93 92EA EØ 3Ø 92EC 9Ø EA 92EE EØ 43 92FØ BØ E6		JSR PULSE1	; IF SO, ; LOOK AT NEXT CYCLE ;2000 HZ CYCLE	210 REM 220 REM GET ONE CHARACTER AT A TIME 230 REM
0		; ;DATA BITS ;			240 : 250 GET A\$:A = ASC (A\$) 255 IF A > 31 THEN PRINT "
0	92F2 A9 ØØ 92F4 8D Ø1 Ø3 92F7 A9 Ø8 92F9 8D Ø2 Ø3 92FC 2Ø 32 93			;CLEAR PARITY COUNT ;DO 8 BITS	"; CHR\$ (128 + A);: GOTO 25Ø 26Ø IF A = 13 THEN PRINT " ": GOTO 25Ø
8	92FC 20 32 93 92FF A5 06 9301 6A 9302 85 06 9304 4D 01 03		LDA BYTE ROR A STA BYTE	;ROTATE BIT ; INTO BYTE ;EOR THIS BIT WITH	270 PRINT " @";: GOTO 250: REM UNPRINTABLE CHAR 280: 290 REM
0	9307 8D 01 03 930A CE 02 03 930D D0 ED		STA PAR	;BIT 7 OF ; PARITY COUNT	300 REM ERROR HANDLING ROUTINE 310 REM
	02dE 2d 22 22	;CHECK PAR			320 : 330 PRINT : PRINT : PRINT :
	930F 20 32 93 9312 6A 9313 4D 01 03 9316 10 01 9318 60		JSR GETBIT ROR A EOR PAR BPL ERR1 RTS		PRINT 340 PRINT D\$; "CLOSE "; F\$ 350 PRINT D\$; "PR #0" 360 END
		; ;PARITY ER	ROR		

No. 73 - July 1984

	I I - II		2011 <u>88</u>
	Listing 1 (continued)		
Listing 3	9319 A9 25 931B 85 ØA 931D A9 93 931F 85 ØB	ERR1 LDA #MESG1 STA ADR LDA /MESG1 STA ADR+1	③
10 PRINT"{CLR} SAVE A RANGE OF MEMORY" 20 PRINT"WHAT IS THE":	9321 20 62 93 9324 00 9325 DØ C1 D2 9331 00	JSR PRMESG BRK	0
INPUT"STARTING ADDRESS"; K1 30 PRINT"WHAT IS THE": INPUT"ENDING ADDRESS";		; ; ;READ A BIT	0
K2 40 PRINT"WHAT IS THE": INPUT"FILENAME";F\$; ;SUBROUTINE RETURNS: ; X=DURATION OF 1ST PULSE	0
50 OPEN 1,1,2,F\$ 60 PRINT#1,K1;CHR\$(13) 70 PRINT#1,K2;CHR\$(13) 80 FOR K=K1 TO K2		; Y=DURATION OF 2ND PULSE ; CARRY SET IFF X> Y	0
9Ø PRINT#1, PEEK(K); CHR\$(13) 1ØØ NEXT 11Ø CLOSE 1	9332 A2 Ø5 9334 E8 9335 AD 6Ø CØ 9338 3Ø FA	GETBIT LDX #5 GETBIT1 INX LDA TAPEIN BMI GETBIT1	0
110 CLOSE 1 120 END	933A E8 933B AD 60 C0 933E 10 FA 9340 A0 00	LDA TAPEIN BPL GETBIT2 LDY #Ø	0
Listing 4 10 TEXT : HOME	9342 C8 9343 AD 60 C0 9346 30 FA 9348 C8	GETBIT3 INY LDA TAPEIN BMI GETBIT3	0
20 PRINT "LOADING NUMERIC DATA FROM A TEXT FILE" 30 PRINT "INTO A RANGE OF MEMORY."	9349 AD 60 C0 934C 10 FA 934E 84 07 9350 E4 07	LDA TAPEIN BPL GETBIT4 STY TEMP CPX TEMP	0
40 PRINT 50 INPUT "WHAT IS THE FILENAME ";F\$ 60 PRINT "WHAT IS THE	9352 6Ø	; RTS;; READ A SINGLE PULSE	0
STARTING ADDRESS (ENTER Ø" 70 PRINT "TO PUT IT AT	9353 A2 ØØ 9355 E8	; PULSE LDX #Ø PULSE1 INX	•
THE ORIGINAL ADDRESS)" 80 INPUT A1 90 PRINT CHR\$ (4); "OPEN ";F\$	9356 AD 60 C0 9359 30 FA 935B E8 935C AD 60 C0	LDA TAPEIN BMI PULSE1 PULSE2 INX LDA TAPEIN	٥
100 PRINT CHR\$ (4); "READ ";F\$ 110 INPUT K1: INPUT K2	935F 1Ø FA 9361 6Ø	BPL PULSE2 RTS	•
120 IF A1 = 0 THEN A1 = K1 130 L = K2 - K1 + 1: A2 = A1 + L - 1 140 PRINT		; PRINT MESSAGES	0
150 PRINT "STARTING ADDRESS = ";A1 160 PRINT "ENDING ADDRESS = ";A2	9362 AØ ØØ 9364 B1 ØA 9366 FØ Ø8 9368 Ø9 8Ø	PRMESG LDY #Ø PRMESG1 LDA (ADR),Y BEQ PRMESG2 ;BRANCH IF ZERO ORA #\$8Ø ;SET BIT 7	0
170 PRINT "LENGTH = ";L 180 PRINT 190 FOR K = A1 TO A2	936A 2Ø FØ FD 936D C8 936E DØ F4	JSR COUT1 INY BNE PRMESG1	0
200 INPUT X: POKE K,X 210 NEXT K 220 PRINT CHR\$ (4); "CLOSE ";F\$	937Ø A9 8D 9372 2Ø FØ FD 9375 6Ø	PRMESG2 LDA #\$8D ; RETURN CHAR JSR COUT1 RTS ;	0
230 END		;;FILE MANAGER BUFFERS	0
	9376 93A3 94A3 9377	WORKAREA DFS 1 SECTOR EQU WORKAREA+45 BUFFER EQU SECTOR+256 END	0

63

Subscribe to MICRO... Save 20% and we'll send you a BONUS GIFT

with your subscription!


Receive a coupon good for one MicroDisk of your choice. A \$15.00 Value — FREE!

64

Each Disk contains a variety of programs from Micro, all entered and ready to run on your machine. Saves time, avoids errors.

This offer expires October 31, 1984

Fill out the attached card and mail today!



Each diskette includes all of the programs in BASIC and/or Assembly Source, plus binary 'load-and-go' files. The price of only \$15.00 includes shipping and handling.

SAVE 20%!

Use This Postage-Paid Card To Subscribe...

Or Call **Toll-Free** 1-800-345-8112


(In PA 1-800-662-2444)

(MasterCard and VISA Accepted)

/AICRO SAVE 20%

□YES! Enter my subscription to MICRO for just \$24.00 per year and send me a BONUS GIFT COUPON for one free MicroDisk.

☐ Renew my subscription to MICRO for just \$24.00 and send me a BONUS GIFT COUPON for one free MicroDisk.



MICRO's Newest Software

Micro Disks

Send me the following MicroDisks at \$15.00 each prepaid

- □ MD-1 Master Disk Directory
- ☐ MD-2 Does¹It Monitor
- □ MD-3 Accurate Printer
- ☐ MD-4 Graphic Printer Dump
- ☐ MD-5 COMPRESS

MicroCalc The Full Screen Calculator

Easier than spreadsheet programs, does calculations of unlimited length and complexity on screen, links screens, saves on disk or tape, provides formatted printer output. Contains a 48'page manual and diskette.

MicroCalc for	Commodore 64	\$29. 9 5
MicroCalc for	Apple II/IIe/IIc	\$29.95
MicroColo for	Atori	\$20.05

Please rush the Micro Software checked above to: Name ___ Address ______ City _____ State ____ Zip ____

MA residents add 5% sales tax.

I'm paying by: ☐ Check ☐ MO☐ VISA ☐ MC	
Total Enclosed: \$	_
Visa/MC#	

MICRO's Best Sellers

Mastering Your VIC-20

Contains 8 projects and programs......Utilities, games - even a version of "VisiCalc." All 8 programs on cassette to help you learn faster. Makes learning to program you VIC 20 fun.

☐ Mastering Your VIC 20...\$19.95

What's Where in the Apple

Revised new edition with Apple He information added to original atlas and gazetter. All Apple users will find this book helpful in understanding their machine and essential for mastering it.

☐ What's Where in the Apple @ **\$19.95**

Best Sellers for APPLE Users!

MICRO on the APPLE

Programming aids, utilities, games, enhancements. Together Volumes 1, 2, and 3 contain over 100 programs on diskette. Fully documented and explained.


☐ 3-Volume Gift-Boxed @ \$59.95 □ Vol.2□ Vol.3 \$24.95 ea.

Please rush the MICRO Books I've checked above to:

Address City _____ State ____ Zip____

MA residents add 5% sales tax.

I'm paying by: ☐ Check ☐ MO ☐ VISA ☐ MC Total Enclosed: \$ ____ Visa/MC #___ Exp. Date:___





NO POSTAGE NECESSARY IF MAILED IN THE UNITED STATES

20%!!!! Subscribe to /AICRO

SAVE

Use This Postage
Paid Card to Order
the Next 12 Issues
of MICRO and SAVI
\$6.00 Off
Newsstand Price!

BUSINESS REPLY CARD

FIRST CLASS PERMIT NO. 60, CHELMSFORD, MA

POSTAGE WILL BE PAID BY ADDRESSEE



P.O. Box 6502 Chelmsford, MA 01824



NO POSTAGE NECESSARY IF MAILED IN THE UNITED STATES

BUSINESS REPLY CARD

FIRST CLASS PERMIT NO. 60, CHELMSFORD, MA

POSTAGE WILL BE PAID BY ADDRESSEE



P.O. Box 6502 Chelmsford, MA 01824



Computin
Ideas...
New Book

A Feast 0



NO POSTAGE NECESSARY IF MAILED IN THE UNITED STATES



Best Sellers From

MICRO

BUSINESS REPLY CARD

FIRST CLASS PERMIT NO. 60, CHELMSFORD, MA

POSTAGE WILL BE PAID BY ADDRESSEE



P.O. Box 6502 Chelmsford, MA 01824



by Robert M. Tripp

Requirements: Any BASIC

If you have an assembly listing or the hex dump of a machine language program, getting it to load with BASIC can be a real problem. BASIC likes to work only in decimal, so you must make the conversion from hex to decimal and then type in the DATA statements. For years, MICRO has had to 'waste space' providing both the 'useful' assembly listing and the 'necessary' decimal DATA statement form of the same information. If there was a simple way to input the natural hex information, then this additional dump would not be required.

One solution is presented here in Listing 1. It is a simple, short BASIC program that will load hexidecimal information. It is best understood through a brief example. Suppose that you have an assembly program that starts as follows:

Ø33C A5 7A ENTER LDA TXTPTR Ø33E 8D 7Ø Ø3 STA TEMPLO Ø341 A5 7B LDA TSTPTR1

and so forth. Normally you would have to convert the hex information: A5 7A 8D 70 03 A5 7B etc. into the decimal equivalents to generate the following DATA statement:

DATA 165,122,141,112,3,165,123

The HEX Loader lets you use a DATA statement of the form:

DATA "A57A8D7ØØ3A57B"

Listing 1

- 10 REM HEX LOADER R.M.TRIPP
- 11 READ X\$:Z=LEN(X\$):GOSUB 17: MS=X:Z=2
- 12 READ HX\$:J=1
- 13 X\$=MID\$(HX\$,J,2)
- 14 IF X\$="XX" THEN END
- 15 IF X\$="YY" THEN GOTO 12
- 16 GOSUB 17:POKE MS,X:MS=MS+1: J=J+2:GOTO 13
- 17 X=Ø:FOR I=1 TO Z: Y=ASC(MID\$(X\$,I,1)):IF Y > 57 THEN Y = Y - 7
- 18 Y=Y-48:X=X*16+Y:NEXT:RETURN

which is obviously much easier to generate.

Using Hex Loader

The first DATA statement must be the hex address at which the hex information is to start loading. The remaining DATA statements each consist of an ASCII string that contains the hex data, terminated by the nonhex ASCII pair "YY". The end of hex information is indicated by the non-hex ASCII pair "XX". For example:

10000 DATA "033C" 10010 DATA "A57A8D7003A57BYY" 10020 DATA "8D7103A900857AA902XX"

The program was written to fit neatly between lines 10 and 20 of your typical BASIC program. You may want to change line 14 so that it performs a GOTO when done loading instead of the current END. That is the only change that should be required to add this utility to your programs.

Hex DATA Generator

The second listing is a special program for the Commodore 64 that generates the BASIC DATA statements from information already existing in memory. You may already have the information in memory from an assembly, from entering it through a monitor, or as the result of running a program. You specify the BASIC line number to start using for the DATA statements and the memory start and ending addresses. The program automatically generates all of the DATA statements required by the Hex Loader and then automatically deletes itself, leaving just the Hex Loader and the DATA statements. It is really pretty neat - and fun to watch in operation, since most of the action is on the screen. And, it can save you a lot of time.

A short BASIC utility that loads DATA written in Hexidecimal notation. A special version for the C-64 generates the DATA statements.

Listina 2

- 1 REM HEX MAKER R.M. TRIPP
- 2 Z=4:INPUT "{CLEAR}BASIC LINE NUMBER: "; LN
- 3 INPUT "HEX START ADDR: ";X\$: MS\$=X\$:GOSUB 3Ø:MS=X
- 4 INPUT "HEX LAST ADDR: ":X\$: GOSUB 30:ME=X
- 5 PRINT "{CLEAR}"; MID\$(STR\$(LN),2);" DATA "; CHR\$(34); MS\$; CHR\$(34): LN=LN+1Ø:K=1:GOTO 7
- 6 PRINT "{CLEAR}";:K=Ø
- 7 FOR I=K TO 6: PRINT MID\$(STR\$(LN),2); " DATA "; CHR\$(34);
- 8 FOR J=ØTO1Ø:X=PEEK(MS): GOSUB 50:PRINT HL\$;:MS=MS+1
- 9 IF MS > ME THEN PRINT "XX"; -:I=6:

J=11

- 1Ø NEXT J:PRINT "YY";CHR\$(34): LN=LN+10
- 11 NEXT I:PRINT"LN=";LN;": MS=":MS: ":ME=":ME
- 12 IF MS> ME THEN PRINT" (DOWN2) GOTO 14":GOTO 16
- 13 PRINT "{DOWN2}GOTO 6":GOTO 16
- 14 PRINT "{CLEAR}";:FORI=1T08: PRINT I:NEXT:PRINT "GOTO 15": GOTO 16
- 15 PRINT "{CLEAR}";:FORI=9T016: PRINT I:NEXT
- 16 POKE 631,19:FOR I=1 TO 9: POKE 631+I,13:NEXT: POKE 198,10:END
- 20 REM HEX LOADER R.M.TRIPP
- 21 READ X\$:Z=LEN(X\$):GOSUB 3Ø: MS=X:PRINT "{CLEAR}LOADING FROM "; X\$; " TO "; :Z=2
- 22 READ HX\$
- 23 FOR J=1 TO 99 STEP 2: X\$=MID\$(HX\$,J,2)
- 24 IF X\$="XX" THEN MS=MS-1: GOSUB 40:PRINT MS\$:END
- 25 IF X\$="YY" THEN J=99:GOTO 27
- 26 GOSUB 30:POKE MS,X:MS=MS+1
- 27 NEXT:GOTO 22
- 3Ø X=Ø:FOR I=1 TO Z: Y=ASC(MID\$(X\$,I,1)):IF Y > 57 THEN Y = Y - 7
- 31 Y=Y-48:X=X*16+Y:NEXT:RETURN
- 40 X=INT(MS/256):GOSUB 50: MS\$=HL\$:X=INT(MS-X*256): GOSUB 50:MS\$=MS\$+HL\$:RETURN
- 5Ø H=INT(X/16):L=INT(X-H*16): IF H> 9 THEN H=H+7
- 51 IF L> 9 THEN L=L+7
- 52 HL\$=CHR\$(H+48)+CHR\$(L+48): RETURN



Circlesfor theCommodore 64

O by Lester Cain

 \circ

An interesting mathematical way to plot circles on the C-64

Editor's Note: For easy method of entering hex object into a BASIC program, see Hex Loader, by R. Tripp, page 65.

The programs contained in this article will give a theory behind creating circles on a Commadore 64 specifically, but generally on any 6502 computer with HiRes capabilities. Also, it gives necessary code to implement circles in a game or business type analysis.

Let us first discuss the problems associated with creating a circle in a HiRes environment. In an 8 bit screen memory each memory address is made up of bytes containing 8 bits in some kind of sequential fashion. Unfortunately, most of the more popular computers do not do this in the same way. Therefore, a universal method has been developed to visualize this screen memory in a way common to all configurations. This universal way of looking at a graphics screen is referred to as World Coordinates X and Y, taken from common graphing methods, where X is the horizontal axis and Y is the vertical axis. The problem then is to draw a circle in this X and Y environment. Using the X and Y outlook, the only time the actual screen layout comes into effect is when actually setting the computed bit at its computed spot in the maze.

	; CIRCLE DRAWING ROUTINES ; PLOTS HIRES CIRCLE ON THE			
	; COMMODORE 64.			
	; CODE BY: LESTER CAIN			
	; EXTERN.	AL GLOBL VARIA	BLES	0
Ø33C	ST	EQU \$33C		
Ø33C Ø33D	X1LO X1HI	EQU ST EQU ST+1		0
Ø33E	Y1L0	EQU ST+2		
Ø344 Ø345	CXLO	EQU ST+8 EQU ST+9		
Ø346	CY	EQU ST+1Ø		•
Ø347 Ø348	RAD MODE	EQU ST+11 EQU ST+12		
ØØBØ	SPLO	EQU \$BØ		0
ØØB1	SPHI ;	EQU SPLO+1		
CØØØ		ORG \$CØØØ		0
	,	: PLOT A CIRCL	E IN HIRES	
	,	Y CONDITIONS: AND CY SET BY	CALLING	
	; RA	DIUS SET IN GL		•
		CONDITIONS: RCLE IS DRAWN	IN HIRES	
	;			0
CØØØ AD 47 Ø3 CØØ3 8D 79 CØ	CIRCLE	LDA RAD STA DX	;FETCH RADIUS ;SAVE AS FIRST DX	
CØØ6 A8		TAY	;COPY RAD TO Y	
CØØ7 2Ø 2C C1 CØØA 8D 77 CØ		JSR MULT8 STA RSQLO	;AND SQUARE IT ;SAVE FOR COMP.	0
CØØD 8C 78 CØ		STY RSQHI	;AND THE HI BYTE	
CØ1Ø A9 ØØ CØ12 8D 7A CØ		LDA #\$Ø STA DY	;ZERO DY	0
CØ15 2Ø 7B CØ		JSR COMPXY	;PLOT 1ST 4 DOTS	
CØ18 EE 7A CØ	LOOP	INC DY	;LEG +1	0
CØ1B AD 79 CØ CØ1E CD 7A CØ		LDA DX CMP DY	;45 DEGREES YET	•
CØ21 3Ø ØC		BMI LOOP1	;PLOT OTHER HALF	
CØ23 AC 7A CØ CØ26 2Ø FE CØ		LDY DY JSR COMLEG	;COMP OTHER LEG ;PLOT ANOTHER 1	•
CØ29 2Ø 7B CØ		JSR COMPXY	. FORGED TIME	
CØ2C 18 CØ2D 9Ø E9		CLC BCC LOOP	; FORCED JUMP	0
COOR AD /C do	; TOOD1		OPE THE DADING	
CØ2F AD 47 Ø3 CØ32 8D 7A CØ	LOOP1	LDA RAD STA DY	GET THE RADIUS	
CØ35 A9 ØØ		LDA #\$ØØ	;ZERO DX	0
CØ37 8D 79 CØ CØ3A 2Ø 7B CØ		STA DX JSR COMPXY	; COMPUTE THIS BAT.	
CØ3D EE 79 CØ	LOOP2	INC DX LDA DY	; INC Y	0
CØ4Ø AD 7A CØ CØ43 CD 79 CØ		CMP DX	;CHECK FOR = WILL ;MEAN CIRCLE COMP	
CØ46 3Ø 2D		BMI DONE	; CIRCLE DON	_
CØ48 AD 79 CØ CØ4B 8D 76 CØ		LDA DX STA TEMP	;SWAP FUNCTIONS	0
CØ4E AD 7A CØ		LDA DY		
CØ51 8D 79 CØ CØ54 AD 76 CØ		STA DX LDA TEMP		0
CØ57 8D 7A CØ		STA DY	;SWAP DONE	
CØ5A AC 7A CØ CØ5D 2Ø FE CØ		LDY DY JSR COMLEG	COMP. OTHER LEG; COMPUTE NEW LENG	0
CØ6Ø 8D 76 CØ		STA TEMP		

Announcing New Software From MICRO

- ★ Mastering Your Vic-20(Cassette)
- ★ Mastering Your Atari(Diskette)
- ★ Mastering Your Commodore 64(Diskette)

Eight entertaining major projects on cassette or diskette, plus a 160-190 page book, teach you BASIC programming the easy way. Run the programs, see what they do, how they are constructed and how they work.

Projects include Microcalc (display calculation program for complex math), Player (compose and edit songs on your keyboard), Master (guessing game for 1-2 players), Clock (character graphics), and four more.

Each package only \$19.95 (C-64 available in Sept.)

MicroCalc

Faster and easier to use than spreadsheet programs, this full screen calculator is useful in business, home and school. A speedy way to learn BASIC expressions if you don't already know them.

There is no limit to the length or complexity of calculations and screens can be automatically linked, saved on disk or cassette, and customized.


> Only \$29.95. Available for C-64 Apple II/IIe, Atari

Micro, P.O. Box 6502 Chelmsford MA 01824 617/256-3649

Visa and Mastercard Accepted

CØ63 AD 7A CØ	LDA DY		
CØ66 8D 79 CØ CØ69 AD 76 CØ CØ6C 8D 7A CØ	STA DX LDA TEMP STA DY		0
CØ6F 2Ø 7B CØ CØ72 18 CØ73 9Ø C8		;COMPUTE NEW SET	0
CØ75 6Ø CØ76 ØØ CØ77 ØØ CØ78 ØØ CØ79 ØØ	DONE RTS TEMP BYT Ø RSQLO BYT Ø RSQHI BYT Ø DX BYT Ø	;RETURN TO CALL ;TEMP STORAGE	•
CØ7A ØØ	DY BYT Ø		0
	; COMPXY: COMPUTES X,Y ; IN EACH QUADRANT FE ; ENTRY CONDITIONS: ; DX, DY COMPUTED BY	ROM DX,DY	0
	; EXIT CONDITIONS: ; A DOT IS PLOTTED IN		0
	; OF THE FOUR QUADRAM ; X1L AND Y1L ARE THE		
	; X2L AND Y1L ARE THE ; X2L AND Y2L ARE THE ; X1L AND Y2L ARE THE :	OFFSET IN 3	©
CØ7B AD 45 Ø3 CØ7E 8D F9 CØ CØ81 8D FB CØ CØ84 AD 44 Ø3	STA X1H STA X2H	;HI CENTER ;RT QUADS. ;LT QUADS. ;CENTER LO	0
CØ87 18 CØ88 6D 79 CØ	CLC	CENTER LO	0
CØ8B 8D F8 CØ CØ8E 9Ø Ø8 CØ9Ø AD 45 Ø3 CØ93 DØ Ø3		; NO OVERFLOW ; IS HI ON ; SKIP INCREM.	•
CØ95 EE F9 CØ	;	;UP RT HI+1	0
CØ98 AD 44 Ø3 CØ9B 38 .	SEC	;CENTER X ;-DX	
CØ9C ED 79 CØ CØ9F 8D FA CØ CØA2 BØ Ø3 CØA4 CE FB CØ	SBC DX STA X2L BCS CIP2 DEC X2H	; NEW PLOT X LO ; NO BORROW ; HIBYTE OF X-1	0
CØA7 AD 46 Ø3		; CENTER Y	0
CØAA 18 CØAB 6D 7A CØ	CLC ADC DY	;+ DY	
	;	;NEW PLOT Y LO	0
CØB1 AD 46 Ø3 CØB4 38 CØB5 ED 7A CØ	SEC	;CENTER Y AG. ;-DY	0
CØB8 8D FD CØ	STA Y2L	; LO VALUE NEW Y	
	; TRANSFER NEW VALUES T ; AND PLOT THE FOUR NEW ;		0
CØBB AD F8 CØ CØBE 8D 3C Ø3 CØC1 AD F9 CØ	LDA X1L	;UPPER RT. QD. ;NEW X LO ;NOW HI VAL.	0
CØC4 8D 3D Ø3 CØC7 AD FC CØ	STA X1HI	•	
CØCA 8D 3E Ø3		; NOW DO Y ; ONLY LO VAL. ; PLOT UP RT.	0
	;		
CØDØ AD FA CØ CØD3 8D 3C Ø3 CØD6 AD FB CØ	LDA X2L STA X1LO LDA X2H	;GET NEW X ;Y DOES NOT ;CHANGE	0

©	CØD9 8D 3D Ø3 CØDC 2Ø 78 C1		STA X1HI JSR PLOTXY	;THIS TIME ;PLOT UP LT	
0	CØDF AD FD CØ CØE2 8D 3E Ø3 CØE5 2Ø 78 C1		LDA Y2L STA Y1LO JSR PLOTXY	; CHANGE Y THIS ; TIME ; PLOT LWR LT.	
•	CØE8 AD F8 CØ CØEB 8D 3C Ø3 CØEE AD F9 CØ		LDA X1L STA X1LO LDA X1H	;CHANGE X THIS ;TIME ;SO WE CAN	
⊗	CØF1 8D 3D Ø3 CØF4 2Ø 78 C1 CØF7 6Ø CØF8 ØØ		STA X1HI JSR PLOTXY RTS BYT Ø	;PLOT LWR RT. ;RETURN	
•	CØF9 ØØ CØFA ØØ CØFB ØØ CØFC ØØ		BYT Ø BYT Ø BYT Ø BYT Ø		
0	CØFD ØØ	Y1L Y2L	BYT Ø		
			COMPUTES UNKNO	WN LEG OF TRIANGLE.	
•		;EXIT CON		N ACC., DY IN Y.	
•	CØFE 98 CØFF 20 2C C1	COMLEG	TYA JSR MULT8	;GET DY :DY*DY	
	C1Ø2 8D 2A C1		STA TEDYL	RETURN LO BYTE	
0	C1Ø5 8C 2B C1 C1Ø8 AD 77 CØ		LDA RSQLO	;R LO	
	C1ØC ED 2A C1		SEC SBC TEDYL	;R LO -DY LO	
0	C1ØF 8D 2A C1 C112 AD 78 CØ		STA TEDYL LDA RSQHI	;R HI	
	C115 FØ Ø6 C117 ED 2B C1		LDA RSQHI BEQ XY1 SBC TEDYH	;NO HI BYTE ;R HI -DY LO	
•	C11A 8D 2B C1 C11D AD 2A C1		STA TEDYH LDA TEDYL	;(R)-(DY)LO	
	C12Ø AC 2B C1 C123 2Ø 45 C1		LDY TEDYH	;HI BYTE; SQRT OF	
©	C126 8D 79 CØ		STA DX	;SAVE FOR DX	
	C129 6Ø C12A ØØ	TEDYL	RTS BYT Ø	;(R)-(DY)	
0	C12B ØØ	TEDYH ;	BYT Ø		
		; ENTRY C	8 BITS BY 8 BI		
⊗		; MULTIPLICAND IN Y, MULTIPLIER IN ACC. ; EXIT CONDITIONS: ; LO BYTE IN ACC. HI BYTE IN Y			
•	ØØAC ØØAD ØØAE	; ANSLO PLIER CAND	EQU \$AC EQU ANSLO+1 EQU ANSLO+2		
0	C12C 85 AD	; MULT8	STA PLIER	;SAVE MULTIPIER	
	C12E 84 AE C13Ø A9 ØØ		STY CAND LDA #\$ØØ	;SAVE MULTICAND ;INIT FIRST VALUE	
0	C132 AØ Ø8	MITT 1	LDY #\$Ø8	COUNTER 8 BITS	
	C134 46 AD C136 90 03	MUL1	LSR ALIER BCC MUL2	;TST NEXT BIT ;IF OFF ROUND	
©	C138 18 C139 65 AE		CLC ADC CAND	;IF ON, ADD	
	C13B 6A C13C 66 AC	MUL2	ROR A ROR ANSLO	;SHIFT ANSWER 1	
0	C13E 88 C13F DØ F3		DEY BNE MUL1	;DEC POS. COUNTER ;LOOP 8 TIMES	



Refer to Figure 1 as this discussion proceeds. The first step will be to define the center of the circle, referred to as CX and CY. Any value will do for a starter, of course assuming it will fit into the screen limitations. Let it be CX = 100 and CY = 100 for an even set of figures to add to and subtract from. Pick out a nice radius for the circle, say R = 50. Divide the circle into 4 quadrants and picture inside each quadrant a right triangle. One side will be DX, the other side DY and the hypotenuse is the Radius. The first point(s) to plot will be on the Radius. No problem so far; the first four points are just + or - from the center of the circle. But this is the end of the easy part. To compute the next point, add one to the value DY and using the pythagorean theorem, compute DX. This formula says the unknown leg is equal to the square root of the (hypotenuse sq. - the known leg sq.). Since this value is the same in all of the 4 quadrants, only one computation is needed. Depending on which quadrant the point is in will determine whether the values DX and DY are added to or subtracted from the center CX,CY values. In quadrant 1, DX is positive and DY is negative. Figure 1 gives each quadrant DX and DY values. To get the circumference point in terms of X and Y, the DY and DX values will be

algebraically added to the CX and CX center for each point on the circle. Now, it is time to call the plotting routine 4 times, once for each quadrant. Also this is where the plotting routine is more or less machine
dependent.
Continue incrementing DY until it
is $>$ = DX. This will plot half of the
circle from the horizontal axis right and

Continue incrementing DY until it is > = DX. This will plot half of the circle from the horizontal axis right and left. When this point is reached, to make the circle come together in a neat fashion, it is necessary to swap DX and DY and plot from the top and bottom towards the already plotted portion of the circle. Continuing the plot without the swap will leave gaps at the vertical axis, because DY has become larger than DX, stretching integer arithmetic beyond its limits of accuracy.

Listing 1 is the Basic loader to load the machine code into memory. Type it in carefully and save often, especially before trying to run it. The last 39 bytes is a screen clear routine. Listing 2 is a short demo to exercise the code. Type it and save it also. Run the loader first, then the demo routine. If all the data statements were correct, the demo will draw four sets of circles converging at a peak in the center of the screen. These two routines are limited to the Commodore 64 HiRes screen.

Some explanation of the Demo is in order to explain how to use the Circle function.

Line 130	Sets up the storage in the cassette buffer and equates the variables of the circle parameters. CL is the center, X value lo, Ch X value hi.
Line	
140	Video chip address, CY is storage for center of the circle.
Line	
150	Turns on the HiRes 0 \$2000 and clears it.
Line	
160	Sets the mode bit to draw.

C141 A8 C142 A5 AC C144 6Ø			;Y=HI BYTE ;A=LO BYTE	•
	; ENTRY C ; LO BYTE	6 BIT SQUARE R ONDITIONS: IN ACC., HI B		0
	; SQRT OF	NDITIONS:		0
ØØAC ØØAD ØØAE ØØAF	; LO HI LO1 HI1	EQU \$AC EQU LO+1 EQU LO+2 EQU LO+3		0
C145 85 AC C147 84 AD C149 A2 Ø1	; SQRT	STA LO STY HI LDX #\$Ø1	;SAVE LO BYTE ;SAVE HI BYTE ;START WITH FIRST 1	0
C14B 86 AE C14D CA C14E 86 AF C15Ø 38	LOP	STX LO1 DEX STX HI1 SEC	;SUBTRACTION REG ;SQRT =Ø	0
C151 A5 AC	ьог	LDA LO TAY	;SAVE REM IN Y	0
C153 A8 C154 E5 AE C156 85 AC C158 A5 AD C15A E5 AF		SBC LO1 STA LO LDA HI SBC HI1	;SUB ODD FROM LO ;ONE REM ;SUB 1 FROM HI	0
C15C 85 AD C15E 9Ø ØD C16Ø E8		STA HI BCC DNE INX	;HI REMAINDER ; RESULT	0
C161 A5 AE C163 69 Ø1		LDA LO1 ADC #1	;ADD 1 + CARRY	
C165 85 AE C167 9Ø E7 C169 E6 AF		STA LO1 BCC LOP INC HI1	;NO NEED TO UP HI ;HI SUB +1	0
C16B DØ E3 C16D 86 AC C16F C4 AC C171 9Ø Ø2	DNE	BNE LOP STX LO CPY LO	;CHECK FOR ROUND ;REM< N	•
C171 90 02 C173 E6 AC C175 A5 AC C177 60	RETS	BCC RETS INC LO LDA LO RTS	;ROUND UP ;PUT SQRT IN ACC.	0
	; • DI OTYV•	PLOTTING ROUTI	NIE.	•
	;USED IN ;ENTRY CO ; MODE IS	GRAPHICS HIRES NDITIONS: SET TO Ø,1,2		0
	; Y IS IN ;EXIT CON		IN HIRES SCREEN	0
C178 AD 3C Ø3 C17B 48 C17C 29 Ø7	PLOTXY	LDA X1LO PHA AND #\$Ø7	;LINE=XAND7	0
C17E 8D 32 C2 C181 68		STA LINE PLA		_
C182 29 F8 C184 85 BØ C186 AD 3D Ø3		AND #\$F8 STA SPLO LDA X1HI	;STRIP X OF LO 3 BITS ;INITIAL POINT	0
C189 85 B1 C18B AD 3E Ø3		STA SPHI LDA Y1LO	;HI BYTE	0
C18E 29 Ø7 C19Ø 18		AND #\$Ø7 CLC	;STRIP Y OF HI 5 BITS	
C191 65 BØ C193 85 BØ		ADC SPLO STA SPLO	;AND ADD TO INIT.	0

	C195 A9 ØØ		LDA #\$ØØ	;ADD IN ANY CARRY		
	C197 65 B1		ADC SPHI	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,		
_	C199 85 B1		STA SPHI			
(2)	C19B AD 3E Ø3		LDA Y1LO	;ROW=INT(Y/8)		
	C19E 4A		LSR A	, , ,		
	C19F 4A		LSR A			
(3)	C1AØ 4A		LSR A			
•	C1A1 A8		TAY	GIVES INDEX	Line	
	C1A2 CØ 19		CPY #25	;DISALLOW OUTSIDE	170	Initial values of Radius,
•	C1A4 1Ø 2C		BPL RETP	GRAPHICS RANGE	.~	center X and Y.
•	C1A6 B9 ØØ C2			GET LO OFFSET	Line	
	C1A9 18 C1AA 65 BØ		CLC ADC SPLO	;ADD TO LO 3 OF Y	180-250	Draws the four sets of
_	Clac 85 BØ		STA SPLO	;AND INITIAL POINT		circles.
0	C1AC 89 B9 C2			GET HI OFFSET	Line	
	C1B1 65 B1		ADC SPHI	,	260	Kills some time, changes
	C1B3 85 B1		STA SPHI			background color and starts
®		;			1	over again.
•	C1B5 AD 48 Ø3	DETMOD	LDA MODE	;MODE Ø,1,2	Line	
	C1B8 FØ 19		BEQ ANDBIT CMP #2	;CLEAR WITH AND	280	If CX is > 255 then make
0	C1BA C9 Ø2 C1BC FØ 29		BEQ XORBIT	;CLR OR SET?		low value -255 and sets hi X
•	C1BE C9 Ø1		CMP #1	, car on but		to 1.
	C1CØ DØ 1Ø		BNE RETP	;BAD VALUE	Line	
	P	;		-	290	Poke the Center value of
•	C1C2 98	SETBIT	TYA	;SAVE Y		Circle to area for the
	C1C3 48		РНА			machine code to use. Set
	C1C4 AC 32 C2		LDY LINE	; INDEX	l l	the Radius and draw the cir-
	C1C7 B9 F8 C1		LDA BITTAB,Y	;BIT VALUES		cle.
	C1CA AØ ØØ		LDY #\$ØØ	GET CDEC DIT	Line	_
	C1CC 11 BØ C1CE 91 BØ		ORA (SPLO),Y STA (SPLO),Y	;SET SPEC. BIT	310	Resets the screen to nor-
®	C1DØ 68		PLA	;RESTORE Y		mal LoRes mode and quits.
	C1D1 A8		TAY	,		GOTO 310 after a break to
	C1D2 6Ø	RETP	RTS		7:	reset.
®		;			Line	Call screen clear routine.
•	C1D3 98	ANDBIT	TYA		320	Call screen clear foutine.
	C1D4 48		PHA		The	a maramatar ara magaggary to
_	C1D5 AC 32 C2 C1D8 A9 FF		LDY LINE LDA #\$FF	;USE RECIPROCAL	draw the	e parameter are necessary to
8	C1D8 A9 FF		SEC	, ODE RECTRICORE		nter X lo and Center X hi
	C1DB F9 F8 C1		SBC BITTAB,Y	;OF SET FUNCTIONS		CL and CH in Demo.
_	C1DE AØ ØØ		LDY #Ø	•		nter Y lo value. (0-200). CY in
●	C1EØ 31 BØ		AND (SPLO),Y		Demo.	inter 1 10 varue. (0-200). C1 in
	C1E2 91 BØ		STA (SPLO),Y		1	ius (0-255). R in Demo.
	C1E4 68		PLA		J) A lau	ius (0-255). K in Demo.
0	C1E5 A8		TAY		The	circle will wrap around on the
	C1E6 6Ø		RTS			nd will clip at Y greater than
	C1E7 98	; XORBIT	TYA	;XOR WILL ALLOW		ess than 0 on the Y axis. Funny
0	C1E7 98	AUIDII	PHA	;WRITING AND		appen if the Y value exceeds a
•	C1E9 AC 32 C2		LDY LINE	; ERASING OVER		200, so the routine will clip for
	C1EC B9 F8 C1		LDA BITTAB,Y	OTHER GRAPHIC	you.	,
0	C1EF AØ ØØ		LDY #\$ØØ	; VALUES		ive included the assembly
9	C1F1 51 BØ		EOR (SPLO),Y			source for assembly buffs and
	C1F3 91 BØ		STA (SPLO),Y			d explanation of the theory. All
_	C1F5 68		PLA TAY			tines with the exception of
0	C1F6 A8 C1F7 6Ø		RTS			should be adaptable to any
	OII / Op	:	1110			with HiRess capabilities.
		; TABLE O	F BIT VALUES T	O SET IN A		CLE is the master routine. It
0				E FOUND IN LINE	squares	the Radius and saves it for the
		;				ng computations, and plots the
	C1F8 8Ø 4Ø 2Ø	BITTAB	BYT \$80,\$40,\$			ur dots. At LOOP DY is
0	C1FB 10 08 04		BYT \$10,\$08,\$	Ø4	increme	nted and checked if $> = DX$, if
	C1FE Ø2 Ø1		BYT \$Ø2,\$Ø1			
		; [,O RYTE	VALUES SCREEN	ADDRESSES		
			Truito Donario	المالية الرواية المالية		
@			BOTTOM ASSUMIN			
0		; TOP TO				

not the next four points are computed and plotted. When the test passes, LOOP1 swaps DX and DY. The plot direction here is from vertical axis, right and left. When DX becomes = DY, the circle is complete and a return is made.

COMPXY does the adding and subtracting of DX and DY from the center point. After each quadrant is computed, the new X and Y values are set to on by calling the plotting routine.

COMLEG finds the unknown value DX using the Pythagorean formula, the Radius squared is computed in CIRCLE.

MULT8 is an 8 bit multiply routine. An 8 bit multiply was chosen due to speed, and anything over 255 would be out of range of most screen displays, since this would only be half of the total in the Circle.

SORT returns an 8 bit square root of the unknown leg of the right triangle. Final value is rounded towards the integer value the remainder is closest to

PLOTXY is the machine dependent routine made to work on the Commodore 64's HiRes screen. Basically it uses the formula from the Programmer's Reference for setting a bit on the HiRes screen. Where it deviates is the final way it determines the byte on the screen. The mode of plotting the bit is determined from the value in The Globl MODE. The bit can be set with an OR, cleared with an AND or toggled with an XOR. The XOR will allow an object to be drawn on top of another and then erased, leaving the object underneath undisturbed. However, the XOR doesn't work very well on the circle, due to an occasional overlap of bits at the meeting point of the circle halves. Look over this routine as it can be used to plot a bit at X and Y from any kind of function (circle, line, rectangle, etc.).

CLEAR clears the HiRes screen and sets screen color to the value found at Address 02, poked here by the Basic Demo.

AICRO"

C2ØØ ØØ 4Ø 8Ø COLTAB BYT \$Ø,\$4Ø,\$8Ø C2Ø3 CØ ØØ 4Ø BYT \$CØ,\$Ø,\$4Ø C2Ø6 8Ø CØ ØØ BYT \$8Ø,\$CØ,\$Ø C2Ø9 4Ø 8Ø CØ BYT \$4Ø,\$8Ø,\$CØ C2ØC ØØ 4Ø 8Ø BYT \$Ø,\$4Ø,\$8Ø C2ØF CØ ØØ 4Ø BYT \$CØ,\$Ø,\$4Ø C212 8Ø CØ ØØ BYT \$8Ø,\$CØ,\$Ø	0
C215 4Ø 8Ø CØ BYT \$4Ø,\$8Ø,\$CØ,\$Ø ; ; HI BYTE VALUES ; TABLE ASSUMES HIRES STARTS ' \$2ØØØ	0
; C219 20 21 22 ROWTAB BYT \$20,\$21,\$22,\$23,\$25 C21E 26 27 28 BYT \$26,\$27,\$28,\$2A C222 2B 2C 2D BYT \$2B,\$2C,\$2D,\$2F C226 30 31 32 BYT \$30,\$31,\$32,\$34	0
C22A 35 36 37 BYT \$35,\$36,\$37,\$39 C22E 3A 3B 3C BYT \$3A,\$3B,\$3C,\$3E	0
C232 ØØ LINE BYT Ø ;LO 3 BITS ;	
;CLEAR : CLEAR HIRES SCREEN ' \$2000;	0
C233 A9 20 CLEAR LDA #\$20 ; NUMBER OF PAGES C235 AA TAX ; SET UP SCREEN C236 85 B1 STA SPHI ; ADDRESS C238 A9 00 LDA #\$00	0
C23A 85 BØ STA SPLO C23C AØ ØØ CLR LDY #\$ØØ C23E 91 BØ CLR1 STA (SPLO),Y C24Ø C8 INY	0
C241 DØ FB BNE CLR1 C243 E6 B1 INC SPHI C245 CA DEX ;DO 2Ø PAGES C246 DØ F4 BNE CLR	0
C248 A5 Ø2 LDA \$Ø2 ;VALUE POKED IN ; FROM BASIC	•
C24A 9D ØØ Ø4 COLOR STA \$Ø4ØØ,X ;FIRST PAGE OF C24D 9D ØØ Ø5 STA \$Ø5ØØ,X ; LO RES SCREEN STA \$Ø6ØØ,X C253 9D ØØ Ø7 STA \$Ø7ØØ,X	•
C256 CA DEX C257 DØ F1 BNE COLOR C259 6Ø RTS C25A END	٥
	•
100 REM — CIRCLE DEMO — 110 REM — CIRCLE ROUTINE RESIDENT — 120 REM — @ \$C000 130 TS=828:CL=TS+8:CH=TS+9:RAD=TS+11:MODE=TS+12 140 V=53248:CY=TS+10:POKE 2,1	•
15Ø POKE V+17,59:POKE V+24,24:GOSUB 32Ø 16Ø POKE MODE,1 17Ø R=4Ø:CX=1ØØ:Y=1ØØ 18Ø FOR I=1 TO 12:C1=Ø	0
19Ø GOSUB 28Ø:CX=CX+5:R=R-3:NEXT:C2=CX:R1=R 2ØØ CX=CX+5:FOR I=1 TO 12:C1=Ø 21Ø GOSUB 28Ø:CX=CX+5:R=R+3:NEXT	0
22Ø R=R1:CX=C2:FOR I=1 TO 12:C1=Ø 23Ø GOSUB 28Ø:Y=Y-5:R=R+3:NEXT 24Ø Y=1ØØ:R=R1:CX=C2:FOR I=1 TO 12:C1=Ø 25Ø GOSUB 28Ø:Y=Y+5:R=R+3:NEXT	0
26Ø GOSUB 33Ø:A=A+1:IF A> 31 THEN A=1 27Ø POKE 2,A:GOSUB 32Ø:GOTO 17Ø 28Ø CS=CX:IF CX> 255 THEN CX=CX-255:C1=1	0
29Ø POKE CL,CX:POKE CH,C1:POKE CY,Y:POKE RAD,R:SYS 49152: CX=CS:RETURN 31Ø POKE V+17,27:POKE V+24,21:END 32Ø SYS 49715:RETURN 33Ø FOR T=1 TO 3ØØØ:NEXT T:RETURN	0

Graphicom and the Koalapad

by John Steiner

Chicago Rainbowfest

Over a year has gone by since the first Color Computer only show, Rainbowfest. Since that first show in Chicago, there have been several around the country, most have been too far away for me to attend. I am looking forward to traveling to Chicago again for the next Rainbowfest.

At the last show, I enjoyed meeting many of the people who have made the Color Computer one of the most expandable and usable computers on the market. Also, many people who have written powerful software were in attendance. This show should be no different; if you can attend, please look for me and say hello.

Graphicom and the Koalapad

This month, I must comment in more detail about one of the best graphic oriented programs I have seen for the Color Computer, Graphicom. Yes, Graphicom is fun for the kids to play with and also interesting, but don't dismiss it as another toy program. For example, I have two practical and useful applications. I use it to create logos and designs for my company products. In addition, I use it to draw and print schematic diagrams. There are many other applications that relate to graphics in a practical business and personal sense.

Drawing with Graphicom requires a single joystick and two fire buttons. One option, however, is to use a Koalapad, modified to fit the Color Computer. For those of you who may be unaware, the Koalapad is a small drawing tablet that plugs into the joystick port of several different types of computers. There are versions for the Apple, Atari, Commodore, IBM PC, and other personal computers, and it comes withth software that allows the use of this sophisticated digitizer.

Koala Industries, however, has not seen fit to make a version of the Koalapad for the CoCo. The enterprising people at Cheshire Cat Software (creators of Graphicom) have included modification instructions to enable the use of the Koalapad with their software. After following these instructions. I found the pad to be a useful tool for other joystick applications as well. Essentially, the pad is an unusual joystick. If nothing is being pressed on the face of the pad, the joystick port returns coordinates of 32,32 (the joystick is centered). If you use a finger or other object to press on the face of the pad, the joystick port reports the coordinates of the location of the pressure on the pad. Moving the finger, or the wood "pencil" that comes with the pad, will cause the joystick coordinates to change in relation to the new location. The result of all this is that the modified Koalapad can be used anywhere you can use a standard joystick.

This new application of a joystick intrigued me, and I have found other joystick software that can use the Koalapad to better advantage than a standard joystick. It occurred to me that other people might be interested in using the Koalapad for use with Graphicom, or for other purposes. I contacted Bob Rosen of Spectrum Projects, publisher of the Graphicom program, and he gave me permission to pass along the modification instructions to vou.

The modification instructions are for the Atari version of the Koalapad. I don't know how much difference there is between versions, so you might be sure to get the Atari version. The pad retails for around \$100.00, but I have seen them on sale for less than \$80.00. In addition to the pad, you will need a six conductor cable, two 1 Megohm resistors, and one or two din plugs that fit the joystick port. A 9 to 12 volt supply is also required.

Figure one contains a circuit board layout of the pad. It is easy to interpret the drawing, once you take the screws out of the bottom of the pad. By the way, there is one screw underneath the label that is stuck to the bottom of the pad. Removing this screw will void your warranty on the pad, so you might want to have the store you purchased the pad from check the pad to make sure it is a working unit before you take it apart.

From the diagram in figure 1, the six wires are connected as follows:

Step 1 to pin 1 of the right joystick din plug.

Step 2 to pin 2 of the right joystick din plug.

Step 3 to pin 4 of the left joystick din plug. (See next paragraph).

Step 4 to pin 4 of the right joystick din plug.

Step 5 to pin 3 of the right joystick din plug and minus of the 8.3 volt supply.

Step 6 to positive of the 8.3 volt supply.

Figure 1 Modification of Atari • • Koala Pad for CoCo Joystick Port of TRS COLOR COMPUTOR Merely add 6 wires to the board, solder in two resistors and add 8.3 V power supply. O رفست 1) Hook up X axis to pin 4 of 339 Chip. 2) hook up Y axis to pin 6 of 339 Chip. 00 3) Connect left fire Connect right fire 5) Connect to ground 6) Connect 8.3 wolts Add two 1 meg ohm resistors as shown

The Koalapad has two "fire" buttons on the top of the pad. The right joystick and fire button connections are hooked to a single din plug. The left fire button is connected to the other din plug for use with Graphicom. I preferred to have only one fire button hooked up to the pad, thus allowing me to have a standard joystick, or remote footswitch in the left joystick port. With Graphicom, the left joystick is not used, only the left fire button. If you are using the tablet with other software, you may want the flexibility of having a joystick and Koalapad in either port at the same time.

Figure two is a schematic of a simple 8.3 volt regulator that is used to obtain power for the Koalapad. The manual states that the 8.3 volts there is quite critical, so they recommend regulating it. Because I was in a hurry to see how it worked, and had an old nine volt AC power supply sitting around (one of those that contain a small transformer that plugs into the wall, and a small cord that ran to a nine volt battery snap), I used it. I found that the load on the Koalapad pulled the 9 volt supply down to 8.45 volts. The pad seems to work fine. I would, however, follow their recommendations on regulating the supply, if you plan on heavy duty use of the pad.

This simple schematic shows how to use a 7805 voltage regulator as a variable voltage regulator that gets a +12 volt input, and yields a voltage that can be adjusted to the apprximately +8.3 volts required by the CoCo Koala Pad mod.

+12V 7805 +5 to +11V
R1 1000 ohms (fixed)
R2 1000 ohms (varible).

R2

I suggest getting your +12V from off your Color Compter's motherboard, and running it to your pad via the center pin of the joystick connector. You'll have to disconnect this pin from ground and then connect it to +12V on your CoCo board.

Figure 2

Figures one and two were both created using Graphicom, by the people at Cheshire Cat Software, and are reprinted from page 32 of the Graphicom software manual by permission of Spectrum Projects. These two illustrations should give you an idea of the usefulness and power of the Graphicom software.

After these simple modifications, plug the pad into the right joystick port, and run the following test program.

10 CLS 20 A = JOYSTK(0):B = JOYSTK(1) 30 PRINT@224,A,B

40 GOTO 20

When you run the program, it should print 32 SPACES 32 on the screen, indicating the two values being read in from the right joystick port. Use the wood pencil to touch the very upper left hand corner of the pad. The numbers should change to 0,0. If you press on the lower right hand corner, it should return 63,63. Moving the stick on the pad should cause the numbers to change with respect to the position of the stick.

I have had a lot of fun with the pad, and pass this information along to those of you who like to experiment with hardware. The process is fairly simple. If you try the modification, and have any problems, you may give me a call in the evening at 701-281-0549. I will try to help. Have fun, and if you develop any software that uses the pad, let me know. The pad is a useful, and interesting accessory for the CoCo.

MICRO

microbes

A Note to Our Readers: In the last issue [Micro 72:26] we printed an article on a Better Random Number Generator. Due to problems with our typesetting equipment, when we transferred the text and program, all of the special symbols such as plus signs, equal signs, greater than, less than, etc. were missing. This was brought to our attention by the authors after the issue was already printed. To correct this problem, we are listing the appropriate changes for the text and reprinting the entire program (minus the hex listing, since it was correct). We are sorry for any inconvenience this may have caused and assure you that the problem has been rectified. Thanks.

In the text wherever R[I1], R[I2],..., R[IK], R[N1], etc. appear there should be a plus sign between the letters and numbers in the brackets — R[I+1], R[I+2], etc.

Page 28, 2nd para., should read R[I+1] = R[I] + 1

Page 29, last para., should read (R[N]/m]

Page 31, under Combination of RNG's, 2nd para., should read RANDOM = XRAN [Y * 100]

Page 32, 1st para., should read RAN = USR(SELECT)

Page 32, 2nd column, 4th para., should read $\{A + B\} \mod C = [A \mod C + B \mod C] \mod C$

12345 OLDRAN

X 11111 MULT

12345
12345
12345
12345
12345
12345
1371 65295 PROD

```
*************
                                                                      BPL TRNSFR
                                                                                   ; IF NO, DO NEXT
                                                                                      IF YES, MULTIPLY.
                                                                      LDX #$Ø4
                                                                                   ; INDEX # OF BYTES
    A BETTER RANDOM NUMBER GENERATOR
                                                                     STX BYTCNT
                                                                                   ; KEEP TRACK OF # BYTES
             FOR APPLESOFT
                                                                                      DEALT WITH SO FAR
                                                            NXTBYT
                                                                     LDA MULT,X
                                                                                   ; LEAST SIGNIF BYTE
             COPYRIGHT 1984
                                                                     STA MULTMP
          THE COMPUTERIST INC.
                                                                     LDY #$Ø7
                                                                                   ; COUNT # BITS
          ALL RIGHTS RESERVED
                                                            MULPLY
                                                                     LSR MULTMP
                                                                                   ; GET LEAST SIG BIT.
                                                                     BCC SHIFT
                                                                                   ; BIT=Ø DON'T ADD.
**************
                                                                                   ; BIT SET, SO ADD
                                                                     CLC
                                                            ADD
                                                                     LDA OLDRAN, X ; OLDRAN TO NEWRAN.
; TO USE THE RNG SUBROUTINE, YOU MUST
                                                                     ADC NEWRAN, X
                                                                     STA NEWRAN, X
; SET UP THE USR FUNCTION.
; SEE EDITORIAL NOTE
                                                                     DEX
                                                                                   ; ALL BYTES DONE
                                                                     BPL ADD
                                                                                   ; NO ADD NEXT
                                                                     CLC
; LOAD IN PARAMETERS FOR THE RNG'S
                                                                                   ; YES, SO PREPARE TO
                                                                                     SHIFT OLDRAN (IE
; Z: RAN=(31415938565*OLD+246Ø7)MOD2Ø
                                                                                     MULT * 2). DROP LAST
                                                           ;
                                                                                     CARRY AS IT IS
 ZADD
                                                                                     Ø MOD2Ø ANYWAY.
          BYT $00,$00,$00,$67,$27
                                                            SHIFT
 ZMULT
          BYT $07,$50,$89,$2E,$05
                                                                     LDX BYTCNT
                                                                                   ; # BYTES TO SHIFT
                                                            SHFTIT
                                                                     ROL OLDRAN, X
 ZRAN
          BYT $00,$00,$00,$00,$00
                                                                                   ; BYTE LEFT
                                                                     DEX
; Y: RAN=(84134532Ø5*OLD+99991)MOD2Ø
                                                                     BPL SHFTIT
                                                                                   ; YES, SHIFT IT.
                                                                     LDX BYTCNT
                                                                                 ; RECOVER # BYTES.
 YADD
          BYT $00,$00,$01,$86,$97
 YMULT
                                                                     DEY
                                                                                   ; MORE BITS LEFT
          BYT $Ø1,$F5,$7B,$1B,$95
                                                                                       IN THIS BYTE
 YRAN
          BYT $00,$00,$00,$00,$00
                                                                     BPL MULPLY
                                                                                   ; YES, MULT BY NEXT.
; X: RAN = (27182819621*OLD+3)MOD2Ø
                                                                     DEC BYTCHT
                                                                                 ; NO, DONE A BYTE.
                                                                     LDX BYTCNT
                                                                                 ; ANY BYTES LEFT
 XADD
          BYT $00,$00,$00,$00,$03
 XMULT
                                                                     BPL NXTBYT
                                                                                   : YES MULT BY IT.
          BYT $06,$54,$38,$E9,$25
 XRAN
          BYT $00,$00,$00,$00,$00
                                                                     LDY XYORZ
; ADD LOOKUP TO BASE LOCS FOR
                                                                                   ; DONE. PUT THE
                                                                     LDX #$Ø4
                                                                                   ; NEW RND INTO THE
; PARAMETER ADDRESSES FOR CURRENT RNG.
                                                                     LDA NEWRAN,X ; RESPECTIVE RNG'S
                                                            MOVRAN
 LOOKUP
         BYT $Ø4,$13,$22
                            ; Z, Y, X
                                                                     STA LSTBAS,Y ; LAST RAN STORAGE.
 XYORZ
                       ; WHICH GENERATOR
          BYT $ØØ
                       ; Y-REG ON ENTRY
 YTEMP
          BYT $ØØ
                                                                     DEX
                                                                                   ; MORE TO MOVE
                                                                     BPL MOVRAN
 XTEMP
                                                                                   ; YES, DO.
          BYT $ØØ
                        ; X-REG ON ENTRY
 MULT
          BYT $00,$00,$00,$00,$00
 OLDRAN
          BYT $00,$00,$00,$00,$00
                                                           ; DONE. NOW TO NORMALIZE FAC, ALIAS NEWRAN.
 RNG
                                                                     LDY #$28
                                                                                   ; $28 (40) BITS IN FAC.
          PHP
                       ; SAVE EVERYTHING
          STX XTEMP
                                                            NRMLIZ
                                                                     LDA NEWRAN
                                                                                   ; FIND HIGHEST SET.
          STY YTEMP
                                                                     ROL
                                                                                   ; # SIGNIFICANT =
                                                                                     28 - # NOT SET
          JSR SIGN
                       ; SEE EDITOR'S NOTE FOR
                                                                                   ; LEAVE WHEN TOP BIT FOUND
                                                                     BCS BITSET
                        ; SIGN ROUTINE
                                                                     ROL NEWRAN+4 ; NOT FOUND YET, SO
                        ; FAC HOLDS S OF USR(S)
                                                                     ROL NEWRAN+3 ; GET RID OF THE Ø
                          PUT FF IN A IF S< Ø.
;
                                                                     ROL NEWRAN+2 ; BIT AT THE TOP.
                          PUT Ø IF Ø. 1 IF S> Ø
                                                                     ROL NEWRAN+1 ; Y WILL KEEP TRACK
          TAX
                        ; FROM THIS
                                                                     ROL NEWRAN ; OF # OF BITS LEFT.
          INX
                       ; DECIDE WHICH RNG
                                                                                   ; ANY LEFT
          LDY LOOKUP, X ; VIA LOOKUP TABLE AND
                                                                     DEY
                                                                                   ; YES, KEEP LOOKING
          STY XYORZ
                       ; SAVE IT FOR LATER
                                                                     BNE NRMLIZ
                                                                                      NO. ALL DONE.
; NOW THAT WE KNOW WHICH GENERATOR, MOVE
                                                                                   ; PROTECT AGAINST
                                                                     DEY
; ITS CONSTANTS TO THE TEMP LOCS.
                                                                                      DIVIDE BY Ø.
                                                                                   ; PUT Ø IN FAC'S
                                                            BITSET
                                                                     LDA #$ØØ
                                                                     STA NEWRAN+4
                                                                                  ; SIGN BYTE.
          LDX #$Ø4
                       ; LOOP TO TRANSFER
                                                                                   ; GET # SIG BITS
TRNSFR
         LDA ADDBAS,Y ; RNG'S VALS TO
                                                                     TYA
                                                                                   ; PUT IN FAC'S +$80
                          STANDARD LOCS, I.E.
                                                                     CLC
                                                                     ADC #$58
                                                                                   ; FORMAT: $58+$28=$8Ø.
          STA NEWRAN,X ; ADD CONST TO NEWRAN,
                                                                                   ; PUT IN EXPONENT
          LDA MULBAS,Y ; MULT CONST
                                                                     STA RANEXP
          STA MULT,X ; TO MULT,
                                                                                     BYTE AND DONE.
          LDA LSTBAS,Y ; LAST RND VAL FROM
                                                                     LDY YTEMP
                                                                                   ; SO, UNSAVE
         STA OLDRAN, X ; THIS RNG TO OLDRAN
                                                                     LDX XTEMP
                                                                                   ; EVERYTHING
         DEY
                                                                     PLP
                                                                                   ; AND
                                                                     RTS
                                                                                   ; SAY GOODBYE.
         DEX
                       ; 5 BYTES DONE
                                                                     END
```

catalog

Name:

Printerface Intelligent

Interface

Printers: Diablo Hytype I, Hardware:

Hytype II, DEC LQP-01,

Xerox

Description: This unique printer interface board is installed in the printer rather than the computer, and upgrades an older printer to perform like the best Daisy Wheel printers. Model DT150 and DT151A intelligent interfaces snap into place without modifying the printer and provide all standard configurations, including RS232 serial, Centronics parallel, IEEE488, and Current loop.


Features include automatic bidirectional printing, microspace, proportional spacing, bold facing, auto centering, variable pitch, self test and debug modes. Accessories available include a 16K buffer memory and a front control panel for 16 functions.

Price:

\$395.00

Contact:

Kuzara International 7770 Vickers, Suite 105 San Diego, CA 92111 619/569-9107



Name: Hardware:

MasterType Apple, Atari,

Commodore-64

Description: "Mastertype" is the bestselling educational software program, having sold over 150,000. It teaches typing and keyboard skills through an exciting arcade game format, and is now the first software program designed to teach Dvorak keyboard skills on the Apple IIc. The new version has been enhanced with HiRes graphics, scoring retention, and, in addition to the 18 lessons on the standard QWERTY keyboard, five lessons on the Dvorak keyboard.

The Dvorak keyboard increases speed and comfort because the most frequently used keys are placed on the "home row" beneath the typists strongest fingers. It is beginning to gain wide acceptence.

Price:

\$39.95

Contact:

Scarborough Systems 25 North Boardway Tarrytown, NY 10591

914/332-4545

Name:

B.I.-80 Column Adaptor

System:

Commodore-64

Description: A high-quality 80 column plug-in module that eliminates the problems of snow, fuzziness, hashing and interference. It gives optimum clarity, even with a full screen of characters, and can easily switch from 40 to 80 column display at any time.

B.I.-80 can be used with Commodore color monitors 1701 and 1703, or with any monochrome video monitor. It is self-initializing, with complete 80 column operating system and BASIC 4.0 language built in. Comes with one year warranty, and full documentation, including a description of the BASIC 4.0 language.

Price:

Contact:

Batteries Included 186 Queen Street West

Toronto, ON m5v 1z1

Canada 416/596-1405



Decisions Name: System: Atari Memory: 48K

Description: A new program that provides assistance on making a logical choice among several alternatives, for both home and business use. The program is flexible enough to analyze any multiple choice decision. Features such as fully prompted inputs, help screens, rapid re-analysis and thorough reference manual make it easy to use. Graphic output screens are easily interpreted and a hard copy record is provided to users with an 80-column printer.

The program uses logical analysis based on scientific principles. It is available either on 5 1/4" disk or cassette tape. Available at some dealers or by mail order.

Price:

\$37.50

Contact:

Lateral Software

P.O. Box 605 Stanton, CA 90680 714/826-3970

Name:

Interface Adapter Board

System:

Commodore 64

Description: The 6522 VIA (Versatile Interface Adapter) input/output chip interface adpater board allows 6522 programming techniques, covered in many available books, to be applied to the C-64 for real-time control applications. It allows full use of the IRO interrupt and, when combined with the C-64's memory capacity, provides a powerful development system and controller in one package. Extensive application notes and programming examples are included.

Each board includes two 6522s, with total of four 8-bit bidirectional I/O ports, eight handshake lines, four 16-bit timer/counters. Up to four Model 64IF22 boards can be connected, providing 16 8-bit ports.

Price:

\$169.00 for first; \$149 for

each extra


Contact:

Schnedler Systems 1501 N. Ivanhoe,

Dept. NR

Arlington, VA 22205

703/237-4796



Name:

Apple SourceLink

Minimum 48K

Apple II, IIe, II Plus System: Memory:

Description: Communications software designed to supplement the use of The Source by personal computer owners. It is compatible with the new Apple modem, as well as the Hayes and Transend modem products. The software includes automatic dialup and sign-on procedure for Telenet, Uninet and Sourcenet networks. simultaneous capture of data from The Source into the Apple memory or disks. including a capture editor and simplified transfer of data from disks to The Source. An additional feature allows Apple and IBM users to automatically access any number of pre-determined services and databases once online.

Contact:

The Source

1616 Anderson Road McLean VA 22102 703/734-7500

Name:

ScreenShooter

Hardware: CRT

Description: A simple way to take photos and slides of a computer CRT using Polaroid 600 High Speed color film, Polachrome 35mm instant slide film, or conventional 35mm color or black and white films. The outfit includes a Polaroid One Step 600 Camera, CRT hood, CRT hood adapter, diopter lens and 35mm SLR camera bracket.

When using the Polaroid One Step, camera exposure is automatic. You place the Screenshooter against the computer screen, view the image through the camera and click away. When using a 35mm SLR camera, the camera's built-in metering system is used to find the exposure. Screenshooter comes with a lifetime warranty (the camera has one year warranty).

Price:

\$169.00

Contact:

NPC Photo Division 1238 Chestnut Street Newton, MA 02164 617/969-4522

Name:

Language Development

Software

System:

Apple II/IIe (Atari

coming soon

One disk drive Hardware:

Description: Currently available languages in this product line include Spanish, French, German, Italian, Biblical Hebrew, Modern Hebrew and Arabic. In the near future, Latin, Russian, Polish, Swedish, and Classical Greek will also be available. All programs teach 1000 of the most common words in the target language. When words have more than one meaning, the program allows for these other meanings, along with English translation. A "Teach Yourself Book"is included in the package for additional information.

Each language program is menudriven with sequential review, random review and quiz options. The software gives instant feedback, tests, and percentage of correctness through interactive learning.

Price:

\$56.95

Contact:

Soflight Software

2223 Encinal Station Sunnyvale, CA 94087

408/735-0871

Name: System: Bug Off! Apple II or IIe

Memory:

64K

Language: Pascal 1.1 or 1.2

Description: A powerful tool that saves time in testing and debugging Apple II Pascal programs. The easily installed package runs at nearexecution speed and is totally interactive. The command screen gives you complete control and lets you build and use your own macros. Stored debugging commands let you start where you left off and you can insert breakpoints wherever you want them.

This package comes with a guarantee of total refund if you are not satisfied and return it within 30 days of shipment.

Price:

\$49.96

Contact:

First Byte

2845 Temple Avenue LongBeach, CA 90806 213/595-7006

Name: Fit and Trim System: Apple II/IIe Memory: 64K RAM

1-2 disk drives, printer Hardware:

optional

Description: This educational and counseling program for weight control features two units. The first Educational unit provides general information on eating and activity changes needed for weight loss, suggesting goals for aerobic, muscle building and other activities. The Counseling unit has Weight Review (projections, current weight and change progress displays), Eating Review (analysis of food you eat, showing calories and problem foods with recommended changes), and Exercise Review (analysis of activities with weekly exercise suggestions).

Five week histories can be summarized and recommendations for weight change can be printed. Capacity is 80 individuals per diskette. The program can be copied and is modifiable.

Price: Contact: \$39.95 Andent, Inc

1000 North Avenue Waukegan, IL 60085

312/223-5077

Name: Digital TLC-1 Hardware: Any RS232 devices

Description: This is a three port active switch that lets any two RS232 devices share a third and also communicate with each other. Any transmission format at any rate up 19,200 baud can be tο accommodated and all connections are made via a six button control panel with out switching transients.

Proper connection between the transmitted and received data pins is fully resolved with the TLC-1 for any combination of Data Communication Equipment and Data Terminal Equipment. Permitting 64 possible connection combinations, all data paths are monitored by six LEDs.

Price:

\$245

Contact:

Digital Laboratories, Inc.

600 Pleasant St.

Watertown, MA 02172

617/924-1680

Name: SpellPack System: Commodore-64

Description: This powerful program teaches your C-64 to spell and checks an entire document in 2-4 minutes. It contains a dictionary of over 20,000 of the most commonly used English words, and allows you to expand this by 5,000 specialized terms.

Each word is compared to the dictionary and those not found are highlighted in context, right on the screen. If the word is misspelled, it can be edited and instantly added to the dictionary. If it is correct but not listed, it can also be added immediately. It accelerates the page rate of checking so that a one page document may take two minutes to check, but a five pager may only take three minutes. Additions and corrections are made with single key command. SpellPack works with most major word processing programs.

Price:

Contact: Batteries Included

186 Queen Street West Toronto, ON m5v 1z1

Canada

416/596-1405

4 in 1 Name: System: Apple

Description: An enhanced database management system that simplifies record-keeping at home or business by handling four separate functions: word processing, list and label making, calculations and data management.

Major data processing operations are combined in a single program so there is no need to change disks midproject. For example, 4 in 1 can perform calculations on defined fields, then merge those fields plus the results into forms or letters created with the word processor. Current tab stops and margin settings are indicated onscreen, as are menu options, prompt messages and system operating messages.

Price:

\$129.95

Contact:

Softsmith Corp.

1431 Doolittle Drive San Leandro, CA 94577

415/487-5900



Name: System: Intec 300 Modem

Apple II/IIPlus/IIe, TRS80 Model 3/4, IBM

Description: A new auto dial/auto answer modem featuring software and essential phone-computer interface connections to function with several computers. Also provided is easy to follow, detailed documentation.

Features include data capture direct to disk file as well as memory buffer, 255 number auto-dialing telephone directory with auto redial of last phone number, non-ASCII file transfer, optional add/delete of linefeeds, transmission of true break signal, and many more.

Price:

\$189.00

Contact:

Intec Corp.

West Bloomfield, MI



Title:

The RS-232 Solution

Author:

Joe Campbell

Price:

\$16.95

Publisher: Sybex Computer Books

The problem of interfacing your computer with any RS-232-C peripheral is covered in this book. Using tools that total less than \$15.00, the reader is instructed how to measure logic levels and conduct other tests. The results of these tests are then taken to derive a specification for a cable, thus making the correct connections. There are ample diagrams and illustrations explaining the basics and beyond, of serial interfacing. The author's 'fool-proof' method is illustrated with real case studies. Case studies include SB80/ADDS, N*/OKI, KayPro/Epson, Osb/TnT, and IBM/NEC. In addition to printers, the interfacing of modems, terminals, and plotters is also explained.

Title:

The Elements of Friendly Software Design

Author:

Paul Heckel

Price:

\$8.95

Publisher: Warner Books

Taking the approach that software is a communication craft, the author draws upon a variety of innovators in this area. Citing such greats as Walt Disney, George Orwell and Leonardo Da Vinci, the idea of visuality and clear communication in software is emphasized. All of the elements of friendly software design are covered from the perspective of both the user and designer. Attention is given to what the user expects, perceives, feels and thinks; all lending to a better understanding and foundation from which to design software. Prototypes and innovations are examined. Points are supported with a variety of pictures, illustrations, etc. Thirty principles of software design are given in addition to seven traps that catch experienced designers.

Title:

The BBC Microcomputer for Beginners

Authors:

Seamus Dunn & Valerie Morgan

Price:

\$13.95

Publisher: Prentice/Hall International

This book covers the in's and out's of the BBC Microcomputer, more popularly known as the Acorn; both models, A and B, are covered. In addition to noting the various characteristics and options available on the BBC microcomputer, programming in BASIC is also covered. In this vain, the book guides the reader in a learning by doing process. Carefully sequenced programs take the user through a variety of programming 'musts', including: conditionals, loops, file management, functions, strings, formatting, graphics, color, and sound. The approach is

that of structured programming. The marriage of programming skills and knowledge of the machine are integral to the book as a whole. There are examples and sample programs to aid the reader in learning both the BBC microcomputer and structured programming using BASIC. At the end of each chapter are problems, happily at the back of the book answers are also provided.

Title:

Microprogrammers Market 1984

Author:

Marshall Hamilton

Price: Publisher: \$13.50 Tab Books

Basically a sourcebook for programmers looking to sell their program ideas, this listing covers hundreds of companies. The information provided on each publisher includes: Company name, address, telephone number, president, submission contact, microcomputer systems covered, age of the company, company's publishing track record, what they are looking for, payment methods, how and when submissions should be handled, response time, current program sources, what types of programs are now being sold and how they are marketed. In addition the author provides a number of valuable tips on writing, submitting and selling. Listings are broken down into Business/Industry, Educational/Tutorial, Games, Home Use, and Utilities.

Title:

How to Make Love to A Computer

Author:

Dr. Maurice K. Byte

Price: \$3.95

Publisher: Pocket Books

For those who are really into their computer this book is a must. Learn the heretofore unspoken secrets of how to make love to your computer. Every aspect is touched upon in this Kama Sutra of computer love making. From the first meeting to that special night together, all of the in's and out's of computer romance are examined. Sexual fears, tips from pros, computerotica, and the joy of programming are a few of the many areas this book covers. Complete with photographs, this is not a book for children.

Title:

Price:

The Illustrated dBase II Book

Author:

Russell A. Stultz \$16.95

Publisher:

Spectrum Books

A reference/tutorial for the popular dBase II software program by Ashton-Tate. The author uses modules to teach the reader how to use dBase II. With the aid of examples and illustrations the beginning programmer is guided through the world of database management. Descriptions of dBase II files, how they are stored, displayed, printed and edited are included. The experienced programmer will find that this can be used as a handy reference; educators will also find the concise text helpful. The modules are alphabetically organized, with a good index offering further reference support. All the reader needs is dBase II, and 8- or 16-bit microcomputer with at least 64K RAM, a disk drive, and a printer.

MICRO Program Listing Conventions

Commodore

```
LISTING
             C64 KEYBOARD
Commands
(CLEAR)
            II ^ CLR
(HOME)
            HOME.
(INSERT)
            I ^ INST
(DOWN)
            民 CRSR DOWN
(UP)
            🕽 ^ CRSR UP
(RIGHT)
            CRSR RIGHT
(LEFT)
            *** ^ CRSR LEFT
Colors
(BLACK)
            ■ CTRL 1 BLK
(WHITE)
            # CTRL 2 WHT
(RED)
            M CTRL 3 RED
(CYN)
            ETRL 4 CYN
(PURPLE)
            X CTRL 5 PUR
(GREEN)
            CTRL 6 GRN
(BLUE)
            CTRL 7 BLU
{YELLOW}
            TE CTRL 8 YEL
(RVS)
            A CTRL 9 RVS ON
(RVSOFF)
            ■ CTRL O RVS OFF
(ORANGE)
(BROWN)
(GREY 1)
            ŏ
               = 3
(GREY 1)
            1
(GREY 2)
            53
(LT GREEN)
               = 6
(LT BLUE)
            7
               = 7
(GREY 3)
               = 8
Functions
(F1)
            ■ f1
(F2)
            ↑ f2
(F3)
            ■ 43
(F4)
            ₽ ^ f4
            # f5
(F5)
(F6)
            2 º f6
(F7)
            #1 f 7
(F8)
Special Characters
(PI)
            ff ^ Pi Char
(POUND)
            £ Pound Sign
(UP ARROW) T Up Arrow
```

Atari

Normal Alphanumeric appear as UPPER CASE:
SAMPLE
Reversed Alphanumeric appear as lower case:
yES (y is reversed)
Special Control Characters in quotes appear as:
(command) as follows:

Listing Command ATARI Keys

Conventions used in ATARI Listings.

Listing	Command	ATARI Keys
(UP) (DOMN) (LEFT) (RIGHT) (CLEAR) (BACK) (TAB) (DELETE LINE) (INSERT LINE) (CLEAR TAB) (SET TAB) (BEEP) (DELETE) (INSERT) (CTRL A)	Cursor Down Cursor Left Cursor Right Clear Screen Back Space Cursor to Tab Delete Line Insert Line Clear Tab Stop Set Tab Stop Beep Speaker Delete Char. Insert Char. Graphic Char.	ESC/CTRL - ESC/CTRL + ESC/CTRL + ESC/CTRL * ESC/CLEAR ESC/CLEAR ESC/BACK S ESC/TAB ESC/SHIFT DELETE ESC/SHIFT INSERT ESC/CTRL TAB ESC/CTRL TAB ESC/CTRL 2 ESC/CTRL BACK S ESC/CTRL INSERT CTRL A Aphic Letter Key

Non-Keyboard Commands

(DIS=)	CHR\$(8)
(ENB=)	CHR\$(9)
(LOWER CASE)	CHR\$(14)
(UPPER CASE)	CHR\$(142)
{^RETURN}	CHR\$ (142)
(DEL)	CHR\$(20)
(SPACE)	CHR\$ (160)

Notesi

- represents SHIFT KEY
- represents Commodore key in lower left corner of keyboard
- 3. CTRL represents CIRL Key
- Graphics characters represented in Listing by keystrokes required to generate the character
- A number directly after a (SYMBOL) indicates multiples of the SYMBOL: (DOWN6) would mean DOWN 6 times

{BACK ARROW}← Back Arrow

Advertiser's Index

Andent, Inc
Batteries Included 75,77
Computer Mail Order Ins Frt Cvr, 1
Computerose Ins Back Cvr
Digital Laboratories
F. Ashton 18
First Byte 76
Indus-Tool 9
Intec Corp 77
Kuzara International 75
Lateral Software 75
MICRO 14
MICRO Magazine 64,67, Ins Back Cvr
NPC Photo Division
, ,
NPC Photo Division
NPC Photo Division 76 Protecto 39,40,41
NPC Photo Division 76 Protecto 39,40,41 Safeware 14
NPC Photo Division 76 Protecto 39,40,41 Safeware 14 Scarborough Systems 75
NPC Photo Division 76 Protecto 39,40,41 Safeware 14 Scarborough Systems 75 Schnedler Systems 7,76
NPC Photo Division 76 Protecto 39,40,41 Safeware 14 Scarborough Systems 75 Schnedler Systems 7,76 Soflight Software 76
NPC Photo Division 76 Protecto 39,40,41 Safeware 14 Scarborough Systems 75 Schnedler Systems 7,76 Soflight Software 76 Softsmith Corp. 77
NPC Photo Division 76 Protecto 39,40,41 Safeware 14 Scarborough Systems 75 Schnedler Systems 7,76 Soflight Software 76 Softsmith Corp. 77 Specialty Electronics 9

More Fun Than The French Foreign Legion

Join the elite corps of authors—Join MICRO!

We are looking for a few good writers who have what it takes:

- a technical understanding of computers
- · innovative techniques and programs
- · good writing skills
- a desire to participate in an exciting and growing field
- the ability to take old ideas beyond themselves
- the willingness to contribute and make a difference.

Don't wait--send for your Writer's Guide today.

Send a S.A.S.E. to:

Mike Rowe MICRO INK P.O. Box 6502 Chelmsford, MA 01824

Next Month In MICRO

Features

The UCSD P-System — This is a more powerful operating system than MS-DOS and the 8088, and, on a 68000 machine, a very fast one, too. Reviews of six 68000 machines are included.

Constructing 3-D Mazes — The program actually gives you rat's-eye views of the maze corridors — and all in 3 1/2K of RAM.

Graphics Print for C64 — The third part of this series adds a program that loads graphic files from a number of popular graphic programs, displays them and dumps them to a printer.

Atari/Epson Character Printing — The Atari puts a tremendous variety of graphic characters on screen; this program allows even custom characters to be put on paper.


Hilister — The second of a two-part series, this covers moving around within a program listing.

Alter T & S — Dump, in hex, any sector on a diskette with Commodore format and then modify any byte in that sector without the loss of other data.

Plus More...

Departments

Reviews in Brief Spotlight Software/Hardware Catalogs New Publications Interface Clinic Lyte Bytes




This famous book now contains the most comprehensive description of firmware and hardware ever published for the whole Apple II family. A new section with guide, atlas and gazeteer now provides Apple IIe specific information.

- Gives names and locations of various Monitor,
 DOS, Integer BASIC and Applesoft routines and tells what they're used for
- Lists **Peeks, Pokes** and **Calls** in over 2000 memory locations
- Allows easy movement between BASIC and Machine Language
- Explains how to use the information for easier, better, faster software writing

This expanded edition is available at the new low price of only \$19.95

For the 35,000 people who already own previous editions, the IIe Appendix is available separately for just \$5.00.

Name	
Address	
City State	Zip
Signature	
□ Check □ VISA □ MasterC	ard
Acct #Expires	
x 6502, Chelmsford, MA 01824	
ng)	Address City State Signature Check □ VISA □ MasterC



Take an active role in your child's development.

Parenting. The most important and rewarding endeavor you'll ever undertake. Gaze into your child's eyes. They're capturing all the wonders of the world around him, and looking to you for guidance.

Now you can gain a unique insight into your child's world with Childpace™— an amazing new Child Development Program for ages 3 to 60 months.

Share the precious firsts.

When will your baby dazzle you with his first spontaneous smile? Stand alone? Take that first wobbly step?

The first five years are filled with continual growth and change. And questions. So even if your child's a toddler, you're still looking for answers. When will he start dressing himself? When should those random scribbles turn into distinctive shapes?

Compare apples-to-apples. Childpace lets you evaluate your child's dexterity, language and social skills in the privacy of your own home. You enter information into Childpace, then he attempts tasks that are appropriate for his age group.

Childpace assesses his skill level based on extensive research, not the biased opinions of friends or relatives. Childpace uses your child's chronological (actual) age.

Grow with your child.

As your child grows, the tasks change to match his newly acquired skills. So Childpace is just as valuable for a 48-month old child as for an infant. Childpace can even evaluate up to 16 different children, and keep permanent records on each of them. Snapshots record your child's physical growth, but Childpace documents his or her actual development.

Track your child's progress, and help him develop specific skills. Childpace also contains warning signals to alert you to potential developmental problems at an early age, before they hold your child back. An ounce of prevention pays off. Childpace. A fascinating glimpse into the world of child development. And more importantly, into your child's world.

Look for Childpace at your local computer hardware or software store. If unable to find it, send \$39.95 to Computerose, Inc. Please allow two weeks for processing. 30 day money back guarantee.



\$39.95 suggested retail price

Childpace is available for the Commodore 64% IBM PC, IBM PC Jr., Atari 800% Apple II, and Radio Shack Color Computer.

*Each is a registered trademark of the respective manufacturer.



2012 East Randol Mill Road Suite 223 Arlington, TX 76011 (817) 277-9153 © 1984 Computerose, Inc.